

**BLOWER HOUSING
REPLACEMENT KIT****INSTALLATION INSTRUCTIONS FOR BLOWER HOUSING REPLACEMENT KIT
(21P18 & 21P20; 621654-05 & 06) USED WITH LGM/LCM036-060 UNITS****Shipping and Packing List****Package 1 of 1 contains:**

- 1- Blower housing

⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional HVAC installer or equivalent, service agency, or the gas supplier

⚠ CAUTION


As with any mechanical equipment, contact with sharp sheet metal edges can result in personal injury. Take care while handling this equipment and wear gloves and protective clothing.

Application

The blower housing replacement kit is used on LGM/LCM036 - 060 unit direct drive blowers. 21P18 (621654-05) does not have corrosion protection. 21P20 (621654-06) has corrosion protection.

Remove Housing

- 1- Disconnect electrical power to unit. Wait five minutes before continuing service procedures to avoid electrical shock. This will allow internal capacitors time to fully discharge.
- 2- Open access panels as shown in figure 1.
- 3- Disconnect J48 from P48 in the blower area and unscrew the ground terminal from the blower deck.

**FIGURE 1**

- 4- Disconnect the Modbus 9-pin blower control plug located in the blower area.
- 5- Remove four screws securing blower assembly to unit. See figure 2.
- 6- If unit was equipped with an optional blower proving switch, remove switch from existing blower housing.
- 7- Remove PT6 pressure transducer bracket and silicone tubing from housing. See figure 2. If needed, remove the inlet ring to disconnect the tubing from the inlet ring barb. See figure 3. Disconnect the pressure transducer wire connector.
- 8- Use the handle on the blower assembly to slide the assembly out of unit.
- 9- Turn the blower assembly upside down. See figure 4.
- 10- Remove the inlet grill, orifice and the side of the housing shown in figure 3.
- 11- Remove the motor / impeller secured to the existing housing. See figures 3 and 4.
- 12- Discard existing housing.




FIGURE 2

Install Replacement Housing

- 1- Remove one side of the replacement housing. See figures 3 and 4.
- 2- Install existing motor / impeller on replacement blower housing in the same manner the motor / impeller was removed from the discarded housing. Secure with 6 bolts provided in this kit. Tighten to 21.7 ft.-lbs.
- 3- Replace the blower housing side, orifice and inlet grill which was previously disassembled. Tighten orifice screws to 10.8 ft.-lbs. Tighten inlet grill screws to 3.7 ft.-lbs.
- 4- If previously removed, attach the optional blower proving switch to replacement housing in the same manner it was removed.
- 5- Attach the pressure transducer bracket, wire connector, and silicone tubing to the housing in reverse order of removal.
- 6- Install blower assembly flanges into rails on the blower deck in the same manner the discarded housing was removed. Secure into place using four screws shown in figure 2.
- 7- Connect P48 to J48 in blower compartment. Screw GND terminal to blower deck in the same manner it was removed.
- 8- Connect the Modbus plug in the blower area to the replacement blower motor 9-pin control plug.
- 9- Bundle harnesses and use wire ties to secure kit harnesses to unit harnesses in the same manner they were removed.




FIGURE 3




FIGURE 4