



LENNOX

User Guide

Color Touchscreen
Programmable Thermostat

ComfortSense® 5500 (13H13)

TABLE OF CONTENTS

Features	2
Temperature Dial Indicator	3
Home Screen	5
Selection Mode	9
Menu Screen	11

Features

The ComfortSense® 5500 Series thermostat is an electronic 7-day, single-stage, programmable, touchscreen thermostat. Features are:

- Large, clear color display that shows the current and set temperatures and time.
- Ergonomic design.
- Smooth Setback Recovery starts system early to achieve setpoint at start of program period.
- Compressor short-cycle protection (5 minutes).
- Real-time clock keeps time during power failures and automatically adjusts for daylight savings time and leap year.
- Program Hold options allow user to override the program schedule as desired by time and date.
- Select individual days or groups of days to set programming.
- Programmable fan offers increased performance when combined with whole home indoor air quality products.

Temperature Dial Indicator




Figure 1. Temperature Dial Feature

- A. This is the maximum **heat position indicator** on the dial. This object will be red in color.
- B. This is the maximum **cool position indicator** on the Dial. This object will be blue in color.
- C. This is the location area where no system demand is active. In figure 1, the example would be any temperature between 73°F and 77°F.
- D. When there is an active call for heating, this area of the dial will fade back and forth from white to red.
- E. When there is an active call for cooling, this area of the dial will fade back and forth from white to blue.
- F. The yellow line indicates the actual room temperature on the temperature dial indicator.

Home Screen





Figure 2. Home Screen


Press the screen anywhere - the first press turns on the backlight.

A. OPERATING MODE - press to access the screen that will list available modes. Selectable modes are heat/cool, heat only, cool only, off, schedule 1, schedule 2, and schedule 3. In addition fan operation can be set to on, auto or circulate.



B. AWAY - Selecting AWAY will allow the user to set the heating and/or cooling mode temperatures when away from home.

Press **cancel** to exit this screen and return to the home screen and normal system operations.







C. Displays current time.

D. Menu - This will allow access to **notifications, performance report, schedules and settings.**

- E. This allows you to set the **heat-to** (if enabled) temperature. Selecting the **heat-to** or temperature dial position indicator will take you to the temperature setting detail screen. The temperature dial will change from white to red when heating is active.
- F. This allows you to set the **cool-to** (if enabled) temperature. Selecting the **cool-to** or temperature **dial position indicator** will take you to the temperature setting detail screen. The dial will change from white to blue when cooling is active.
- G. Displays the current indoor temperature.
- H. Indicates the schedule is on hold until the next time period or permanent.
 1. Place the schedule on hold by pressing on either the **heat-to** or **cool-to** location on the screen. If an adjustment is required for the temperature setting, this can be done now.
 2. After approximately three seconds the screen will display the override setting options.
 3. From the override setting screen, the options are **1 hour**, **2 hour** or **Permanent**. Make selection and then press **set**.
 4. For the 1 or 2 hour setting the home screen will indicate **schedule hold until *time indicated*** (i.e., 11:57 pm). To exit schedule hold, press ⊗.
 5. For the permanent setting the screen will indicate **schedule hold permanently**. To exit schedule hold, press ⊗.
- I. **System Status Icons** - Equipment operation information appears along the left side of the home screen. The displayed icons will indicate heating demand, cooling compressor delay, cooling demand or transitioning to next schedule setting (see table 1).

Table 1. System Status Icons

	Red flames indicates the system is heating.
 waiting	Snow flake indicates the next mode of operation will be cooling. Waiting indicates there is a compressor delay which is by default 5 minutes and not adjustable.
	Blue flames indicates the system is cooling.
	Transitioning to next schedule setting.

Selection Mode

Press anywhere in the area indicated below to select how the system will operate.




Figure 3. Home Screen (Accessing Mode Screen)




OPERATING MODES

1. **HEAT/COOL** allows the thermostat to switch between heating and cooling automatically.
2. **HEAT ONLY** allows only heating demand.
3. **COOL ONLY** allows only cooling demand.
4. **OFF** indicates system has been turned off.
5. **SCHEDULES (up to three can be set), FAN-ON, AUTO and CIRCULATE** (see *Edit Schedules* on page 13 for customizing schedules).
6. **ON, AUTO and CIRCULATE** - Select by pressing the desired fan operation ON, AUTO and CIRCULATE. When selected a green check mark will be indicated.

If FAN mode AUTO, ON or CIRCULATE was selected during scheduling for the current period, the thermostat will indicate the current fan mode in the information display (FAN ON or FAN CIRC).

In the CIRCULATE mode, the user can cycle the fan for a programmed period time of active time per hour during periods of equipment inactivity (i.e., heating or cooling equipment not running).

Table 2. Fan Operation

	on	Fan is NOT following the schedule and runs continuously until it is changed from the select mode .
	auto	Fan will follow the fan setting in the selected schedule.
	circulate	Fan is following schedule and cycles during periods of equipment inactivity. Circulate off time is dependent on user settings.




Figure 4. User Menu Screen

NOTIFICATIONS

When a system error or reminder occurs, a pop-up screen will appear indicating the condition.

- Error code notification pop-up can be dismissed by pressing the back button. Contact the dealer to resolve the issue.

- For notification, press either clear or set a future reminder.
Any active history for notifications (critical errors or reminders will be listed under settings > notification.

If critical errors occur, they will also be displayed under **notifications** as illustrated in figure 5. Press the contractor info option for assistance.




Figure 5. Notifications - Critical

PERFORMANCE REPORT

This will display the total number of hours each month that the system has been running. Example would be for mar (March) 23H or 23 hours. To return to the menu screen, press the house icon in the upper left-hand corner of the screen.

EDIT SCHEDULES

NOTE: See Selection Mode on page 9 to run a specific schedule.

From the HOME screen press the **MENU** and press **edit schedules** option.

The edit schedules screen will allow section of up too three separate schedules. On the edit schedules screen, each schedule can be renamed and edited. See Figure 7 for editing schedules.

NOTE: *If a fan mode is selected under the **select mode** screen, it will over-ride any fan setting in individual schedules.*

<	edit schedules	
	schedule 1	>
	schedule 2	>
	schedule 3	>
	add schedule	

Figure 6. Edit Schedules Screen




Figure 7. Renaming and Editing Schedules

SETTINGS (USER)





<	user settings	
	fan	>
	heat/cool	>
	general	>
	display	>

Figure 8. User Settings Options

Table 3. User Settings (Fan)

Setting Selection	Function	Description
fan	on, auto and circulate	See table 2 for detail description.

Table 4. User Settings (Heat/Cool or Cool Only)

Setting Selection	Function	Description
heat / cool (gas or electric heating is selected)	normal	Heats home to desired temperature setting. Options are on or off .
	setpoint range	Heating limits with a default of 90°F. Range is 45°F to 90°F Cooling limits with a default of 45°F. Range is 45°F to 99°F
cool only (option only appears if no heating equipment is available or configured)	setpoint range	Cooling limits with a default of 45°F. Range is 45°F to 99°F

Table 5. User Settings (General)

Setting Selection	Function	Description
general - provides information about the thermostat and settings for screen lock, date & time and language.	about	Displays information concerning thermostat model number, serial number, hardware and software revisions.
	screen lock	Setting options are unlocked, partially, and locked. To set partially lock, create a three digit code. Partially lock restricts access to the menu. To set locked , create a three digit code. Lock restricts access to anything on the screen. <i>NOTE: Partially Lock and Locked is set for one instance only. Either would need to be set each time it is desired to partially locked or locked the screen. Master code is 864 in case user forget their custom code.</i>
	date & time	Settings for 24-hour clock (military), daylight savings, set time and date.
	language	Languages available are English, Spanish, Portuguese and French.

Table 6. User Settings (Display)

Setting Selection	Function	Description
<p>display - Allows the user to control some information that is displayed on the home screen.</p>	screen saver	<p>Options are enable and disable. Default is enabled. When enabled only the time and inside temperature is displayed on the screen. Touching the screen will restore all other details.</p> <p>The backlight setting is also on the same screen. Options are continuous on or energy save. Default is continuous on.</p>
	screen brightness	A horizontal adjustment bar is provided to move from minimum to maximum brightness.
	temperature scale	°F for Fahrenheit or C° for Celsius.
	clean screen	This will disable the touchscreen for 30 seconds.

INDEX

A

About, 17

Away, 6

B

Backlight, 18

C

Clean Screen, 18

Cool-To, 7

Critical Notifications, 12

D

Date and Time, 17

Display Settings, 18

E

Edit Schedules, 13

F

Fan Operation, 10

Features, 2

G

General Settings, 17

H

Heat-To, 7

Home Screen, 5

L

Language Selection, 17

M

Master Unlock Code, 17

Menu, 6, 11

N

Normal Setting, 16

Notifications, 11

O

Operating Modes, 6, 10

P

Performance Report, 13

S

Schedule Hold, 7

Schedules, 10

Screen Brightness, 18

Screen Lock, 17

Screen Saver, 18

Selection Mode, 9

setpoint range, 16

Settings, 15

System Status Icons, 8

T

Temperature Dial Indicator, 3

Temperature Override Setting, 7

Temperature Scale, 18

U

Unlock Code (master), 17

® U.S. Registered Trademark

Model: 13H13
507500-01
3/2015



©2015 Lennox Industries Inc.
Dallas, Texas, USA