



iComfort[®] S30 Smart Thermostat

Color Touchscreen Programmable
Wi-Fi Communicating Thermostat

(12U67)



CHEAT SHEET TOPICS AND TROUBLESHOOTING TIPS

ACC-15-03 September 22, 2015
Revised October 12, 2015

TABLE OF CONTENTS

1. Smart Hub	3
1.1. Installation	3
1.2. Antennas	3
1.3. Wire Connections	3
1.4. Troubleshooting	3
1.5. Electrical Voltages:	6
1.6. Networking Multiple Smart Hubs (Single Smart Hub Group) — Thermostat software release 3.00):	6
2. Mag-Mount	7
2.1. Mounting to 2x4 Electrical J-Box	7
2.2. Troubleshooting	8
3. HD Display	10
3.1. Wi-Fi	10
3.2. Ramp, Sag, and Power interruption	12
3.3. Electrical Discharge	12
3.4. Screen Locks Up or Goes Blank	12
4. Dealer Portal	13
4.1. Spoofing	13
4.2. Remote View and Control:	13
5. Creating Consumer Portal Account	13
5.1. Setting Up Account	13
5.2. Adding System to Consumer Account	14
6. Removing System from your Consumer Portal Account	14
Remove Home	14
Move Out	14
7. IComfort® Mobile Setup Application	15
7.1. Operating System Requirements	15
7.2. Commissioning	15
7.3. Connecting iComfort® Mobile Setup Application to Smart Hub using Smart-Hub Wi-Fi* (alternative method)	16
7.4. Service	17
7.5. Troubleshooting	18

1. Smart Hub

1.1. Installation

DO NOT install the Smart Hub on indoor unit, duct work or equipment that could induce vibration to the module. Mount Smart Hub on flat surface away from indoor unit to minimize vibration. Securing module to a wall stud is desirable. If mounted on metal surface other than above, antennas need to be perpendicular to the metal surface.

1.2. Antennas

Unfold both antennas to the vertical position. Adjustments may be required to optimized transmitting and receiving.

1.3. Wire Connections

1.3.1. Wire gauge and Maximum Run Length:

The Smart Hub connects to the indoor unit through common four-conductor thermostat wire. It receives 24VAC power from the indoor unit over two wires and communicates with the indoor unit and the rest of the HVAC system through two different wires. Wiring from the Smart Hub to the indoor unit should be limited to 300 feet or less (for 18 AWG wire).

1.3.2. Smart Hub to Mag-Mount Terminal Connections

Type	Smart Hub Terminal Labels	Mag-Mount Terminal Labels	Terminal Color	Function
RS-485	+	+	Yellow	Two wire serial RS-485 interface, 3.3V signaling up to 400 feet.
	-	-	Green	
24VAC Power	A	A	Blue	24VAC RS-bus power input
	B	B	Black	24VAC RS-bus common input

1.3.3. Smart Hub to Indoor Unit Terminal Connections

Type	Smart Hub Terminal Labels	Indoor Unit Terminal Labels	Terminal Color	Function
RS-BUS	l+	l+	Yellow	RS-bus high – data line 1 RS-bus high – data line 2
	i-	i-	Green	
24VAC Power	R	R	Red	24VAC RS-bus power input
	C	C	Black	24VAC RS-bus common input

1.4. Troubleshooting

1.4.1. LEDs

These LEDs have a red LED chip and a green LED chip in the package and can show red, green, or amber colors, steady or flashing.

NOTE: Smart Hub boot up time averages around 3 to 4 minutes.




Figure 1. Smart Hub Indicators and Connectors

1.4.2. General Rules

- Unlit indicators show there is no power to the Smart Hub or its software has suffered a critical initialization error.
- Steady amber indicators show Smart Hub boot up and self-check processes are in progress or have completed. Boot-up and self-checks normally complete rapidly, so amber indicators may appear only briefly (except for the Wi-Fi indicator).
- Flashing amber Wi-Fi indicator shows that the Wi-Fi module check is in progress. Steady amber Wi-Fi indicator shows that the Wi-Fi module has passed its check but is not connected to the home Wi-Fi network.
- Flashing green indicators show acquisition and test of resources across wired interfaces to the Mag-Mount / HD Display and to installed HVAC equipment
- Steady green indicators show that the associated function is connected and operating normally.
- Flashing red indicators shows a problem with the associated function.
- Flashing red ALERT indicator shows that a critical alert condition exists. If one of the other indicators is also flashing red, that is the likely source of the alert. If no other indicators are flashing red, the source of the alert is not defined.

1.4.3. Center Push Button Indicators

The center push button has a RGB (red-green-blue) LED backlight that indicates the Lennox-managed local network communication status of the Smart Hub, and if the Smart Hub is transferring a software image from a flash drive plugged into the USB port. While this LED indicator can show any color, it is currently limited to amber, green, or blue.

When the Smart Hub is in a **normal steady state** -- when the Smart Hub is in normal day-to-day operation -- the center push button backlight shows:

- Steady blue when there is only one Smart Hub in the home and it is not connected to a mobile device running a iComfort® S30 application.
- Steady blue when there is more than one Smart Hub in the home, but this Smart Hub is not connected to any other Smart Hub.
- Steady blue when the Smart Hub is connected to another Smart Hub in the home through a Lennox-managed local network.

During various Smart Hub **transient states** -- when the Smart Hub is engaged in a special task that should complete soon -- the center push button backlight shows:

- Steady amber (briefly) while the Smart Hub conducts self tests and boots up.
- Flashing amber while software or firmware updates for an iComfort® S30 system component or a connected field-upgradable HVAC asset is being transferred from files on a flash drive plugged into the Smart Hub USB port.
- Steady blue while the Smart Hub conducts checks on its internal Wi-Fi module and remote HVAC assets. (icon indicators show progress.)
- Flashing green when the Smart Hub is attempting a Lennox-managed local network connection with another Smart Hub in the home or with a mobile device running the iComfort® S30 service maintenance application.
- Steady green when the Smart Hub is connected to a mobile device running the iComfort® S30 service maintenance application through a Lennox-managed local network connection. (This is considered a transient state because the mobile device will disconnect from the Lennox-managed network when the task at hand is complete.)

1.4.4. Wi-Fi Connection

The following terminology is used in this troubleshooting section:

- **Router Signal Strength (RSSI)**. RSSI is an indication of the signal strength of the Wi-Fi router being received by the scanning device (i.e., smart phone). Therefore, the higher the RSSI number (or less negative in some devices), the stronger the signal.
- **802.11a, g and n** are wireless networking specification that extends throughput up to 130mbps using the 2.4 GHz band.
- **Internet Protocol Address (IP address)**. This is a numerical label assigned to each device (e.g., computer, printer, thermostat) participating in a computer network that uses the Internet Protocol for communication. An IP address serves two principal functions: host or network interface identification and location addressing.
- **Electromagnetic Interference Causing Poor Connectivity**

Locate both the thermostat and router away from other devices that could possibility interfere with wireless communications. Some examples of other devices that could interfere are:

- ✓ Microwave ovens
- ✓ Wireless cameras
- ✓ Portable phones and bases
- ✓ Baby monitors
- ✓ Wireless speakers
- ✓ Bluetooth devices
- ✓ Garage door openers
- ✓ Neighbor's wireless devices.

To eliminate a possible source of interference, temporally disable any devices and see if Wi-Fi performance has improved.

The Smart Hub may be relocated to a new location to obtain a stronger Wi-Fi signal connection to the home wireless router. The Smart Hub may be placed anywhere in the home as long as wiring can be run to it.

- **Router Signal Strength (RSSI)**

The ideal signal strength range for the iComfort® S30 is -1 to -69 RSSI. The signal strength can be viewed from the thermostat interface. Use steps 1

1. Press NETWORK SETTINGS; this screen shows a graphical view of buttons representing Wi-Fi options OPEN and SECURE wireless networks and a button for adding a network.
2. Select the access point that has already been established and connected to. When selecting the info icon, a screen will appear which will display an option to forget the network and IP address assigned to the iComfort® S30 by your router, sub-net mask, router, DNS and RSSI. The RSSI signal strength is anywhere between -1 to -69, then the signal strength is sufficient. If outside this range, then either locate the router closer to the thermostat or add a repeater.




Figure 2. Verifying Signal Strength

1.5. Electrical Voltages:

- **Smart Hub Power In:** 24VAC typical (18VAC to 30VAC range) at 1 Amp maximum from indoor unit.
- **Smart Hub Power Out:** 12 VDC (± 0.25 V) at 1 A maximum to Mag-Mount / HD Display
- **Communication with Mag-Mount/HD Display:** Two-wire serial RS-485 interface, 3.3-V signaling, up to 400 feet to Mag-Mount (18 AWG wire).

1.6. Networking Multiple Smart Hubs (Single Smart Hub Group) — Thermostat software release 3.00):

- If more than eight iComfort S30 Smart Thermostat HVAC are needed in a home, they can be segregated into groups, with each group containing eight or less Smart Hubs.
 - ✓ **Group 0** is for a stand-alone Smart Hub or there is not desired to connect to other Smart Hub on the local Wi-Fi network.
 - ✓ **Group 1 (default)** is for homes with up to eight Smart Hubs and HD Displays that will communicate with each other through the home wireless router. To change the Group ID, go to the **Dealer Control Center** and touch **equipment**. Under the **equipment list** touch **Smart Hub**. Scroll down to the end of the list on the right side of the screen until you reach **Group ID**. Change the **Group ID** to the desired number.
 - ✓ **Group 2 through 999** are for homes that require multiple Smart Hub groups consisting of up to eight Smart Hubs per group.
- Currently each individual Smart Hub group is completely isolated from other local Smart Hub groups even if they are all using the small home Wi-Fi router. HD Displays in one group can only control and access information within its own Smart Hub Group.
- Selecting the home Wi-Fi network and entering the password must be repeated for each Smart Hub.
- When a second Smart Hub within a single Smart Hub Group connects to the home Wi-Fi network, it will automatically connect to the first Smart Hub the home Wi-Fi network. This is true for any additional Smart Hubs added as well.

Limitations in software release 3.00):

From a single HD display, the following functions can not be controlled or viewed when interacting with other Smart Hub within the same Smart Hub group.

- Away Mode
- Weather
- Date and Time
- Notifications

Advantages:

The isolation between groups may be used to good advantage if there is some compelling reason that an HD Display in one part of the home should not be able to adjust the set point of a system elsewhere in the home. Assigning the systems to two different Smart Hub Groups would allow this. An example of this might be to isolate the system in the master suite or a guest bedroom from the HD Display in the children's area. The homeowner iComfort S30 mobile application is able to see and interact with all Smart Hubs installed in the home even if they are spread among several groups.

2. Mag-Mount

2.1. Mounting to 2x4 Electrical J-Box

2.1.1. Short Term Recommendation

Use Honeywell back plate from LPP store part # X5392.

2.1.2. Back plate - Long Term:

We will enlarge the existing back plate to cover 2"x 4" J box and replacement of larger stats with the iComfort S30

2.1.3. Wiring Connections

2.1.3.1. Wire gauge and Maximum Run Length: The Smart Hub connects to the indoor unit through common four-conductor thermostat wire. It receives 24VAC power from the indoor unit over two wires and communicates with the indoor unit and the rest of the HVAC system through two different wires. Wiring from the Smart Hub to the indoor unit should be limited to 300 feet or less (for 18 AWG wire).

2.1.3.2. Mag-Mount to Smart Hub

Type	Mag-Mount Terminal Labels	Smart Hub Terminal Labels	Terminal Color	Function
RS-485	+	+	Yellow	Two wire serial RS-485 interface, 3.3V signaling up to 400 feet.
	-	-	Green	
24VAC Power	A	A	Red	24VAC RS-bus power input
	B	B	Black	24VAC RS-bus common input

2.2. Troubleshooting

2.2.1. LED:

A blue LED, mounted on the internal circuit board indicates status.




Figure 3. Mag-Mount Blue LED

- **Steady** - Mag-Mount is receiving power from the Smart Hub but HD display is not attached.
- **Flashing** - Mag-Mount is receiving power from the Smart Hub but is experiencing some difficulty:
 - ✓ It is not communicating with the Smart Hub is the most common issue
 - ✓ There has been a software error in the Mag-Mount processor
 - ✓ There has been an internal hardware error in the Mag-Mount
- **Off** - Possible causes:
 - ✓ Mag-Mount is not receiving power from the Smart Hub. Check wiring at Mag-Mount and Smart Hub. A mis-wiring will not cause any damage but will prevent the system from operating.
 - ✓ There has been a serious Mag-Mount internal hardware or software failure which is a very remote cause.

2.2.2. Electrical Voltages

The Mag-Mount provides 5-VDC to the HD Display at up to 1.5 Amps. The 12VDC supply from the Smart Hub is reduced to 5VDC using a switching regulator on the PCB inside the Mag-Mount. A 6VDC TVS diode on the 5VDC output line will clamp the output voltage to a safe level if the regulator malfunctions and an over-voltage condition occurs. The Mag-Mount has the ability to monitor the 5-V current drawn by the HD Display. When the HD Display is not on the Mag-Mount, the 5VDC regulator is shut down, removing the 5VDC power from the HD Display connector.

2.2.3. Troubleshooting with Display Removed

Check for 12VDC on Mag-Mount terminals + and -.

2.2.4. HD Display Interface (Electrical) (Do not push on terminals)

- Ground
- 5-VDC
- RX
- TX
- Sense




Figure 4. Mag-Mount HD Display Contactors

3. HD Display

3.1. Wi-Fi

3.1.1. Router and Internet Connection:

This is for connecting the S30 Control System to the home wireless network. This settings is disabled by default.

- A. From the home screen, go to **menu > settings > wi-fi**
- B. Slide the option to **ON** to enable Wi-Fi.

If the Access Point is Visible

- A. Wi-Fi network will show not connected. Press on **not connected**.
- B. **Select a network** will be displayed listing all detected networks within range. Selected your home network by pressing on the network name. **DO NOT USE A GUEST OR UNSECURE ACCESS POINT.**
- C. Assuming that your network is secure, a password will be requested. Enter your password and press **join** to continue.


NOTE - If you wish to see the characters you are typing, check show password.

Access Point is Hidden

- A. Slide the option to **ON** to enable Wi-Fi.
- B. Wi-Fi network will show not connected. Press on **not connected**.
- C. Select **other**.
- D. The enter new network information screen will appear. Enter the name of the hidden network.
- E. **Select Security**. Options are none, WEP, WPA and WPA2. **DO NOT USE A GUEST OR UNSECURE ACCESS POINT.**
- F. Once security type is selected, a password field will appear. Enter the password and press **join** to continue..

NOTE - If you wish to see the characters you are typing, check show password.

Whether connecting to a visible or hidden network, if successful, the connection icon above both the router and Internet icon will have a green check mark above each.



3.1.2. Consumer Account Creation from Thermostat and Connection to Server

Reasons to create an account:

- To enable remote access to the system using a mobile device with the Lennox mobile application installed while away from home. This will allow remote adjustment for temperature settings and other features.
- To enable the Smart Away feature discussed later on in this instruction.

- To directly communicate to the Dealer any issues the system may be incurring.
- Go to **menu > settings > account**. This menu allows two options:

NOTE - If setting up new account you will need to first go to the home tab and enter all information there then to account and create account and enter all information there.

Using Existing Account


If an account has already been created.

- Use the **sign in** option to access your account.
- Enter your email address and password to connect your system to your online account or you can generate a pin number and then enter it in the consumer portal by add another system feature.

Creating a New Account

- Use this option to create an account. Enter your email and desired password to use. Select **create new account**.
- The new account screen will appear. Enter your first name, last name and phone number (phone number is option however if entered, **do not use dashes**, only numbers).
- Enter an email address and repeat to verify email address.
- Create a password under the set password location. Retype the password to verify.
- Check the box that will allow your dealer to receive service alerts and possibility fix your issue remotely (recommended).
- Check that you agreed to the Lennox EULA. Press on LENNOX EULA to read the end-user license agreement.

If the setup and connection to the Lennox server is successful, a green check mark will appear above the service icon under the **wi-fi** menu option.



3.1.3. Adding Additional Thermostat to your Consumer Account

This information should have already been completed by the installer. However, selecting this option will allow the home information to be verify and corrected if necessary. If the home information is missing then enter the information now. This information is required to registered the system when creating an account. If there are multiple thermostats in the home, each thermostat home address will be the same except for the home name (for example, Home Upstairs or Home Downstairs). This way multiple thermostats can be added to the customer account with a single login.

3.1.4. Seeing Other Thermostats

Seeing **two** or more thermostats on one thermostat is automatic once they are all connected to the home router for 3.0 and for 3.01 if no router is available then they can all talk by pushing the center button on the first Smart Hub and twice on the second Smart Hub. Once connection between Smart Hubs are established the center ring on the Smart Hub will be blue.

3.2. Ramp, Sag, and Power interruption

Display (thermostat) will indicate error “unable to communicate with Smart Hub”. This pop-up will be displayed for three minutes which will cause the watchdog to reset the display after three minutes.

- All will recover fine after the reset.
- This whole process will take between 5 – 6 minutes.
- During this test and sometimes also noticeable when manually un-powering and powering the Smart Hub during test setups, dashes appear on the display instead of the ambient temperature reading. The dashes will remain on the display for approximately two minutes. After the wait period has ended the display will recover fully.


3.3. Electrical Discharge

Display will indicate error “unable to communicate with Smart Hub”. This pop up will be on the display for 3 minutes which will cause the watchdog to reset the Display after three minutes. All will recover fine after the reset. This whole process took between 5 – 6 minutes.

3.4. Screen Locks Up or Goes Blank

If the HD Display screen freezes or goes blank then perform a reset. Reset the display by pressing the **RESET** button and holding it for 5-6 seconds or until screen goes blank if screen is on. The reset button is located at the top left hand back side of the display. It is a very small button and is flush with the case.


NOTE: The reset button only reboots the HD Display. This action alone does not change any settings previously configured for the system.



4. Dealer Portal

4.1. Spoofing

Dealer: Using your DaveNet dealer account, go to the iComfort tab and view all of your iComfort Wi-Fi & S30 customers. Select the iComfort S30 customer whose account you are wanting access too and select it. The customer's account will open and you will be able to see their system alerts and a tab for their equipment and if they have given remote in permission you will see remote in button under the S30 home screen. This remote in function gives you the ability to make changes and do test from the Dealer Control Center in the S30.



FTC: Using your login information and accessing iComfort you can spoof the dealers account by putting in the dealer number. Using the dealer spoofing account number will allow you access to all customers assigned to that dealer. You will be able to view and remote into a customer's account just like the dealer can if the homeowner has given permission to do so.

4.2. Remote View and Control:

Dealer will only be able to remote view or control dealer control center section and configurable parameters only if Dealer Remote View and Control has been enabled at the homeowner system.

- A. Go to **menu > system > general > dealer info**
- B. Select **dealer access**.
- C. Enable **Remote View** by toggling to **ON**.
- D. Enable **Remote Control** by selecting **ON**.

5. Creating Consumer Portal Account

This procedure allows the creation of a consumer account using the customer portal instead of at the thermostat.

5.1. Setting Up Account

- A. Go to the consumer portal website.
- B. Select **sign up**.
- C. Enter all required account info, login, password and enable or disable email updates. For security purposes type the code that is displayed in the provided box.

- D. Check the if you agree to the **Lennox EULA**.
- E. Select **sign up**. A pop-up will appear indicating **you have successfully created your account**. Select **OK** to continue.
- F. Creation of account is completed.

5.2. Adding System to Consumer Account

- A. Login into the consumer portal.
- B. From **my homes** screen, select the **email address** located in the upper right hand corner of the screen.
- C. An option to add **icomfort** is available. Select **icomfort** and enter the **pin number** for the applicable system located in the home. A pin number can be created from the HD Display. From the home screen, go to **menu > settings > account** and select generate pin number.
- D. Enter the **pin number** and press **add**.
- E. Complete the information under the add icomfort screen (home name, country, address, city, state and zip code. Once completed, press **done** to continue.

***NOTE** - If there are multiple systems in the home, then the home name must be unique for each system added to the consumer portal account.*

- F. Your system should appear momentary on the consumer portal screen.

6. Removing System from your Consumer Portal Account

A system can be removed using either the Consumer Portal or directly from the HD Display. There are two methods that are available to remove the system, either **remove home** or **move out**:

***NOTE** - If you have given your dealer **remote in** access, they will no longer be able to remotely access your system.*

Remove Home

- A. Go to the consumer portal website or to the HD display that controls the system to be removed.
- B. Go to **menu > settings > home info** and select **remove home**.
- C. A critical warning notification will appears confirming the action, press **yes** to remove the home (system).

Move Out

In firmware version 3.0, this feature works exactly like the remove home selection.

***NOTE** - If you have given your dealer **remote in** access, they will no longer be able to remotely access your system.*

- A. Go to the consumer portal website or to the HD display that controls the system to be removed.
- B. Go to **menu > settings > account** and select **move out**.
- C. A critical warning notification will appears confirming the action, press **yes** to remove the home (system).

7. IComfort® Mobile Setup Application

7.1. Operating System Requirements

Dealer commissioning application (iComfort® Mobile Setup) is available for both IOS 6.0 and higher (App Store) and Android 4.1 and higher (Google Play).


7.2. Commissioning

To commission a system using the iComfort® Mobile Setup Application perform the following:

NOTE - It is recommend that when using the iComfort® Mobile Setup application to commission the system, remove the HD Display from the Mag-Mount before starting. Once commissioning is completed, reattached the HD Display to the Mag-Mount.

- A. Download and install the iComfort® Mobile Setup Application.
- B. Go to the Smart Hub and press the center Lennox button once.
- C. The center ring LED will start blinking green for two minutes. During that time the Smart Hub will broadcast its Wi-Fi identifier (SSID).
- D. Go to your mobile device's Wi-Fi connection tool and locate the Smart Hub Wi-Fi broadcast identifier. The identifier (SSID) is **Direct E300-5200** for example.
NOTE - Refer to your mobile device's owners manual on how to use your Wi-Fi Connection tool.
- E. To connect to the Smart Hub use the last eight digits of the Smart Hub SSID as the password (example E3005200).
- F. Once connected to the mobile device the Smart Hub center ring LED turns solid green.
- G. Start the iComfort Mobile Setup Application and make sure you connect to the correct Smart hub by checking the serial number
NOTE - The serial number check is only needed if multiple Smart Hubs are shown. For example if you have three systems and have completed commissioning of two and while on third unit, the other two Smart hubs connection data is still listed in the iComfort Mobile Setup Application. If you chose the wrong one it will not connect because it would have already stopped broadcasting its connection signal.
- H. Press the **remote in** tab on the iComfort® Mobile Setup Application home screen. This will take you to the commissioning screen.
NOTE - If the system has not been commissioned it will go to commissioning screen. If the system has already been commissioned it will go to dealer control center.
- I. Once the commissioning is completed, exit the iComfort® Mobile Setup Application.
- J. Go to the mobile device's Wi-Fi tool and manually disconnect from the Smart Hub. Or if there is no activity after three minutes the application will automatically disconnect from the Smart Hub.
- K. Once disconnected the Smart Hub LED will return to a solid blue.


- L. Once you are done commissioning the system using the Mobile Dealer Application, go to the HD Display and press the **reset** button. This will allow the commissioning information stored in the Smart Hub to be downloaded to the HD Display.



NOTE - If the connection between the iComfort Mobile Setup Application and Smart Hub is idle for 15 minutes, the Smart Hub will auto-disconnect from the mobile device. Repeat procedures to reconnect.

7.3. Connecting iComfort Mobile Setup Application to Smart Hub using Smart-Hub Wi-Fi* (alternative method)

From the home screen, go to **menu > settings > advanced settings > pair Smart Hub to iComfort dealer commissioning app** selection. It will auto connect to iComfort Mobile Setup Application and start you at the dealer control center screen. The following screen will appear and show the status of the connection. Once connected the screen will automatically disappear.



7.4. Service

To use Lennox iComfort® Mobile Setup Application as a service tool the commissioning of the system must have already been completed.

- A. Download and install the iComfort® Mobile Setup Application if not already installed.
- B. Go to the Smart Hub and press the center Lennox button once.
- C. The center ring LED will start blinking green for two minutes. During that time the Smart Hub will broadcast its Wi-Fi identifier (SSID).
- D. If this is the first time connecting to the target Smart Hub then go to your mobile device's Wi-Fi connection tool and locate the Smart Hub Wi-Fi broadcast identifier. The identifier (SSID) is **Direct E300-5200** for example. If your mobile device had already connected previously to the target Smart Hub, then select the applicable Smart Hub SSID on the list and skip to step F.

NOTE - Refer to your mobile device's owners manual on how to use your Wi-Fi Connection tool.

- E. To connect to the Smart Hub use the last eight digits of the Smart Hub SSID as the password (E3005200).
- F. Once connected to the mobile device the Smart Hub center ring LED turns solid green.
- G. Start the iComfort® Mobile Setup Application and make sure you connected to the correct Smart hub by checking the serial number and pushing on the displayed Smart Hub.
- H. Press the **remote in** tab on the iComfort® Mobile Setup Application home screen. This will take you to the dealer control center.
- I. Once servicing is completed, exit the iComfort® Mobile Setup Application.
- J. Go to the mobile device's Wi-Fi tool and manually disconnect from the Smart Hub.
- K. Once disconnected or after three minutes of inactivity the Smart Hub LED turns to a solid blue.

NOTE - If the connection between the iComfort® Mobile Setup Application and Smart Hub is idle for 15 minutes, the Smart Hub will auto-disconnect from the mobile device. Repeat entire procedure to reconnect.

7.5. Troubleshooting

Issue: Your mobile device (smart phone or tablet) will not connect to the Smart Hub using the procedures in the installation and setup guide. Then try the following possible solution.

Solution: Disable mobile data on your device if applicable.

- **Android 4.4** - Go to Settings > Wireless & Networks > More > Mobile Networks > Data Enabled and un-check this option
- **Android 5.x** - Go to Settings > Connections > More Networks > Mobile Networks > Mobile Data and unchecked this option.
- **IOS** - To turn off cellular data, tap Settings > Cellular on your iPhone or Settings > Cellular Data on your iPad. Disable **Cellular Data** and **Data Roaming**.



- Note: When mobile (cellular) data is successfully disabled, icons for 2G, 3G or 4G will not longer be present on the main screen.

Try to connect to Smart Hub. Reports indicate that disabling mobile data will reduce the interference that may be causing the connection issue.

REMINDER: Do not forget to turn your mobile data setting back on when you are finished with the Lennox Mobile Setup application.