



THIS MANUAL MUST BE LEFT WITH THE BUILDING OWNER FOR FUTURE REFERENCE

⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional HVAC installer or equivalent, or service agency.

⚠ IMPORTANT

The Clean Air Act of 1990 bans the intentional venting of refrigerant (CFCs, HCFCs and HFCs) as of July 1, 1992. Approved methods of recovery, recycling or reclaiming must be followed. Fines and/or incarceration may be levied for noncompliance.

⚠ CAUTION

As with any mechanical equipment, contact with sharp sheet metal edges can result in personal injury. Take care while handling this equipment and wear gloves and protective clothing.

INSTALLATION INSTRUCTIONS

Elite® ELP Series 7.5 and 10 Ton

HEAT PUMPS
7.5 AND 10 TONS
507744-02
7/2019

Table of Contents

Shipping and Packing List	1
Outdoor Unit	1
Unit Dimensions, Corner Weights and Centers of Gravity ..	2
Unit Plumbing Parts Arrangement	3
Model Number Identification	4
Unit Control Box Components Arrangement	4
Rigging the Unit for Lifting	4
Installation Clearances	5
Line Set	5
Electrical Connections	5
Refrigerant Charge	9
System Operation	12
Defrost System	12
Defrost Control Board	12
Maintenance	13

Shipping and Packing List

Check the unit for shipping damage. If damaged or parts are missing, immediately contact the last shipping carrier.

- 1 - Assembled outdoor unit
- 1 - Installation instructions


Outdoor Unit

ELP Series heat pumps, which will also be referred to in this instruction as the outdoor unit, use HFC-410A refrigerant. This outdoor unit must be installed with a matching indoor unit and line set as outlined in the EL Series Engineering Handbook.


This outdoor unit is designed for use in thermal expansion valve (TXV) systems only.

Unit Dimensions, Corner Weights and Centers of Gravity


Model No.	CORNER WEIGHTS								CENTER OF GRAVITY			
	AA		BB		CC		DD		EE		FF	
	lbs.	kg	lbs.	kg	lbs.	kg	lbs.	kg	in.	mm	in.	mm
ELP090S4S	108	49	108	49	114	52	114	52	21-3/4	552	29	737
ELP120S4S	120	54	114	52	139	63	149	68	20	508	25-1/4	641




REFRIGERANT LINE CONNECTIONS DETAIL



TOP VIEW




FRONT VIEW




SIDE VIEW

Unit Plumbing Parts Arrangement


ELP090S4S



ELP120S4S




Model Number Identification



Unit Control Box Components Arrangement

ELP090S4S AND ELP120S4S



Rigging the Unit for Lifting

Rig the unit for lifting by attaching four cables to the holes in the base rail of the unit. See figure 1.

- 1 - Remove protective packaging before rigging the unit for lifting.
- 2 - Connect the rigging to the holes in each corner of the unit's base.

- 3 - All panels must be in place for rigging.
- 4 - Place a field-provided H-style frame just above the top edge of the unit. The frame must be of adequate strength and length. (An H-style frame will prevent the top of the unit from being damaged.)





FIGURE 1. ELP090S4S and ELP120S4S

Installation Clearances

See Unit Dimensions on page 2 for sizing mounting slab, platforms or supports. Refer to figures 4 through 6 for mandatory installation clearance requirements.

NOTES:

- Clearance to one of the remaining two sides may be 12 in. (305 mm) and the final side may be 6 in. (152 mm).
- A clearance of 24 in. (610 mm) must be maintained between two units.
- 48 in. (1219 mm) clearance required on top of unit.



**FIGURE 2. ELP090S4S and ELP120S4S
Installation Clearances**

Line Set

Field refrigerant piping consists of liquid and suction lines connecting the condensing unit and the indoor unit. Liquid and suction service valves are located in a compartment at the corner of the unit below the control box.

Piping can be routed directly from the service valves or field supplied elbows can be added to divert the piping as required.

Refer to table 1 for field-fabricated refrigerant line sizes for runs up to 50 linear feet (15 m).

**TABLE 1. Refrigerant Line Sizes for Runs
Up to 50 Linear Feet**

Unit	Liquid Line	Suction Line
ELP090	5/8" (16mm)	1-1/8" (29mm)
ELP120	5/8" (16mm)	1-1/8" (29mm)

Refrigerant Line Limitations

You may install the unit in applications that have line set lengths of up to 50 linear feet (15 m) with refrigerant line sizes as outlined in table 1 (excluding equivalent length of fittings). Size refrigerant lines greater than 50 linear feet (15m or greater) according to the Lennox Refrigerant Piping Design and Fabrication Guidelines (Corp. 9351-L9) or latest version.

Electrical Connections

⚠ WARNING



Electric Shock Hazard. Can cause injury or death. Unit must be properly grounded in accordance with national and local codes.


Line voltage is present at all components when unit is not in operation on units with single-pole contactors. Disconnect all remote electric power supplies before opening access panel. Unit may have multiple power supplies.

In the United States, wiring must conform with current local codes and the current National Electric Code (NEC). In Canada, wiring must conform with current local codes and the current Canadian Electrical Code (CEC).

TRANSFORMER – 24VAC, 70VA – PROVIDED

NOTE – The addition of accessories to the system could exceed the 70VA power requirement of the factory-provided transformer. Measure the system's current and voltage after installation is complete to determine transformer loading. If loading exceeds the factory-provided transformer capacity, a larger field-provided transformer will need to be installed in the system.


1 CIRCUIT SIZING AND DISCONNECT SWITCH




Refer to the unit nameplate for minimum circuit ampacity, amperage minimum, and maximum fuse or circuit breaker fusible (HACR per NEC). Install power wiring and properly sized disconnect switch.

NOTE — UNITS ARE APPROVED FOR USE ONLY WITH COPPER CONDUCTORS. GROUND UNIT AT DISCONNECT SWITCH OR TO AN EARTH GROUND.

2 TYPICAL HIGH VOLTAGE POWER SUPPLY CONNECTIONS




3 INSTALL THERMOSTAT




Install room thermostat (ordered separately) on an inside wall approximately in the center of the conditioned area and 5 feet (1.5m) from the floor. It should not be installed on an outside wall or where it can be affected by sunlight, drafts or vibrations.

4 TYPICAL CONTROL WIRING



5 TYPICAL UNIT CONTROL WIRE CONNECTIONS



WIRE RUN LENGTH	AWG#	INSULATION TYPE
LESS THAN 100' (30M)	18	TEMPERATURE RATING
MORE THAN 100' (30M)	16	35°C MINIMUM

- A RUN CONTROL WIRES THROUGH RIGHT CUTOUT.
- B RUN CONTROL WIRES THROUGH WIRE TIES.
- C MAKE CONTROL WIRE CONNECTIONS USING FIELD PROVIDED WIRE NUTS. SEE FIGURE 3 FOR CONNECTION REQUIREMENTS.
- D TIGHTEN WIRE TIE TO SECURE 24VDC CONTROL WIRING.

NOTE - FOR PROPER VOLTAGES, SELECT THERMOSTAT WIRE (CONTROL WIRING) GAUGE PER TABLE ABOVE.

NOTE - WIRE TIE PROVIDES LOW VOLTAGE WIRE STRAIN RELIEF AND MAINTAINS SEPARATION OF FIELD INSTALLED LOW AND HIGH VOLTAGE CIRCUITS.

NOTE - DO NOT BUNDLE ANY EXCESS 24VAC CONTROL WIRES INSIDE CONTROL BOX.

Two Stage Compressor Solenoid (L34) Resistance Check

Resistance check: Measure the resistance from the end of one molded plug lead to either of the two female connectors in the plug. One of the connectors should read close to zero ohms while the other should read infinity.

Repeat with other wire. The same female connector as before should read zero, while the other connector again reads infinity. Reverse polarity on the ohmmeter leads and repeat. The female connector that read infinity previously should now read close to zero ohms.

Replace plug if either of these test methods don't show the desired results.




FIGURE 3. Typical Wiring Diagram – ELP090S4S and ELP120S4S (G, J, Y, M Voltages)

Refrigerant Charge

ELP units have a factory holding charge of 2 pounds of HFC-410A. Additional refrigerant will need to be added during installation (table 2).

TABLE 2. Adding Refrigerant

Models	Total lbs – Stage 1 with 25 ft line set	Liquid line diameter (inches)	Ounces adjustment per ft of liquid line	Suction line diameter (inches)	Ounces adjustment per ft of suction line
ELP090S4S	23.25	5/8	1.5	1-1/8	0.2
ELP120S4S	32.5	5/8	1.5	1-1/8	0.2

To charge the system, use the following procedure:

- 1 - Measure actual length of liquid and vapor lines for each circuit.
- 2 - Add refrigerant to each circuit based on measured liquid and suction line lengths.
 - A - If the measured line length is greater than 25 feet, add refrigerant (refer to table 2).
 - B - If the measured line length is less than 25 feet, remove refrigerant (refer to table 2).
- 3 - Check normal operating pressures:
 - A - Connect a manifold gauge set to the service valves:
 - Low pressure gauge to vapor valve service port
 - High pressure gauge to liquid valve service port
 - B - Operate the system until pressures and temperatures stabilize (5 minutes minimum).
 - C - Use a thermometer to measure the outdoor ambient temperature.
 - D - If the outdoor temperature is greater than 65°F (18°C):
 - Apply the outdoor ambient temperature to tables 4 or 5 to determine normal operating pressures. Compare the normal operating pressures to the pressures obtained from the connected gauges. If liquid pressure is high, remove refrigerant from the system. If liquid pressure is low, add refrigerant to the system.
 - Add or remove charge in increments.
 - Allow the system to stabilize at least 5 minutes each time refrigerant is added or removed.
 - Minor variations in these pressures may be expected due to differences in installations. Significant differences could mean that the system is not properly charged or that a problem exists with some component in the system.
- 4 - If the outdoor ambient temperature is below 65°F (18°C) it may be necessary to restrict the air flow through the outdoor coil to achieve liquid pressures in the 325-375 psig (2240-2585 kPa) range. These higher pressures are necessary for checking the charge. Block equal sections of the outdoor coil on all coil sides until the liquid pressure is in the 325-375 psig range (figure 10).




FIGURE 4. Blocking Outdoor Coil

A - Charge the unit using the approach method in the next section:

- Using the same thermometer, compare liquid temperature at service valve to outdoor ambient temperature.

Approach Temperature = Liquid temperature minus ambient temperature

- Approach temperature should be as indicated in tables 3 or 6 for each stage. An approach temperature greater than this value indicates an undercharge. An approach temperature less than this value indicates an overcharge.
- Add or remove charge in increments.
- Allow system to stabilize at least 5 minutes each time refrigerant is added or removed.
- Do not use the approach method if system pressures do not match pressures in table 4, 5, or 7 except when the outdoor ambient temperature is below 65°F (18°C).
- The approach method is not valid for grossly over or undercharged systems.

TABLE 3. HFC-410A Approach Temperatures*

Models	Approach Temperature (°F) (+/-1)	Approach Temperature (°C) (+/-0.05)
ELP090S4S / ELA090	7.0	3.9
ELP120S4S / ELA120	6.0	3.3

*Approach temperature method valid at full load.

TABLE 4. HFC-410A Normal Operating Pressures – Cooling Mode (Liquid ±10 and Suction ±5 psig)*

Outdoor Air Temp	ELP090 / ELA090		ELP120 / ELA120		(2) ELP090 + ELA240			
	Liquid	Suction	Liquid	Suction	Stg 1 Liquid	Stg 1 Suction	Stg 2 Liquid	Stg 2 Suction
65° F (18° C)	226	119	247	132	221	137	223	134
75° F (24° C)	261	125	291	136	260	140	261	136
85° F (29° C)	303	129	333	138	304	142	305	138
95° F (35° C)	349	133	370	140	354	145	357	141
105° F (41° C)	404	135	437	142	403	147	406	143
115° F (46° C)	462	137	495	144	462	150	469	146
125° F (52° C)	525	136	562	146	526	152	538	150
SCFM	2760		4000		6125			

*pressures at 80°F dry bulb and 67°F wet bulb.

TABLE 5. HFC-410A Normal Operating Pressures – Heating Mode (Liquid ±10 and Suction ±5 psig)*

Outdoor Air Temp	ELP090 / ELA090		ELP120 / ELA120		(2) ELP090 + ELA240			
	Liquid	Suction	Liquid	Suction	Stg 1 Liquid	Stg 1 Suction	Stg 2 Liquid	Stg 2 Suction
60° F (15° C)	364	121	335	115	370	119	370	119
50° F (10° C)	343	100	322	101	350	100	350	100
40° F (4° C)	324	83	308	86	338	82	338	82
30° F (-1° C)	311	72	294	72	322	64	322	64
20° F (-6° C)	297	57	280	58	311	50	311	50
10° F (-12° C)	280	44	266	44	299	37	299	37
SCFM	2760		4000		6125			

*pressures at 70°F dry bulb entering indoor air temperature.

TABLE 6. HFC-410A Temperature (°F) – Pressure (Psig)

°F	Psig	°F	Psig	°F	Psig	°F	Psig	°F	Psig	°F	Psig	°F	Psig	°F	Psig
32	100.8	48	137.1	63	178.5	79	231.6	94	290.8	110	365.0	125	445.9	141	545.6
33	102.9	49	139.6	64	181.6	80	235.3	95	295.1	111	370.0	126	451.8	142	552.3
34	105.0	50	142.2	65	184.3	81	239.0	96	299.4	112	375.1	127	457.6	143	559.1
35	107.1	51	144.8	66	187.7	82	242.7	97	303.8	113	380.2	128	463.5	144	565.9
36	109.2	52	147.4	67	190.9	83	246.5	98	308.2	114	385.4	129	469.5	145	572.8
37	111.4	53	150.1	68	194.1	84	250.3	99	312.7	115	390.7	130	475.6	146	579.8
38	113.6	54	152.8	69	197.3	85	254.1	100	317.2	116	396.0	131	481.6	147	586.8
39	115.8	55	155.5	70	200.6	86	258.0	101	321.8	117	401.3	132	487.8	148	593.8
40	118.0	56	158.2	71	203.9	87	262.0	102	326.4	118	406.7	133	494.0	149	601.0
41	120.3	57	161.0	72	207.2	88	266.0	103	331.0	119	412.2	134	500.2	150	608.1
42	122.6	58	163.9	73	210.6	89	270.0	104	335.7	120	417.7	135	506.5	151	615.4
43	125.0	59	166.7	74	214.0	90	274.1	105	340.5	121	423.2	136	512.9	152	622.7
44	127.3	60	169.6	75	217.4	91	278.2	106	345.3	122	428.8	137	519.3	153	630.1
45	129.7	61	172.6	76	220.9	92	282.3	107	350.1	123	434.5	138	525.8	154	637.5
46	132.2	62	175.4	77	224.4	93	286.5	108	355.0	124	440.2	139	532.4	155	645.0
47	134.6			78	228.0			109	360.0			140	539.0		

System Operation

The outdoor unit and indoor blower cycle on demand from the room thermostat. When the thermostat blower switch is in the ON position, the indoor blower operates continuously.

HIGH PRESSURE SWITCHES (S4 AND S7)

These units are equipped with an auto-reset high pressure switch (single-pole, single-throw) which is located on the discharge line. The switch shuts off the compressor when discharge pressure rises above the factory setting. High Pressure (auto reset) – trip at 640 psig; reset at 512 psig.

LOW PRESSURE SWITCH (S87)

These units are equipped with a loss-of-charge switch that is located in the liquid line. The switch is a SPST, auto-reset switch that is normally closed. The switch opens at 40 psi and closes at 90 psi.

Defrost System

The defrost system includes a defrost thermostat and a defrost control.

DEFROST THERMOSTAT

The defrost thermostat is located on the liquid line between the check/expansion valve and the distributor on each coil. When the defrost thermostat senses 42°F (5.5°C) or cooler, its contacts close and send a signal to the defrost control board to start the defrost timing. It also terminates defrost when the liquid line warms up to 70°F (21°C).

DEFROST CONTROL

The defrost control board includes the combined functions of a time/temperature defrost control, defrost relay, time delay, diagnostic LEDs, and a terminal strip for field wiring connections.

The control provides automatic switching from normal heating operation to defrost mode and back. During compressor cycle (defrost thermostat is closed, calling for defrost), the control accumulates compressor run times at 30, 60, or 90 minute field adjustable intervals. If the defrost thermostat is closed when the selected compressor run time interval ends, the defrost relay is energized and defrost begins.

Each timing pin selection provides a different accumulated compressor run time period for one defrost cycle. This time period must occur before a defrost cycle is initiated. The defrost interval can be adjusted to 30 (T1), 60 (T2), or 90 (T3) minutes. The maximum defrost period is 14 minutes and cannot be adjusted.

NOTE — Defrost control part number is listed near the P1 timing pins.

- Units with defrost control **100269-02**: The factory default defrost interval is 60 minutes.
- Units with defrost control **100269-04 or higher**: The factory default defrost interval is 90 minutes.

If the timing selector jumper is missing, the defrost control defaults to a 90-minute defrost interval.

Defrost Control Board

DEFROST CONTROL TIMING PINS




FIGURE 5. Outdoor Unit Defrost Control Board

A TEST option is provided for troubleshooting. The TEST mode may be started any time the unit is operating in the heating mode and the defrost thermostat is closed or jumpered. If the jumper is in the TEST position at power-up, the control will ignore the test pins. When the jumper is placed across the TEST pins for two seconds, the control will enter the defrost mode. If the jumper is removed before an additional 5-second period has elapsed (7 seconds total), the unit will remain in defrost mode until the defrost thermostat opens or 14 minutes have passed. If the jumper is not removed until after the additional 5-second period has elapsed, the defrost will terminate and the test option will not function again until the jumper is removed and re-applied.

COMPRESSOR DELAY

The defrost board has a field-selectable function to reduce occasional sounds that may occur while the unit is cycling in and out of the defrost mode. When the compressor delay jumper is removed, the compressor will be cycled off for 30 seconds going in and out of the defrost mode.

NOTE — The 30-second compressor feature is ignored when the TEST pins have been jumpered.

TIME DELAY

The timed-off delay is five minutes long. The delay helps protect the compressor from short-cycling in case the power to the unit is interrupted or a pressure switch opens. The delay is bypassed by placing the timer select jumper across the TEST pins for 0.5 seconds.

NOTE — The board must have a thermostat demand for the bypass function.

PRESSURE SWITCH CIRCUITS

The defrost control includes two pressure switch circuits. The factory-installed high pressure switch (S4) wires are connected to the board's HI PS terminals (figure 5). The board also includes LO PS terminals to accommodate the factory installed loss-of-charge switch.

During a single thermostat cycle, the defrost control will lock out the unit after the fifth time that the circuit is interrupted by any pressure switch that is wired to the control board. In addition, the diagnostic LEDs will indicate a pressure switch lockout after the fifth occurrence of an open pressure switch (table 7). The unit will remain locked out until power is broken then remade to the control or until the jumper is applied to the TEST pins for 0.5 seconds.

NOTE – The defrost control board ignores input from the loss-of-charge switch terminals during the TEST mode, during the defrost cycle, during the 90-second start-up period, and for the first 90 seconds each time the reversing valve switches heat/cool modes. ***If the TEST pins are jumpered and the 5-minute delay is being bypassed, the LO PS terminal signal is not ignored during the 90-second start-up period.***

SERVICE LIGHT CONNECTION

The defrost control board includes terminal connections for a service light which provides a signal that activates the room thermostat service light during periods of inefficient operation.

IMPORTANT

After testing has been completed, properly reposition test jumper across desired timing pins.

DIAGNOSTIC LEDs

The defrost board uses two LEDs for diagnostics. The LEDs flash a specific sequence according to the diagnosis (table 7).

TABLE 7. Defrost Control Board Diagnostic LEDs

DS2 Green	DS1 Red	Condition
OFF	OFF	Power problem
Simultaneous Slow Flash		Normal operation
Alternating Slow Flash		5-min. anti-short cycle delay
Fault and Lockout Codes		
OFF	Slow Flash	Loss-of-Charge Fault
OFF	ON	Loss-of-Charge Lockout
Slow Flash	OFF	High Pressure Fault
ON	OFF	High Pressure Lockout

Maintenance

At the beginning of each cooling season, the system should be checked as follows:

OUTDOOR UNIT

- 1 - Clean and inspect the condenser coil. You can flush the coil with a water hose.
- 2 - The outdoor fan motor is prelubricated and sealed. No further lubrication is necessary.
- 3 - Visually inspect connecting lines and coils for evidence of oil leaks.
- 4 - Check wiring for loose connections.
- 5 - Check for correct voltage at the unit while the unit is operating and while it is off.
- 6 - Check amp-draw of the outdoor fan motor.
Unit nameplate _____ **Actual** _____
- 7 - Check amp-draw of the compressor.
Unit nameplate _____ **Actual** _____

NOTE — If the owner complains of insufficient cooling, gauge the unit and check the refrigerant charge. Refer to section on refrigerant charging in this instruction.

INDOOR COIL

- 1 - If necessary, clean the coil.
- 2 - Check connecting lines and coils for evidence of oil leaks.
- 3 - If necessary, check the condensate line and clean it.

INDOOR UNIT

- 1 - Clean or change filters.
- 2 - Adjust the blower speed for cooling. Measure the pressure drop over the coil to determine the correct blower CFM. Refer to the unit information service manual for pressure drop tables and procedure.
- 3 - On belt drive blowers, check the belt for wear and proper tension.
- 4 - Check all wiring for loose connections.
- 5 - Check for correct voltage at the unit (blower operating).
- 6 - Check amp-draw on blower motor.
Unit nameplate _____ **Actual** _____

Start-Up and Performance Checklist

Job Name _____	Job no. _____	Date _____
Job Location _____	City _____	State _____
Installer _____	City _____	State _____
Unit Model No. _____	Serial No. _____	Service Technician _____
Nameplate Voltage _____		
Rated Load Ampacity _____ Compressor Amperage: _____		
Maximum Fuse or Circuit Breaker _____		
Electrical Connections Tight? <input type="checkbox"/>	Indoor Filter clean? <input type="checkbox"/>	Supply Voltage (Unit Off) _____
Indoor Blower RPM _____	S.P. Drop Over Indoor (Dry) _____	Outdoor Coil Entering Air Temp. _____
Vapor Pressure; _____		
Refrigerant Lines: - Leak Checked? <input type="checkbox"/> Properly Insulated? <input type="checkbox"/> Outdoor Fan Checked? <input type="checkbox"/>		
Service Valves: --- Fully Opened? <input type="checkbox"/> Caps Tight? <input type="checkbox"/> Voltage With Compressor Operating _____		
SEQUENCE OF OPERATION		THERMOSTAT
Heating Correct? <input type="checkbox"/>	Cooling Correct? <input type="checkbox"/>	Calibrated? <input type="checkbox"/> Properly Set? <input type="checkbox"/> Level? <input type="checkbox"/>