

**XC21 SERIES UNITS (iComfort®-ENABLED)**



**NOTICE**

A thermostat is not included and must be ordered separately.

- A Lennox communicating thermostat must be used in communicating applications.
- In non-communicating applications, the Lennox ComfortSense® 7500 thermostat may be used, as well as other non-communicating thermostats.

In all cases, setup is critical to ensure proper system operation.

Field wiring examples for non-communicating applications begin on page 68.

See the thermostat **Quick Start Guide** for communicating and partial communicating field wiring connections.

**⚠ WARNING**

Improper installation, adjustment, alteration, service or maintenance can cause personal injury, loss of life, or damage to property.

Installation and service must be performed by a licensed professional installer (or equivalent) or a service agency.

This document provides information only on **build XC21-XXX-230-04** and **later** which features the new air conditioner control hardware and other enhancements. Refer to **Corp. 0504-L2** for earlier model version service related information.

**TABLE OF CONTENTS**

**I. OVERVIEW**

Model Number Identification .....	2
Typical Serial Number Identification .....	2
Specifications .....	2
Electrical Data .....	3
Unit Dimensions .....	4
Unit Parts Arrangement .....	5
General .....	6
Operating Gauge Set and Service Valves .....	6

**II. SYSTEM OPERATION AND SERVICE**

Jumpers, Loop and Terminals (101798-XX) .....	12
System Status, Fault and Lockout LED Codes .....	14
Component Field Configuration and Troubleshooting .....	19
Jumpers and Links (103369-01 and -02) .....	28
Jumpers and Links (103369-03) .....	28
Configuring Unit .....	32
7-Segment Alert and System Status Codes .....	36
Compressor Information and Testing .....	41
Maintenance .....	45
Checklists .....	45
Unit Wiring Diagrams .....	47
Factory Wiring Diagrams .....	51
Load Shed Wiring .....	55
Unit Sequence of Operations .....	58

**III. INSTALLATION**

Unit Placement .....	62
Removing and Installing Panels .....	65
Electrical .....	66
Field Control Wiring .....	68
New or Replacement Line Set .....	70
Brazing Connections .....	72
Flushing the System .....	75
Leak Testing the System .....	77
Evacuating the System .....	79
Unit Start-Up .....	81


**IV. SYSTEM CHARGE**

Servicing Unit Delivered Void of Charge .....	81
Unit Start-Up .....	81
System Refrigerant .....	81


**APPENDIX A - UNIT CHARGING STICKERS**

# I. OVERVIEW

## Model Number Identification



## Typical Serial Number Identification



## Specifications

Model Number	Unit		Outdoor Fan	
	Sound Rating Number (dB) <sup>1</sup>	Factory Refrigerant Charge <sup>2</sup>	Number of Blades	Diameter - inches.
XC21-024-230-04	69	12 lbs. 0 oz.	3	26.0
XC21-024-230-05, -06, -07, -08, -09, -10	69	11 lbs. 12 oz.	5	26.1
XC21-036-230-04	71	12 lbs. 5 oz.	3	26.0
XC21-036-230-05, -06, -07, -08, -09, -10	71	12 lbs. 5 oz.	5	26.1
XC21-048-230-04	73	13 lbs. 0 oz.	3	26.0
XC21-048-230-05, -06, 07	73	13 lbs. 0 oz.	5	26.1
XC21-048-230-08, -09, 10	73	13 lbs. 8 oz.	5	26.1
XC21-060-230-04,	73	13 lbs. 0 oz.	3	26.0
XC21-060-230-05, -06, -07	73	13 lbs. 0 oz.	5	26.1
XC21-060-230-08	73	13 lbs. 10 oz.	5	26.1
XC21-060-230-09, -10	73	13 lbs. 0 oz.	5	26.1
XC21-060-230-11	73	12 lbs. 8 oz.	5	26.1

<sup>1</sup> Tested according to AHRI Standard 270-2008 test conditions.

<sup>2</sup> Refrigerant charge sufficient for 15 feet length of refrigerant lines.

## Electrical Data

208/230V-60 Hz-1 Ph

Model Number	Unit		Compressor		Condenser Fan			
	Maximum Over-current Protection (amps) <sup>1</sup>	Minimum Circuitry Ampacity <sup>2</sup>	Rated Load Amps (RLA)	Locked Rotor Amps (LRA)	Motor HP	Nominal RPM 1-Stage	Nominal RPM 2-Stage	Full Load Amps (FLA)
XC21-024-230-04	25	15.7	10.3	52.0	1/3	700	820	2.8
XC21-024-230-05	30	18.9	13.5	58.3	1/3	475	550	2.0
XC21-024-230-06	30	18.9	13.5	58.3	1/3	475	550	2.0
XC21-024-230-07	25	20.0	10.3	52.0	1/3	475	550	2.0
XC21-024-230-08, -09, -10	25	20.0	11.7	58.3	1/3	425	500	2.0

208/230V-60 Hz-1 Ph

Model Number	Unit		Compressor		Condenser Fan			
	Maximum Over-current Protection (amps) <sup>1</sup>	Minimum Circuitry Ampacity <sup>2</sup>	Rated Load Amps (RLA)	Locked Rotor Amps (LRA)	Motor HP	Nominal RPM 1-Stage	Nominal RPM 2-Stage	Full Load Amps (FLA)
XC21-036-230-04	40	23.7	16.7	82.0	1/3	700	820	2.8
XC21-036-230-05	35	22.9	16.7	82.0	1/3	475	550	2.0
XC21-036-230-06	35	22.9	16.7	82.0	1/3	475	550	2.0
XC21-036-230-07	35	22.9	16.7	82.0	1/3	475	550	2.0
XC21-036-230-08, -09, -10	35	21.1	15.3	83.0	1/3	525	600	2.0

208/230V-60 Hz-1 Ph

Model Number	Unit		Compressor		Condenser Fan			
	Maximum Over-current Protection (amps) <sup>1</sup>	Minimum Circuitry Ampacity <sup>2</sup>	Rated Load Amps (RLA)	Locked Rotor Amps (LRA)	Motor HP	Nominal RPM 1-Stage	Nominal RPM 2-Stage	Full Load Amps (FLA)
XC21-048-230-04	50	29.3	21.2	96.0	1/3	700	820	2.8
XC21-048-230-05, 06, -07	45	28.5	21.2	96.0	1/3	600	675	2.0
XC21-048-230-08, -09, -10	45	28.5	21.2	104.0	1/3	600	675	2.0



208/230V-60 Hz-1 Ph

Model Number	Unit		Compressor		Condenser Fan			
	Maximum Over-current Protection (amps) <sup>1</sup>	Minimum Circuitry Ampacity <sup>2</sup>	Rated Load Amps (RLA)	Locked Rotor Amps (LRA)	Motor HP	Nominal RPM 1-Stage	Nominal RPM 2-Stage	Full Load Amps (FLA)
XC21-060-230-04	60	34.9	25.7	118.0	1/3	700	820	2.8
XC21-060-230-05	50	25.7	25.7	118.0	1/3	600	675	2.0
XC21-060-230-06	50	25.7	25.7	118.0	1/3	600	675	2.0
XC21-060-230-07	50	34.1	25.7	118.0	1/3	600	675	2.0
XC21-060-230-08	60	38.0	28.8	152.9	1/3	625	700	2.0
XC21-060-230-09, -10	50	34.1	25.7	118.0	1/3	600	675	2.0
XC21-060-230-11	60	38.5	27.1	152.9	1/3	625	700	2.0

<sup>1</sup> HACR type circuit breaker or fuse.

<sup>2</sup> Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.

**Unit Dimensions - Inches (mm) and Parts Arrangement**



# Typical Unit Parts Arrangement




Figure 1. Plumbing, Switches and Sensor Components

## Accessories

For update-to-date information, see any of the following publications:

- Lennox XC21 Product Specification bulletin (EHB)
- Lennox Product Catalog
- Lennox Price Book

## ! IMPORTANT

This unit must be matched with an indoor coil as specified in the Product Specification bulletin. Coils previously charged with HCFC-22 must be flushed.

## ! CAUTION

As with any mechanical equipment, contact with sharp sheet metal edges can result in personal injury. Take care while handling this equipment and wear gloves and protective clothing.

## ! IMPORTANT

The Clean Air Act of 1990 bans the intentional venting of refrigerant (CFCs, HCFCs AND HFCs) as of July 1, 1992. Approved methods of recovery, recycling or reclaiming must be followed. Fines and/or incarceration may be levied for noncompliance.

## General

The XC21 is a high efficiency residential split-system air conditioner unit, which features a one-stage scroll compressor, iComfort™-enabled control and HFC-410A refrigerant. Units are available in 2, 3, 4 and 5-ton sizes. This model series is designed for use with an expansion valve metering device only. Refer to the XC17 Product Specification bulletin for ordering the correct indoor coil expansion valve.

## Operating Gauge Set and Service Valves

These instructions are intended as a general guide and do not supersede local codes in any way. Consult authorities who have jurisdiction before installation.

## TORQUE REQUIREMENTS

When servicing or repairing heating, ventilating, and air conditioning components, ensure the fasteners are appropriately tightened. Table 1 shows torque values for fasteners.

## ! IMPORTANT

Only use Allen wrenches of sufficient hardness (50Rc - Rockwell Harness Scale minimum). Fully insert the wrench into the valve stem recess.

Service valve stems are factory-torqued (from 9 ft-lbs for small valves, to 25 ft-lbs for large valves) to prevent refrigerant loss during shipping and handling. Using an Allen wrench rated at less than 50Rc risks rounding or breaking off the wrench, or stripping the valve stem recess.

See the Lennox Service and Application Notes #C-08-1 for further details and information.

## ! IMPORTANT

To prevent stripping of the various caps used, the appropriately sized wrench should be used and fitted snugly over the cap before tightening.

Table 1. Torque Requirements

Parts	Recommended Torque	
Service valve cap	8 ft.- lb.	11 NM
Sheet metal screws	16 in.- lb.	2 NM
Machine screws #10	28 in.- lb.	3 NM
Compressor bolts	90 in.- lb.	10 NM
Gauge port seal cap	8 ft.- lb.	11 NM

## USING MANIFOLD GAUGE SET

When checking the system charge, only use a manifold gauge set that features low loss anti-blow back fittings.

Manifold gauge set used with HFC-410A refrigerant systems must be capable of handling the higher system operating pressures. The gauges should be rated for use with pressures of 0 - 800 psig on the high side and a low side of 30" vacuum to 250 psig with dampened speed to 500 psi. Gauge hoses must be rated for use at up to 800 psig of pressure with a 4000 psig burst rating.

## OPERATING SERVICE VALVES


The liquid and vapor line service valves are used for removing refrigerant, flushing, leak testing, evacuating, checking charge and charging.

Each valve is equipped with a service port which has a factory-installed valve stem. Figure 2 provides information on how to access and operating both angle and ball service valves.


# SERVICE VALVES ANGLE AND BALL

## Operating Angle Type Service Valve:

1. Remove stem cap with an appropriately sized wrench.
2. Use a service wrench with a hex-head extension (3/16" for liquid line valve sizes and 5/16" for vapor line valve sizes) to back the stem out counterclockwise as far as it will go.




When service valve is **OPEN**, the service port is open to line set, indoor and outdoor unit.



WHEN SERVICE VALVE IS **CLOSED**, THE SERVICE PORT IS OPEN TO THE LINE SET AND INDOOR UNIT.

## Operating Ball Type Service Valve:


1. Remove stem cap with an appropriately sized wrench.
2. Use an appropriately sized wrench to open. To open valve, rotate stem counterclockwise 90°. To close, rotate stem clockwise 90°.



## To Access Service Port:

A service port cap protects the service port core from contamination and serves as the primary leak seal.


1. Remove service port cap with an appropriately sized wrench.
2. Connect gauge set to service port.
3. When testing is completed, replace service port cap and tighten as follows:
  - With torque wrench: Finger tighten and torque cap per table 1.
  - Without torque wrench: Finger tighten and use an appropriately sized wrench to turn an additional 1/6 turn clockwise.



## Reinstall Stem Cap:

Stem cap protects the valve stem from damage and serves as the primary seal. Replace the stem cap and tighten as follows:

- With Torque Wrench: Finger tighten and then torque cap per table 1.
- Without Torque Wrench: Finger tighten and use an appropriately sized wrench to turn an additional 1/12 turn clockwise.



NOTE — A label with specific torque requirements may be affixed to the stem cap. If the label is present, use the specified torque.

Figure 2. Angle and Ball Service Valves

## II. SYSTEM OPERATION AND SERVICE

### **▲ IMPORTANT**

Some scroll compressor have internal vacuum protector that will unload scrolls when suction pressure goes below 20 psig. A hissing sound will be heard when the compressor is running unloaded. Protector will reset when low pressure in system is raised above 40 psig. **DO NOT REPLACE COMPRESSOR.**

The main control (A175) provides the following system functions:

- Compressor anti-short-cycle delay.
- High (S4) and low (S87) pressure switches
- Ambient (RT13) and Discharge Line (RT28) Temperature Sensors Monitoring and Protection.
- Five strikes lockout safety feature for High/Low Pressure Switches and High Discharge Line Temperature. See figures 35, 34 and 36 feature function.

### **COMPRESSOR ANTI-SHORT CYCLE DELAY**

The main control protects the compressor from:

- Short cycling (five minutes) when there is initial power up
- Interruption in power to the unit
- High or low pressure switch or discharge line sensor trips
- Delay after Y1 demand is removed.

In non-communicating systems the delay is set for 300 seconds (five minutes) and can not be changed. To override timer when active or inactive, place a jumper on the field test pins between 1 and 2 seconds.

In communicating system, the iComfort™ thermostat has a separate built-in 5-minute non-adjustable short cycle protection.

#### **Resetting Anti-Short Cycle Delay**

The **E33** pins on the main control can be jumpered between 1 to 2 seconds to reset the anti-short cycle delay sequence.

### **HIGH (S4) AND LOW (S87) PRESSURE SWITCHES**

The unit's reset pressure switches LO PS (S4) and HI PS (S87) are factory-wired into the main control on the LO-PS and HI-PS terminals, there locations are illustrated on page 5. Sequence of operations for both pressure switches are provided in figures 35 and 34.

### **HIGH DISCHARGE LINE TEMPERATURE SENSOR (RT28)**

The high discharge line temperature sensor location is illustrated on page 5. This sensor's sequence of operations is provided in figure 36.

#### **High Discharge Line Sensor Open/Shorted Event Condition**


Discharge sensor open / short fault is ignored during initial 90-seconds of compressor run time. After that, if discharge temperature sensor is detected open or short, the control will de-energize all the outputs and anti-short cycle timer is started. Discharge sensor faulty alert LED code will be displayed.

### **OUTDOOR AMBIENT TEMPERATURE (RT13)**

If the outdoor ambient temperature sensor detected a open, or out of range  $-40^{\circ}\text{F}$  to  $+140^{\circ}\text{F}$  ( $-40^{\circ}\text{C}$  to  $60^{\circ}\text{C}$ ) then LED alert codes are displayed, however cooling operation will continue. See table 6 for LED alert codes for the ambient sensor. Location of outdoor ambient temperature sensor is illustrated on page 5.

### **COIL TEMPERATURE SENSOR**

This model does not use a coil temperature sensor. The cable assembly attached to the main control's E30 connection has a 10K resistor installed between pins 5 and 6 as illustrated in figure 3.



**Figure 3. 10k Resistor Location**

### **TESTING AMBIENT (RT13) AND HIGH DISCHARGE LINE TEMPERATURE (RT28) SENSORS**

Sensors connect through a field-replaceable harness assembly that plugs directly into the main control. Through these sensors, the main control can monitor outdoor ambient and discharge line temperature fault conditions. As the detected temperature changes, the resistance across the sensor changes. Tables 3 and 4 lists how the resistance varies as the temperature changes for both type of sensors. Sensor resistance values can be checked by ohming across pins shown in table 2.

When a sensor indicates a resistance value that is not within the range as listed in table 2, then the following condition may be present:

- Sensor detects an out-of-range outdoor ambient air temperature condition and will display LED alert code on the main control.
- The sensor is operating normally when the ambient air temperature at the sensor is below or above the main control's expected ohm values. The main control will indicate the sensor as faulty, however under this scenario, the sensor is not actually faulty.
- Once the outdoor ambient air temperature has returned to within the sensor's normal operating range, the LED alert code will automatically stop.



**Table 2. Sensor Temperature / Resistance Range**

Sensor	Temperature Range °F (°C)	Resistance values range (ohms)	Pins/ Wire Color
Outdoor (Ambient)	-40°F to 140°F (-40°C to 60°C)	280,000 to 3750	3 and 4 (Black)
Discharge	-35°F to 310°F (-37°C to 154°C)	41,000 to 103	1 and 2 (Yellow)

Note: Sensor resistance decreases as sensed temperature increases (see tables 3 and 4.

**Table 3. Ambient Sensor (RT13) Temperature / Resistance Range**

Degrees Fahrenheit	Resistance	Degrees Fahrenheit	Resistance	Degrees Fahrenheit	Resistance	Degrees Fahrenheit	Resistance
136.3	2680	56.8	16657	21.6	44154	-11.3	123152
133.1	2859	56.0	16973	21.0	44851	-11.9	125787
130.1	3040	55.3	17293	20.5	45560	-12.6	128508
127.3	3223	54.6	17616	20.0	46281	-13.2	131320
124.7	3407	53.9	17942	19.4	47014	-13.9	134227
122.1	3592	53.2	18273	18.9	47759	-14.5	137234
119.7	3779	52.5	18607	18.4	48517	-15.2	140347
117.5	3968	51.9	18945	17.8	49289	-15.9	143571
115.3	4159	51.2	19287	17.3	50074	-16.5	146913
113.2	4351	50.5	19633	16.8	50873	-17.2	150378
111.2	4544	49.9	19982	16.3	51686	-17.9	153974
109.3	4740	49.2	20336	15.7	52514	-18.6	157708
107.4	4937	48.5	20695	15.2	53356	-19.3	161588
105.6	5136	47.9	21057	14.7	54215	-20.1	165624
103.9	5336	47.3	21424	14.1	55089	-20.8	169824
102.3	5539	46.6	21795	13.6	55979	-21.5	174200
100.6	5743	46.0	22171	13.1	56887	-22.3	178762
99.1	5949	45.4	22551	12.5	57811	-23.0	183522
97.6	6157	44.7	22936	12.0	58754	-23.8	188493
96.1	6367	44.1	23326	11.5	59715	-24.6	193691
94.7	6578	43.5	23720	11.0	60694	-25.4	199130
93.3	6792	42.9	24120	10.4	61693	-26.2	204829
92.0	7007	42.3	24525	9.9	62712	-27.0	210805
90.6	7225	41.7	24934	9.3	63752	-27.8	217080
89.4	7444	41.1	25349	8.8	64812	-28.7	223677
88.1	7666	40.5	25769	8.3	65895	-29.5	230621
86.9	7890	39.9	26195	7.7	67000	-30.4	237941
85.7	8115	39.3	26626	7.2	68128	-31.3	245667
84.5	8343	38.7	27063	6.7	69281	-32.2	253834
83.4	8573	38.1	27505	6.1	70458	-33.2	262482
82.3	8806	37.5	27954	5.6	71661	-34.1	271655
81.2	9040	37.0	28408	5.0	72890	-35.1	281400
80.1	9277	36.4	28868	4.5	74147	-36.1	291774
79.0	9516	35.8	29335	3.9	75431	-37.1	302840
78.0	9757	35.2	29808	3.4	76745	-38.2	314669
77.0	10001	34.7	30288	2.8	78090	-39.2	327343

76.0	10247	34.1	30774	2.3	79465
75.0	10496	33.5	31267	1.7	80873
74.1	10747	33.0	31766	1.2	82314
73.1	11000	32.4	32273	0.6	83790
72.2	11256	31.9	32787	0.0	85302
71.3	11515	31.3	33309	-0.5	86852
70.4	11776	30.7	33837	-1.1	88440
69.5	12040	30.2	34374	-1.7	90068
68.6	12306	29.6	34918	-2.2	91738
67.7	12575	29.1	35471	-2.8	93452
66.9	12847	28.6	36031	-3.4	95211
66.0	13122	28.0	36600	-4.0	97016
65.2	13400	27.5	37177	-4.6	98870
64.4	13681	26.9	37764	-5.2	100775
63.6	13964	26.4	38359	-5.7	102733
62.8	14251	25.8	38963	-6.3	104746
62.0	14540	25.3	39577	-6.9	106817
61.2	14833	24.8	40200	-7.5	108948
60.5	15129	24.2	40833	-8.2	111141
59.7	15428	23.7	41476	-8.8	113400
59.0	15730	23.2	42130	-9.4	115727
58.2	16036	22.6	42794	-10.0	118126
57.5	16345	22.1	43468	-10.6	120600

**Table 4. High Discharge (RT28) Sensor Temperature / Resistance Range**


Degrees Fahrenheit	Resistance	Degrees Fahrenheit	Resistance	Degrees Fahrenheit	Resistance	Degrees Fahrenheit	Resistance
303.1	183	186.1	1052	136.8	2656	94.5	6613
298.1	195	185.0	1072	136.0	2698	93.6	6739
293.4	207	183.9	1093	135.2	2740	92.8	6869
289.0	220	182.8	1114	134.5	2783	92.0	7002
284.8	232	181.8	1135	133.7	2827	91.2	7139
280.9	245	180.7	1157	132.9	2872	90.3	7281
277.1	258	179.6	1179	132.2	2917	89.5	7426
273.6	270	178.6	1201	131.4	2963	88.6	7575
270.2	283	177.6	1223	130.6	3010	87.8	7729
267.0	297	176.6	1245	129.9	3057	86.9	7888
263.9	310	175.5	1268	129.1	3105	86.0	8051
260.9	323	174.6	1291	128.4	3154	85.2	8220
258.1	336	173.6	1315	127.6	3204	84.3	8394
255.3	350	172.6	1338	126.8	3255	83.4	8574
252.7	364	171.6	1362	126.1	3307	82.5	8759
250.1	378	170.6	1386	125.3	3359	81.6	8951
247.7	391	169.7	1411	124.6	3413	80.7	9149
245.3	405	168.7	1435	123.8	3467	79.8	9354
243.0	420	167.8	1460	123.1	3523	78.8	9566
240.8	434	166.9	1486	122.3	3579	77.9	9786
238.6	448	165.9	1511	121.6	3637	76.9	10013
236.5	463	165.0	1537	120.8	3695	76.0	10250
234.4	478	164.1	1563	120.1	3755	75.0	10495
232.4	492	163.2	1590	119.3	3816	74.1	10749
230.5	507	162.3	1617	118.5	3877	73.1	11014
228.6	523	161.4	1644	117.8	3940	72.1	11289
226.7	538	160.5	1672	117.0	4005	71.1	11575
224.9	553	159.7	1699	116.3	4070	70.0	11873
223.2	569	158.8	1728	115.5	4137	69.0	12184
221.5	584	157.9	1756	114.8	4205	68.0	12509
219.8	600	157.1	1785	114.0	4274	66.9	12848
218.1	616	156.2	1815	113.2	4345	65.8	13202
216.5	632	155.3	1845	112.5	4418	64.7	13573
214.9	649	154.5	1875	111.7	4491	63.6	13961
213.4	665	153.6	1905	111.0	4567	62.5	14368
211.9	682	152.8	1936	110.2	4644	61.3	14796
210.4	698	152.0	1968	109.4	4722	60.2	15246
208.9	715	151.1	1999	108.7	4802	59.0	15719
207.5	732	150.3	2032	107.9	4884	57.8	16218
206.0	750	149.5	2064	107.1	4968	56.6	16744
204.6	767	148.7	2098	106.4	5054	55.3	17301
203.3	785	147.9	2131	105.6	5141	54.0	17891
201.9	803	147.1	2165	104.8	5231	52.7	18516
200.6	821	146.2	2200	104.0	5323	51.4	19180
199.3	839	145.4	2235	103.3	5416	50.0	19887
198.0	857	144.6	2270	102.5	5512	48.6	20641
196.8	876	143.8	2306	101.7	5610	47.2	21448
195.5	894	143.0	2343	100.9	5711	45.7	22311
194.3	913	142.3	2380	100.1	5814		
193.1	932	141.5	2418	99.3	5920		
191.9	952	140.7	2456	98.5	6028		
190.7	971	139.9	2495	97.7	6139		
189.5	991	139.1	2534	96.9	6253		
188.4	1011	138.3	2574	96.1	6370		
187.2	1031	137.6	2615	95.3	6489		

# Jumpers, Loop and Terminals (101798-XX)

**Table 5. Main Control Jumpers and Terminals**

## TWO-STAGE

Table 5 provides additional information concerning jumpers, links, and connections for the A175 Main Control.




Board ID	Label	Description
E12	PSC Fan	240 VAC output connection for outdoor fan.
E16	PSC Fan	240 VAC input connection for outdoor fan.
E18	W	24VAC output for defrost auxiliary heat output.
	L	Thermostat service light connection.
	Y2	24VAC thermostat input/output for second stage operation of the unit.
	Y1	24VAC thermostat input for first stage operation of the unit.
	O	24VAC thermostat input for reversing valve operation
	DS	Humiditrol Input
	C	24VAC system common
	i-	Input/Output - RSBus data low. Used in communicating mode only with compatible indoor thermostat.
	i+	Input/Output - RSBus data high. Used in communicating mode only with compatible indoor thermostat.
R	24VAC system power input	
E21 and E22	LO-PS	S4 connection for low-pressure switch (2.4 milliamps @ 18VAC)
E31 and E32	Y1 OUT	24VAC common output, switched for enabling compressor contactor.
E24 and E25	HS-PS	S87 connection for high-pressure switch (E25) and 24VAC (E24) to A177 "R" input.
E26	Y1 FAN	First Stage and second stage basic and precision dehumidification ECM fan motor 24VDC output connection 1.
E27	Y2 FAN	Second stage basic and precision dehumidification ECM fan motor 24VDC output connection 2.
E28	FAN C	ECM common connection for ECM fan.
E30	Six position square pin header E30 provides connections for the temperature sensors.	
	DIS (YELLOW) PINS 5 and 6	DIS 5 — Discharge line temperature sensor supply. DIS 6 — Discharge line temperature sensor return. Range is 35°F to 310°F. Sensor is clipped on a 1/2" copper tube.
	AMB (BLACK) Pins 3 and 4	AMB 3 — Outdoor ambient temperature sensor supply. AMB 4 — Outdoor ambient temperature return. Range is 40°F to +140°F
	COIL (BROWN) Pins 1 and 2	COIL 1 — Outdoor coil temperature sensor supply. COIL 2 — Outdoor coil temperature sensor return This model does not utilize a coil sensor. The cable harness assembly for the sensors incorporates a 10K resistor between pins 5 and 6.
E33	Field Test	This jumper allows service personnel to defeat the timed off control, initiate or terminate a defrost and field programming of unit capacity feature.
E34	Y2 Solenoid	Second-stage compressor output.
W1	Short DS To R	Cut for Humiditrol (EDA) application. This sets the outdoor fan speed to predefined speed. See table 12 for set speed based on unit capacity size. Use only in two-stage units.

**Figure 4. Jumpers, Loop and Links (Outdoor Control Part Number - 101798-XX)**

# E33 JUMPER (TEST) PINS

PLACING THE **JUMPER ON** THE **E33** JUMPER PINS (SEE PAGE 37 FOR LOCATION OF **E33** JUMPER PINS) ALLOWS THE TECHNICIAN TO

- CLEAR COMPRESSOR ANTI-SHORT CYCLE DELAY.
- CLEAR FIVE-STRIKE FAULT LOCKOUTS — HIGH / LOW PRESSURE SWITCHES AND HIGH DISCHARGE TEMPERATURE SENSOR.
- SET THE UNIT CAPACITY CODE (PROCEDURE PROVIDED ON PAGE 19).



NOTES:

1 — PLACING A **JUMPER ON** THE **E33** PINS WILL NOT RESET (REBOOT) THE MAIN CONTROL (A175). THE ONLY WAY TO RESET THE OUTDOOR UNIT IS TO CYCLE THE 24VAC POWER TO THE OUTDOOR UNIT'S MAIN CONTROL.

2 — IF THE JUMPER REMAINS ON THE **E33** PINS FOR LONGER THAN FIVE SECONDS, THE MAIN CONTROL WILL IGNORE THE **JUMPER ON** E33 PINS AND REVERT TO NORMAL OPERATION.

**Figure 5. Multi-Function E33 Jumper (Test) Pin (Outdoor Control Part Number - 101798-XX)**

## System Status, Fault and Lockout LED Codes - (Outdoor Control Part Number - 101798-XX)

LED codes are displayed using various LEDs located on the air conditioner control (A175). See page 12 for location of air conditioner control LEDs.

### DS11 AND DS14 — SYSTEM STATUS, FAULT AND LOCKOUT LED CODES

DS11 (Green) and DS14 (Red) LEDs indicate non-communicating mode diagnostics conditions that are listed in table 6.

These LEDs display fault conditions in system cooling capacity, dehumidification mode, anti-short cycle lockout, high and low pressures, high discharge line temperature, outdoor ambient temperature, and discharge sensor failures.

### DS15 AND DS13 — COMPRESSOR FAULT AND LOCKOUT LED CODES

DS15 (Yellow) and DS13 (Red) LEDs indicate non-communicating mode diagnostics conditions that are listed in table 7.

These LEDs display the most common fault conditions in the system. When an abnormal condition is detected, this function communicates the specific condition through system diagnostic LEDs. The function is capable of detecting both mechanical and electrical system problems.

**Table 6. System Status, Fault and Lockout LED Codes and Related iComfort™ Thermostat Alert Codes (Outdoor Control Part Number - 101798-XX)**

System fault and lockout alarm codes take precedence over system status codes (cooling, heating stages or defrost/dehumidification). The LEDs display only the latest active fault or lock out alarm code (if present). The LEDs display system status if no fault or lockout codes are active. See notes at end of table for duration of fast flash, slow flash and pause.					
Air Conditioner Control LEDs		iComfort™ Thermostat Display	Condition	Possible Cause(s)	Solution
DS11 Green	DS14 Red				
SYSTEM STATUS					
Off	Off	Not applicable	Power problem	No power (24V) to control terminals R and C or control failure.	1 Check control transformer power (24V). 2 If power is available to control and LED(s) do not light, replace control.
Simultaneous slow flash		Not applicable	Normal operation	Unit operating normally or in standby mode.	
Alternating slow flash		Not applicable	5-minute anti-short-cycle delay	Initial power up, safety trip, end of room thermostat demand.	None required (Jumper FIELD TEST pins to override)
Simultaneous fast flash		Moderate / Critical Alert Code 180	Ambient sensor problem	Sensor being detected open or shorted or out of temperature range. control will revert to time/temperature defrost operation. (System will still heat or cool).	
Alternating fast flash		Moderate / Critical Alert Code 417	Coil sensor problem	This model does not utilize a coil sensor, however this alert indicates either an open or shorted circuit. See if 10K resistor is not damage or missing. Resistor is located in the sensor harness assembly, brown lead.	

## ⚠ IMPORTANT

DS15 and DS13 compressor LED fault and lockout codes do not provide safety protection. This is a monitoring function only and cannot control or shut down other devices.

### RESETTING LED FAULT AND LOCKOUT LED CODES

All LED fault and lockout codes can be reset manually or automatically:

#### 1. Manual Reset

Manual reset can be achieved by one of the following methods:

- Disconnecting **R** wire from the air conditioner control's **R** terminal.
- Turning the indoor unit off and on again.

Cycle the 24VAC power to air conditioner control off and on. After power up, existing code will display for 60 seconds and then clear.

#### 2. Automatic Reset

After a fault or lockout is detected, the air conditioner control continues to monitor the unit's system and compressor operations. When/if conditions return to normal, the alert code is turned off automatically.

System fault and lockout alarm codes take precedence over system status codes (cooling, heating stages or defrost/dehumidification). The LEDs display only the latest active fault or lock out alarm code (if present). The LEDs display system status if no fault or lockout codes are active. See notes at end of table for duration of fast flash, slow flash and pause.

Air Conditioner Control LEDs		iComfort™ Thermostat Display	Condition	Possible Cause(s)	Solution
DS11 Green	DS14 Red				
On	On	Not applicable	Air conditioner control failure	Indicates that control has internal component failure. Cycle 24 volt power to control. If code does not clear, replace control.	
On	2 fast flashes then pause	Not applicable	Defrost	These are codes that show status of operation whether in low stage or high stage, heating or cooling, defrost or in the EDA mode.	
1 fast flashes then pause	Off	Not applicable	First-stage compressor cooling	These are codes that show status of operation whether in low stage or high stage, heating or cooling, defrost or in the EDA mode.	
2 fast flashes then pause	Off	Not applicable	Second-stage compressor cooling	These are codes that show status of operation whether in low stage or high stage, heating or cooling, defrost or in the EDA mode.	
2 fast flashes then pause	On	Not applicable	Dehumidification mode	These are codes that show status of operation whether in low stage or high stage, heating or cooling, defrost or in the EDA mode.	
<b>ALERT STATUS</b>					
None	None	Moderate Alert Code 105	Device communication failure	iComfort™ thermostat device is unable to communicate with any other device on the RSBus. Alarm only occurs if a specific device did communicate initially after power up and communication was later lost. Possible causes are lost connection, bus short or open, or other device stop responding.	
None	None	Moderate Alert Code 120	Unresponsive device	Message could be sent by any device on RSBus if expected response message is not received from other device. If sent by indoor or outdoor control, device did not get expected response (incorrect or no response at all) from active Subnet controller. If sent by the iComfort Touch® thermostat, and did not get the expected response (incorrect or no response at all) from device. Normally this indicate device malfunction.	
None	None	Critical Alert Code 124	Active subnet controller missing	Device lost connection to iComfort™ thermostat. Thermostat is sending heartbeat message in one minute intervals. Device sets this alarm if no Heartbeat is received for three minutes. Normally this indicate lost connection to thermostat, or thermostat is not working. Alert will clear after valid subnet controller message is received.	
None	None	Critical Alert Code 125	Hardware failure	Entire or partial system failure. Alert will clear 300 seconds after fault has recovered.	
None	None	Moderate / Critical Alert Code 126	Internal control communication failure	Internal communication on outdoor control. Alert will clear 300 seconds after fault has recovered.	
None	None	Critical Alert Code 131	Corrupted control parameters	System stored configuration data is corrupted. System will not run. Refer to communicating thermostat for memory corrupt handling.	
None	None	Critical Alert Code 132	Failed flash CRC check.	No operations, A175 control enters boot loader mode. Alarm will clear after reset.	

System fault and lockout alarm codes take precedence over system status codes (cooling, heating stages or defrost/dehumidification). The LEDs display only the latest active fault or lock out alarm code (if present). The LEDs display system status if no fault or lockout codes are active. See notes at end of table for duration of fast flash, slow flash and pause.

Air Conditioner Control LEDs		iComfort™ Thermostat Display	Condition	Possible Cause(s)	Solution
DS11 Green	DS14 Red				
Off	Slow flash	Moderate Alert Code 410	Low pressure fault	<ol style="list-style-type: none"> <li>1 Restricted air flow over indoor or outdoor coil.</li> <li>2 Improper refrigerant charge in system.</li> <li>3 Improper metering device installed or incorrect operation of metering device.</li> <li>4 Incorrect or improper sensor location or connection to system.</li> </ol>	<ol style="list-style-type: none"> <li>1 Remove any blockages or restrictions from coils and/or fans. Check indoor and outdoor fan motor for proper current draws.</li> <li>2 Check system charge using approach and subcooling temperatures.</li> <li>3 Check system operating pressures and compare to unit charging charts.</li> <li>4 Make sure all pressure switches and sensors have secure connections to system to prevent refrigerant leaks or errors in pressure and temperature measurements.</li> </ol>
Off	On	Critical Alert Code 411	Low pressure switch lockout		
Slow flash	Off	Moderate Alert Code 412	High pressure fault		
On	Off	Critical Alert Code 413	High pressure switch lockout		
Slow flash	On	Moderate Alert Code 414	Discharge line temperature fault	This code detects high discharge temperatures. If the discharge line temperature exceeds a temperature of 279°F (137°C) during compressor operation, the control will de-energize the compressor contactor output (and the defrost output if active). The compressor will remain off until the discharge temperature has dropped below 225°F (107°C).	
Fast flash	On	Critical Alert Code 415	Discharge line temperature lockout		
OFF	Fast flash	Moderate / Critical Alert Code 417	Discharge sensor fault	The A175 control detects open or short sensor or out of temperature sensor range. This fault is detected by allowing the unit to run for 90 seconds before checking sensor resistance. If the sensor resistance is not within range after 90 seconds, the control will raise the alarm.	
Simultaneous Fast flash then Pause		None	Second-stage heat lock-in	If the unit is in non-communicating mode and it goes to second stage due to ambient temperature being below second stage lock-in setting (E48).	
Fast simultaneous flashing of DS11, DS13, DS14 and DS15			OEM mode	Factory Test Mode.	
<ol style="list-style-type: none"> <li>1. Pause duration is two (2) seconds.</li> <li>2. Fast flash duration is 1/2 second. Slow flash duration is one (1) second.</li> </ol>					

**Table 7. Compressor Fault and Lockout LED Codes and Related iComfort™ Thermostat Alert Codes (Outdoor Control Part Number - 101798-XX)**

NOTE — See notes 1 and 2 in table below for duration of fast / slow flashes and pause.

Air Conditioner Control LEDs		iComfort™ Thermostat Display	Condition	Possible Cause(s)	Solution	Clearing Status
DS15 Yellow	DS13 Red					
Off	On	Moderate/ Critical Alert <sup>3</sup> 400	Compressor internal overload trip	Thermostat demand signal Y1 is present, but compressor not running	<ol style="list-style-type: none"> <li>1 Compressor protector is open. <ul style="list-style-type: none"> <li>• Check for high head pressure</li> <li>• Check compressor supply voltage</li> </ul> </li> <li>2 Outdoor unit power disconnect is open.</li> <li>3 Compressor circuit breaker or fuse(s) is open.</li> <li>4 Broken wire or connector is not making contact.</li> <li>5 Low or high pressure switch open if present in the system.</li> <li>6 Compressor contactor has failed to close.</li> </ol>	Clears the error after current is sensed in the run and start winding for two seconds, service removed or power reset.



Air Conditioner Control LEDs		iComfort™ Thermostat Display	Condition	Possible Cause(s)	Solution	Clearing Status
DS15 Yellow	DS13 Red					
1 flash then pause	Off	<p><b>Critical Alert</b> Code 401 (outdoor control part# 101798-03)</p> <p><b>Moderate Alert</b> Code 401 (outdoor control part# 101798-04)</p>	Long run time.	Compressor is running extremely long run cycles.	<ol style="list-style-type: none"> <li>1 Low refrigerant charge.</li> <li>2 Evaporator blower is not running. <ul style="list-style-type: none"> <li>• Check blower relay coil and contacts</li> <li>• Check blower motor capacitor</li> <li>• Check blower motor for failure or blockage</li> <li>• Check evaporator blower wiring and connectors</li> <li>• Check indoor blower control</li> <li>• Check thermostat wiring for open circuit</li> </ul> </li> <li>3 Evaporator coil is frozen. <ul style="list-style-type: none"> <li>• Check for low suction pressure</li> <li>• Check for excessively low thermostat setting</li> <li>• Check evaporator airflow (coil blockages or return air filter)</li> <li>• Check ductwork or registers for blockage.</li> </ul> </li> <li>4 Faulty metering device. <ul style="list-style-type: none"> <li>• Check TXV bulb installation (size, location and contact)</li> <li>• Check if TXV/fixed orifice is stuck closed or defective</li> </ul> </li> <li>5 Condenser coil is dirty.</li> <li>6 Liquid line restriction (filter drier blocked if present).</li> <li>7 Thermostat is malfunctioning. <ul style="list-style-type: none"> <li>• Check thermostat sub-base or wiring for short circuit</li> <li>• Check thermostat installation (location and level)</li> </ul> </li> </ol>	Clears the error after 30 consecutive normal run cycles, or after power reset.
2 flashes then pause	Off	Critical Alert Code 402	System pressure trip	Indicates the compressor protector is open or missing supply power to the compressor.	<ol style="list-style-type: none"> <li>1 High head pressure. <ul style="list-style-type: none"> <li>• Check high pressure switch if present in system</li> <li>• Check if system is overcharged with refrigerant</li> <li>• Check for non-condensable in system</li> </ul> </li> <li>2 Condenser coil poor air circulation (dirty, blocked, damaged).</li> <li>3 Condenser fan is not running. <ul style="list-style-type: none"> <li>• Check fan capacitor</li> <li>• Check fan wiring and connectors</li> <li>• Check fan motor for failure or blockage</li> </ul> </li> <li>4 Return air duct has substantial leakage.</li> </ol>	Clears after four consecutive normal compressor run cycles, or after power reset.
3 flashes then pause	Off	Moderate Alert Code 403	Short cycling	Compressor is running less than three minutes.	<ol style="list-style-type: none"> <li>1 Thermostat demand signal is intermittent.</li> <li>2 Time delay relay or Air Conditioner Control is defective.</li> <li>3 If high pressure switch is present, see flash Code 2 information.</li> </ol>	Clears after four consecutive normal compressor run cycles, or after power reset.
4 flashes then pause	Off	Critical Alert Code 404	Locked rotor	Compressor has a locked out due to run capacitor short, bearings are seized, excessive liquid refrigerant.	<ol style="list-style-type: none"> <li>1 Run capacitor has failed.</li> <li>2 Low line voltage (contact utility if voltage at disconnect is low). <ul style="list-style-type: none"> <li>• Check wiring connections</li> </ul> </li> <li>3 Excessive liquid refrigerant in the compressor.</li> <li>4 Compressor bearings are seized.</li> </ol>	Clears after power reset or four normal compressor cycles.

Air Conditioner Control LEDs		iComfort™ Thermostat Display	Condition	Possible Cause(s)	Solution	Clearing Status
DS15 Yellow	DS13 Red					
5 flashes then pause	Off	Critical Alert Code 405	Open circuit	Compressor has an open circuit due to power disconnection, fuse is open or other similar conditions.	<ol style="list-style-type: none"> <li>1 Outdoor unit power disconnect is open.</li> <li>2 Unit circuit breaker or fuse(s) is open.</li> <li>3 Unit contactor has failed to close. <ul style="list-style-type: none"> <li>• Check compressor contactor wiring and connectors</li> <li>• Check for compressor contactor failure (burned, pitted or open)</li> <li>• Check wiring and connectors between supply and compressor</li> <li>• Check for low pilot voltage at compressor contactor coil</li> </ul> </li> <li>4 High pressure switch is open and requires manual reset.</li> <li>5 Open circuit in compressor supply wiring or connections.</li> <li>6 Unusually long compressor protector reset time due to extreme ambient temperature.</li> <li>7 Compressor windings are damaged. <ul style="list-style-type: none"> <li>• Check compressor motor winding resistance</li> </ul> </li> </ol>	Clears after one normal compressor run cycle or power reset.
6 flashes then pause	Off	Critical Alert Code 406	Open start circuit	Current not sensed by Start transformer.	<ol style="list-style-type: none"> <li>1 Run capacitor has failed.</li> <li>2 Open circuit in compressor start wiring or connections. <ul style="list-style-type: none"> <li>• Check wiring and connectors between supply and the compressor <b>S</b> terminal</li> </ul> </li> <li>3 Compressor start winding is damaged. <ul style="list-style-type: none"> <li>• Check compressor motor winding resistance</li> </ul> </li> </ol>	Clears when amperage is detected in RUN and START sensors, or after power reset.
7 flashes then pause	Off	Critical Alert Code 407	Open run circuit	Current not sensed by run transformer.	<ol style="list-style-type: none"> <li>1 Open circuit in compressor start wiring or connections. <ul style="list-style-type: none"> <li>• Check wiring and connectors between supply and the compressor <b>R</b> terminal</li> </ul> </li> <li>2 Compressor start winding is damaged. <ul style="list-style-type: none"> <li>• Check compressor motor winding resistance</li> </ul> </li> </ol>	Clears when amperage is detected in RUN and START sensors, or after power reset.
8 flashes then pause	Off	Critical Alert Code 408	Welded contactor	Compressor always runs	<ol style="list-style-type: none"> <li>1 Compressor contactor failed to open.</li> <li>2 Thermostat demand signal not connected to module.</li> </ol>	Clears after one normal compressor run cycle or after power reset.
9 flashes then pause	Off	Moderate/Critical Alert <sup>3</sup> Code 409	Secondary low voltage	24VAC is below 18VAC.	<ol style="list-style-type: none"> <li>1 Control circuit transformer is overloaded.</li> <li>2 Low line voltage (contact utility if voltage at disconnect is low). <ul style="list-style-type: none"> <li>• Check wiring connections</li> </ul> </li> </ol>	Clears after voltage is higher than 20VAC for two seconds, or after power reset.
Fast simultaneous flashing of DS11, DS13, DS14 and DS15			OEM mode	Factory test mode.		
<ol style="list-style-type: none"> <li>1. Pause duration is two (2) seconds.</li> <li>2. Fast flash duration is 1/2 second. Slow flash duration is one (1) second.</li> <li>3. Initially a moderate status is displayed and is escalated to critical if alarm exists for more than 10 minutes.</li> </ol>						

## Field Configuration and Testing - (Outdoor Control Part Number - 101798-XX)

This section provides procedures for configuring, adjusting and testing various components of this unit.

- Fan Motor (B4) Test Procedure
- Fan Motor Control (A177) Configuration and Testing
- Top Grille and Fan Motor Mounting Adjustment (Fan Clearance)
- Heat Pump Control (A175) Unit Nominal Capacity Code configuration

### B4 FAN MOTOR TEST

See figure 9 for procedures on test the B4 fan motor.

### FAN MOTOR CONTROL (A177) LED CODES AND SEQUENCE OF OPERATION — XC21-XXX-230-05 AND LATER

During start up, the LED:

1. Display error conditions (see table 10), if present
2. If no errors are detected, then the LED code indicating stage operation (see table 11) will display the applicable code and then a long pause.
3. The fan motor speed / RPM (revolutions per minute) indicator is displayed next (see table 12).
4. After the RPM indicator is displayed, there is a short pause. The sequence repeats if a thermostat demand is still present. See figure 6 for LED sequence. See table 9 for description of flash and pause durations.

### FAN MOTOR CONTROL TROUBLESHOOTING — XC21-XXX-230-05 AND LATER

Use the following subsections to verify and test the fan motor control (A177).

#### Verifying Jumper Settings (J2)

The unit is shipped from the factory with the default motor RPM setting required for the specific model size. Use the table 12 for two-stage operation to verify that jumpers are set correctly for the specific size unit.

#### Verifying LED Status Codes

**During start up, the fan motor control LED will display any error conditions. If error conditions exist then no other codes will display. If no error conditions are present, then the stage status and and RPM indicator are displayed.** Two-stage units have various fan motor speed operations available (see table 12).

### Verifying Correct DC Output Voltage (J2)

The following three methods can be used to determine whether the fan motor (B4) is operating at the correct RPMs based on unit size.

1. Use the information provided in table 8 to verify that all four jumper terminals are set correctly for the specific size unit.
2. Verify LED RPM indicator is displaying the correct flash sequence for the applicable size unit (see table 12).
3. Test DC voltage output on the fan motor control's J2 terminals (see figure 7) while under full load and verify the voltage read to the voltage listed in table 12 for the applicable size unit.
4. If no voltage is detected at the **J2** terminals, verify there is a Y1 demand at the thermostat and applicable voltages detected all fan motor control voltage inputs, see table 8.

*NOTE — Voltage will be present at specific inputs depending on the type of demand (low or high stage and EDA operation).*

If there is a demand, proceed to the next section for further testing.

### **VERIFYING CORRECT INPUT VOLTAGE (ECM/Y1, ECM/Y2, ECM C AND EXT ECM/R) — XC21-XXX-230-05 AND LATER**

Using a volt meter, check voltages on the following fan motor control inputs using table 8. Voltage will only be present during a thermostat demand. See figure 8 for test example.

If correct voltages are detected at applicable inputs during a demand, and no voltage is present at the J2 terminals, then fan motor control should be replaced.

**Table 8. Fan Motor Control Voltage Inputs**

Input	Thermostat Demand	Voltage Present
ECM/Y1 and ECM C (Low Stage)	YES	24VDC
	NO	NONE
ECM/Y1 - ECM/Y2 and ECM C (High Stage)	YES	24VDC at each input
	NO	NONE at each input
ECM/Y2 and ECM C (EDA Operation)	YES	24VDC
	NO	NONE
EXT ECM/R and ECM C	YES	24VAC
	NO	NONE

**Table 9. Fan Motor Control (A177) Flash and Pause Durations — XC21-XXX-230-05 AND LATER**

Flash or Pause State	Duration
Flash Flash	Three flashes per second
Slow Flash	One flash per second
Short Pause	Two seconds of OFF time.
Long Pause	Five seconds of OFF time.

**Table 10. Fan Motor Control Error/Fault LED Codes — XC21-XXX-230-05 AND LATER**

Unit Status	Fan Motor Control LED	Possible Cause
Mismatched RPM	Fast Flash with no pause	Internal feedback, PWM does not match target.
CRC Failure	Constant ON.	Microcontroller CRC failure.

**Table 11. Fan Motor Control Stage Operation LED Indicator Codes — XC21-XXX-230-05 AND LATER**

Unit Status	Unit Status	Fan Motor Control LED
Two Stage Operation	Low Stage — ECM1/Y1 ONLY	One slow flash, then short pause.
	High Stage — ECM1/Y1 and ECM2/Y2	Two slow flash, then short pause.
	EDA Operation — ECM2/Y2 ONLY	Three slow flash, then short pause.

**Table 12. Two Stage — Fan Motor Control RPM Jumper Settings, LED RPM Indicator and P2 DC Voltage Outputs — XC21-XXX-230-05 AND LATER**

Application	CFM Profile Pin Select				Low Stage — ECM1/Y1 Only			High Stage — ECM1/Y1 and ECM2/Y2			EDA Operation — ECM2/Y2 Only		
	4	3	2	1	RPM	LED Code	DC Volt	RPM	LED Code	DC Volt	RPM	LED Code	DC Volt
XC21-024	ON	ON	OFF	OFF	475	6	15.1	550	8	17.6	200	3	6.3
XC-036	ON	OFF	ON	ON	525	7	16.8	600	8	19.2	225	3	7.0
XC21-048 and XC21-060	ON	OFF	OFF	ON	600	8	19.2	675	9	21.6	225	3	7.0

\* LED Code indicates Fan Motor Control LED flash sequence. For example, LED Code 9 indicates 9 slow flashes and pause.




Figure 6. Fan Motor Control One/Two Stage and EDA LED Sequence of Operation — XC21-XXX-230-05 AND LATER




Figure 7. Fan Control, Wiring, Jumper Settings, Testing and LED Location — XC21-XXX-230-05 AND LATER




Figure 8. Testing for External Power to Fan Motor Control — XC21-XXX-230-05 AND LATER

## Fan Motor (B4) Test Procedure

A simple test can be used to test the fan motor operation. A fully charged 9V battery will be required for this procedure.

# FAN MOTOR TEST

THIS IS A TEST THAT WILL VERIFY THAT THE MOTOR DOES OPERATE.

1. VERIFY MAIN (240 VOLT) POWER IF **OFF** TO UNIT.
2. REMOVE BOTH WIRES (BROWN AND BLACK) FROM THE J2 TERMINAL ON THE FAN MOTOR CONTROL (A177).
3. ROOM THERMOSTAT SHOULD BE IN **OFF** POSITION (UNIT IN IDLE MODE - NO HEATING OR COOLING DEMANDS)
4. TURN MAIN POWER (240 VOLT) **ON** TO UNIT.
5. CONNECT 9 VOLT BATTERY TO FAN MOTOR PLUGS AS NOTED IN PICTURE BELOW.
6. FAN MOTOR SHOULD RUN AT A REDUCED FAN SPEED.
7. IF FAN MOTOR DOES NOT RUN, THEN REPLACE FAN MOTOR ASSEMBLY.






Figure 9. Fan Motor (B4) Test — XC21-XXX-230-05 AND LATER



**TOP GRILLE OR FAN MOTOR MOUNT ADJUSTMENT FOR FAN CLEARANCE**

Sometimes during shipping, either the fan motor mounting or top grille may become out of alignment. This may cause the fan motor blade to not clear the orifice ring. If this situation occurs, simply adjust either or both the fan motor mount or top grille positions to allow proper clearance. The top grille four fastener insertion points to the plastic top and motor mount locations are larger than the fasteners used to secure the grille and fan motor mounts. Use the procedures provided in figure 10 to adjust for fan clearance.



**Figure 10. Fan Blade Clearance Adjustment — XC21-XXX-230-05 AND LATER**

# AIR CONDITIONER CONTROL (A175) UNIT NOMINAL CAPACITY CODE CONFIGURATION

In a communicating system, the unit capacity code must be configured if the room thermostat is indicating either an

alert code 313, *indoor and outdoor unit capacity mismatch error code*, or alert code 34, *must program unit capacity for outdoor unit*. Use figure 11 to configure the unit normal capacity code.




Figure 11. Main Control (A175) Unit Nominal Capacity Code Configuration (XC21-XXX-230-04 and 05)


**FAN MOTOR SURGE PROTECTION  
(XC21-XXX-230-05 MODELS ONLY)**

**Surge Protector** - Metal Oxide Varistor (MOV) - A component designed to protect electrical devices from voltage spikes that are 3-to-4 times the normal circuit voltage (see figure 12 for illustration of component).

A MOV is essentially a batch of metallic-oxide grains separated by insulating layers. Repeated voltage surges break down the insulating layers, lowering the overall resistance and eventually causing the device to draw too much current and trip whatever over-current protection is inherent in the system)

**MOV Check:** They are supposed to be located beyond the line fuse (though possibly not always). In this case, where the line fuse blows or circuit breaker trips but there is no visible damage to the MOV(s), the simplest test may be to just temporarily remove the MOV(s) and see if the problem goes away.

See figure 1 for location of the surge protections device in the unit control box area.



**Figure 12. Fan Motor Surge Protection Device  
(XC21-XXX-230-05 models only)**

# Jumper and Link Settings (103369-01 and -02)

## Communication System

The jumper settings and link are default settings and ONLY control system operation if configuration settings in the iComfort™ thermostat are not available.


The Lennox iComfort™ thermostat must be used in communicating applications.

## Non-Communicating System

The unit will operate based on jumper settings and R TO DS link on the MAIN CONTROL. All unit setting changes must be done at the MAIN CONTROL. The Lennox ComfortSense® 7000 thermostat may be used, as well as other non-communicating electronic-only thermostats.

**NOTE** — Fan cycling routine when activated will cycle the fan ON for five minutes if the outdoor ambient air temperature is between 15°F and 35°F and the compressor has been OFF for 25 to 30 minutes. This option is to help reduce the potential for ice build up on the orifice ring during system OFF cycles that are greater than 25 to 30 minutes.

Set up of jumpers on replacement outdoor control.



### J3 ALL UNITS)

FAN CYCLING

JUMPER ON  
FAN ON FOR 5 MINUTES

JUMPER OFF  
DISABLE (DEFAULT)

SEE NOTE ABOVE FOR FURTHER DETAILS.

### J1 (HP ONLY)

DEFROST TERMINATION TEMPERATURE

100 DEGREE TARGET

90 DEGREE TARGET

70 DEGREE TARGET

50 DEGREE TARGET (DEFAULT)

(DEFAULT WHEN JUMPER IS REMOVED OR MISSING)

### DS TO R TWO-STAGE UNIT ONLY)

Cut for Humiditrol® - Enhanced Dehumidification Accessory (EDA) applications.

NOTE - LINK NOT APPLICABLE TO ONE-STAGE UNITS. CUTTING LINK WILL HAVE NO AFFECT ON OPERATION OF ONE-STAGE UNITS.

### (HP ONLY) J4

COMPRESSOR SHIFT DELAY

30 SECOND DELAY (DEFAULT)

0 SECOND DELAY

### (TWO-STAGE HEAT PUMP ONLY) J2

SECOND-STAGE LOCK-IN TEMPERATURE

55 DEGREE TARGET

50 DEGREE TARGET

45 DEGREE TARGET

40 DEGREE TARGET (DEFAULT)

## MANDATORY CONFIGURATION REQUIREMENTS — HEAT PUMP CONTROL — TWO-STAGE OPERATION


1. Set defrost termination temperature (J1) to ensure a completely clear coil before termination of defrost. Low outdoor temperatures could require higher defrost termination temperature setting. Factory default setting is 50°F. If jumper is removed or missing, default is 90°F.

**IMPORTANT** — All mandatory configuration requirements (jumpers and link) MUST be completed prior to starting unit.

2. Second-stage lock-in factory default setting for J2 is 40°F. If jumper is removed or missing, default is OFF.

Figure 13. Jumpers and Links (Outdoor Control Part Numbers 103369-01 and -02)

# Jumper and Link Settings (103369-03)



## J1 - DEFROST TERMINATION TEMPERATURE

- The J1 jumper is factory-set to 50°F (10°C). This jumper can be repositioned to terminate defrost at 70°F, 90°F or MAX ( 21°C, 32°C and MAX). If there is no jumper on J1, the default termination temperature is 90°F(32°C).

NOTE - Colder climates may require a higher defrost termination temperature to maintain a clear coil.

- If the J1 jumper is set to MAX, defrost will run maximum defrost sequence.


## J3 - DEFROST AUTO

- Defrost Auto can be set to either ON or OFF. Factory setting is OFF.

Note: If the jumper is missing the default is OFF.

- Defrost Auto is set to OFF, the defrost cycle will run and terminate based on J1 setting.
- Defrost Auto is set to ON, the defrost termination will be determined based on the following rules:
  - The first defrost after the unit is powered up, or the first defrost after cooling call, will terminate based on the J1 setting.
  - The accumulated heating run-time between defrost cycles:
    - If the heating run time between defrost cycles is less than 50 minutes, the defrost termination temperature will be increased for the next defrost cycle based on the current termination setting. If the current termination setting is 50°F or 70°F, then the next defrost termination will be 90°F. If J1 is set at 90°F or MAX, the next defrost cycle will terminate at the MAX setting.
    - If the heating run time between defrosts is longer than 1 hour for 2 consecutive heating cycles and the termination temperature is set at 50°F, 70°F, or 90°F, then the defrost control will follow the J1 jumper setting during the next defrost cycle. If the J1 jumper is set to MAX, then the next defrost termination temperature will be decreased to 90°F.
  - If J1 is set to MAX, the system will always run at MAX when accumulated compressor OFF time is longer than 30 minutes and ambient temperature is less than 35°F.
  - When the ambient sensor temperature is higher than 40°F and J1 is set to MAX, defrost termination will be 90°F. If J1 is 50°F, 70°F, or 90°F, defrost termination will follow the J1 setting.

## Normal Defrost Sequence



## Maximum Defrost Sequence







Figure 14. Jumpers and Links (Outdoor Control Part Number 103369-03)



**(\*) Maximum Defrost Sequence**



**(\*\*) Normal Defrost Sequence**



Note: If the defrost terminates by reaching the maximum allowed defrost time, it is not considered a successful defrost and the unit will enter defrost again after 30 minutes of compressor heating run time with the coil sensor below 35F

**Figure 15. Defrost Auto Selection and Max Defrost Sequence of Operations (Outdoor Control Part Number 103369-03)**




Figure 16. Demand Defrost - MAX Defrost (Outdoor Control Part Number 103369-03)

## 103369-01, -02 and -03 Configuring Unit

For the new outdoor control to work correctly, it **MUST BE** programmed for unit type (AC or HP and number of stages), unit capacity and outdoor fan profile (RPM). The new outdoor control has an auto-detection feature that will determine the unit type. The following set up procedures **MUST** be done on all new outdoor controls.

### Auto-Detection of Unit Type (air conditioner or heat pump and number of stages)

During initial power-up the control will auto-detect the unit type. The unit type is determined by what is connected to various outputs on the new control.

The unit capacity and fan speed are manually configured. Until those parameters are configured the 7-segment display will show 3 bars for the unit capacity and fan speed.




SEVEN-SEGMENT DISPLAY

PUSH BUTTON

- Anytime there is a connection to **O OUT** terminal, the control will detect the unit type as a heat pump.
- Anytime there is no connection to **O** terminal, the control will detect the unit type as a air conditioner.

- Anytime there is a connection to **Y2 OUT** terminal, the control will detect the unit as two-stage.
- Anytime there is no connection to **Y2** terminal, the control will detect the unit as one-stage.

If the control auto-detects the unit type incorrectly it may be due to the control being miswired, loose connection or missing connection to the required control output terminal. Disconnect power to the control, verify connections, correct wiring and reconnect power. Verify that the correct unit type is displayed on the seven-segment display.




**OUTDOOR CONTROL**



# Configuring Unit Type

During initial power-up the control will auto-detect the unit type. The unit type is automatically determined by what is connected to **Y2 OUT** and/or **O OUT** on the control. The unit type can be permanently stored in the control's memory by manually configuring the unit type using the following procedure. Typically the capacity and fan speed will not be configured and will display the three dashes for each. For manual configuration of the unit type, proceed as indicated.



Outdoor control is in **IDLE mode** (No heating or cooling demand)

Yes

No

To enter **unit type configuration**, push and hold button next to single character display until **dash** symbol appears and immediately release button. Once dash starts blinking, proceed to next step.

Push and hold button until the solid **Pt** sequence is displayed on the seven-segment display and then immediately release the button.

[This configuration sequence allows the installer to select a unit type (number / letter combination) that matches the outdoor type and number of stages.]

Press and hold the button during the **Pt** cycling display.

[The **Pt** sequence will repeat 5 times and if a selection is not made the control will return to idle mode.]

- |                              |                           |
|------------------------------|---------------------------|
| Unit Type / Number of Stages |                           |
| 1AC                          | One stage air conditioner |
| 2AC                          | Two stage air conditioner |
| 1HP                          | One stage heat pump       |
| 2HP                          | Two stage heat pump       |

1. When the correct unit type is displayed, release button immediately. [Display will start flashing]
2. Push and hold button until selection stops flashing during one of the three cycles. [Release the button]
3. If selection is not made during those three cycles the control will return to idle mode.

NOT SELECTED

SELECTED

The outdoor control will store unit type in memory and will automatically exit the configuration and reset control.

If three horizontal bars display in any part of the 7-segment string during power up, the outdoor control did not store that configuration. (Unit type, capacity or fan RPM. If this happens, the configuration sequence for that section of the string must be repeated.


During power up of the outdoor control, the seven-segment display will show the stored number of stages unit type, capacity and outdoor fan speed.

2 H P PAUSE 3 6 PAUSE 1 2

TWO STAGE HEAT PUMP      CAPACITY (3-TON)      FAN PROFILE

# Configuring Unit Capacity or Fan Profile

**Power-up** - Unit capacity (two-digit number) and displayed represents unit size code (outdoor unit capacity). During initial power up, the number of stages / unit type, unit capacity and outdoor fan speed will appear on the 7-segment display. If three horizontal bars display in any part of the 7-segment display string during power-up, the outdoor control did not store that configuration (unit type, capacity or fan RPM). If this happens, the configuration sequence for that section of the string must be repeated.



Outdoor control is in **IDLE** mode (No heating or cooling demand)

To enter **unit capacity or fan profile configuration**, push and hold button next to single character display until **dash** symbol appears and immediately release button. Once dash starts blinking, proceed to next step.

Push and hold button until the solid **PC** or **PF** sequence is displayed on the seven-segment display and then immediately release the button. This configuration sequence allows the installer to select a unit type (number / letter combination) that matches the outdoor unit type and number of stages.



**UNIT CAPACITY**  
**FAN PROFILE**

Either the **PC** or **PF** sequence will repeat 5 times and if a selection is not made the control will return to idle mode. Press and hold the button during the **PC** or **PF** cycling display.

**Unit Capacity Code**

12	1-TON
18	1-1/2-TON
24	2-TON
30	2-1/2-TON
36	3-TON
42	3-1/2-TON
48	4-TON
60	5-TON

**Fan Profile Code (see notes)**  
SEE NOTE 1




- When the correct unit capacity or fan profile is displayed, release button immediately. [Display will start blinking]
- Push and hold button until selection stops flashing during one of the three cycles. [Release push button]
- If selection is not made during those three cycles the control will return to idle mode.

**NOTES**

- Determine fan motor-type (EBM or ECM).
- Units with EBM motors** - The fan motor RPM must be field set or three bars will appear in the fan profile string section of the 7-segment display. The factory default is 700 RPM.
- Units with ECM motors** - The fan motor RPM is factory set and can not be adjusted. The ECM motor speed (fan profile) string will not appear on the 7-segment display. The fan profile displayed is applicable only to EBM fan motor applications.

If three horizontal bars display in any part of the 7-segment display string during power-up, the outdoor control did not store that configuration (unit type, capacity or fan profile). If this occurs, the configuration sequence for that section of the string must be repeated.



**Table 13. Fan RPM Profiles for EBM Motors**



**EBM FAN/MOTOR ASSEMBLY**

Fan RPM Profile	Model Number	Stage 1 PWM %	Stage 1 RPM	Stage 2 PWM %	Stage 2 RPM	EDA Stage PWM %	EDA Stage RPM
0	XC/XP17-024	55	400	55	400	55	400
1	XC/XP17-030	62	450	62	450	62	450
2	Not assigned	69	500	69	500	69	500
3	Not assigned	71	550	76	550	71	550
4	XC/XP17-036 and -042	83	600	83	600	83	600
5	Not assigned	90	650	90	650	90	650
6	XC/XP17-048 and -060	92	675	92	675	92	675
7	Not assigned	97	700	97	700	97	700
8	Not assigned	48	350	55	400	27	200
9	Not assigned	55	400	62	450	27	200
10	XP21-024	58	425	69	500	27	200
11	XC21-024	65	475	76	550	27	200
12	XC/XP21-036	72	525	83	600	30	225
13	Not assigned	79	575	90	650	30	225
14	XC21-048, - 060 and XP21-048	83	600	92	675	30	225
15	XP21-060	86	625	97	700	30	225

**Table 14. Fan RPM for ECM Motors**



**ECM MOTOR**

Model Number	Stage 1 RPM	Stage 2 RPM	EDA Stage RPM
XP17N-XX-230-01	700	N/A	250
XP19-XX-230-06	700	825	250
XC21-XX-230-04			
XP21N-XX-230-01			

## Seven-Segment Alert and System Status Codes

Alert codes are displayed using the seven-segment display located on the outdoor control.

**NOTE** — System fault and lockout alarm code displays takes precedence over system status (cooling, heating stages or defrost/dehumidification).

The seven-segment will display an abnormal condition (error code) when detected in the system. A list of the codes are shown in table 15.

### RESETTING ALERT CODES

Alert codes can be reset manually or automatically:

#### 4. Manual Reset

Manual reset can be achieved by one of the following methods:

- Disconnecting **R** wire from the main control's **R** terminal.
- Turning the indoor unit off and back on again

After power up all existing codes are cleared.

#### 5. Automatic Reset

After an alert is detected, the main control continues to monitor the unit's system and compressor operations. When/if conditions return to normal, the alert code is turned off automatically.

**Table 15. Seven-Segment Display Alert Codes**

**NOTE** — System fault and lockout seven-segment display alarm codes takes precedence over system status codes (cooling, heating stages or defrost/dehumidification). Only the latest active fault or lockout alarm code if present will be displayed. If no fault or lockout codes are active, then system status are routinely displayed.




Alert Codes	Alarm Description	Possible Causes and Clearing Alarm
E 105	The outdoor unit has lost communication with the rest of the system.	Equipment is unable to communicate. This may indicate the existence of other alarms / codes. In most cases errors are related to electrical noise. Make sure high voltage power is separated from RSBUS. Check for mis-wired and/or loose connections between the stat, indoor unit and outdoor unit. Check for a high voltage source of noise close to the system. This is a self-recoverable error.
E 120	There is a delay in the outdoor unit responding to the system.	Typically, this alarm/code does not cause any issues and will clear on its own. The alarm / code is usually caused by a delay in the outdoor unit responding to the thermostat. Check all wiring connections. Cleared after unresponsive device responds to any inquiry
E 124	The iComfort™ thermostat has lost communication with the outdoor unit for more than 3 minutes.	Equipment lost communication with the thermostat. Check the wiring connections, ohm wires and cycle power. The alarm stops all associated HVAC operations and waits for a heartbeat message from the unit that's not communicating. The alarm / fault clears after communication is re-established.
E 125	There is a hardware problem with the outdoor unit control.	There is a control hardware problem. Replace the outdoor control if the problem prevents operation and is persistent. The alarm / fault is cleared 300 seconds after the fault recovers
E 126	There is an internal communication problem with the outdoor unit control.	There is an internal hardware problem on the control. Typically the control will re-set itself. Replace the control if the problem prevents operation and is persistent. The alarm / fault is cleared 300 seconds after the fault recovers.
E 131	The outdoor unit control parameters are corrupted	Reconfigure the system. Replace the control if heating or cooling is not available
E 180	The iComfort™ thermostat has found a problem with the outdoor unit's ambient sensor.	In normal operation after outdoor control recognizes sensors, the alarm will be sent if valid temperature reading is lost. Compare outdoor sensor resistance to temperature/resistance charts in unit installation instructions. Replace sensor pack if necessary. At the beginning of (any) configuration, furnace or air-handler control will detect the presence of the sensor(s). If detected (reading in range), appropriate feature will be set as 'installed' and shown in the iComfort™ thermostat 'About' screen. The alarm / fault will clear upon configuration, or sensing normal values.
E 345	The <b>O</b> relay on the air-handler or outdoor unit has failed. Either the pilot relay contacts did not close or the relay coil did not energize.	<b>O</b> relay / stage 1 failed. Pilot relay contacts did not close or the relay coil did not energize. Replace control. Fault clears after a power reset.
E 401	Either the compressor ran for more than 18 hours continuously.	Compressor ran more than 18 hours to satisfy a single thermostat demand. If the unit is 2-stage, the high-speed will lock-out and the unit will run at low-speed. If it is a HP and ODT <65°F, the system will not raise an alarm. Confirm that the system is properly charged with refrigerant. Check for stuck reversing valve, excessive cooling load and properly sized equipment. Confirm that the evaporator coil is clean. The alarm clears after 30 consecutive normal run cycles or a power reset.
E 403	The compressor ran for less than 3 minutes to satisfy a thermostat demand (short-cycling)	Compressor running five (5) consecutive cycles of less than four (4) minutes. Code will automatically reset once the compressor has completed a cycle longer than 4 minutes.
E 409	The secondary voltage for the outdoor unit has fallen below 18VAC. If this continues for 10 minutes, the system will shut down.	Secondary voltage is below 18VAC. After 10 minutes, operation is discontinued. Check the indoor line voltage, transformer output voltage. The alarm clears after the voltage is higher than 20VAC for 2 seconds or after a power reset.

**Table 16. Seven-Segment Display Alert Codes (continued)**

E 410	The outdoor unit cycled off due to low pressure switch opening.	Unit pressure is below the lower limit. The system is shut down. The low pressure switch for HFC-410A closes above 90PSIG and opens below 40PSIG. Confirm that the system is properly charged with refrigerant. Check TXV, indoor unit blower motor, dirty filters or clogged refrigerant filter. Confirm that the evaporator coil is clean. The alarm clears after the pressure switch closes or after a power reset
E 411	The low pressure switch has opened 5 times during one cooling cycle. As a result, the system will shutdown.	Open low pressure switch error count reached 5 strikes. The low pressure switch for R410A will open at 40PSIG and close at 90PSIG. Confirm that the system is properly charged with refrigerant. Check TXV, indoor unit blower motor, dirty filters or clogged refrigerant filter. Confirm that the evaporator coil is clean. The alarm clears after a power reset
E 412	The outdoor unit pressure is above the required limit. The system will shut down.	Unit pressure is above the upper limit. System is shut down. The high pressure switch for HFC-410A will open at 590PSIG and close at 418PSIG. Confirm that the system is properly charged with refrigerant. Check condenser fan motor, TXV, indoor unit blower motor, stuck reversing valve or clogged refrigerant filter. Confirm that the outdoor unit is clean. The alarm clears after 4 consecutive normal compressor run cycles, the pressure switch closes or a power reset
E 413	The high pressure switch has opened 5 times during one cooling cycle. As a result, the iComfort™ thermostat will shutdown.	Open high pressure switch error count reached 5 strikes. System is shut down. The high pressure switch for HFC-410A will open at 590PSIG and close at 418PSIG. Confirm that the system is properly charged with refrigerant. Check condenser fan motor, TXV, indoor unit blower motor, stuck reversing valve or clogged refrigerant filter. Confirm that the outdoor unit is clean. The alarm clears after a power reset.
E 414	The discharge line temperature is higher than the recommended upper limit of 279°F.	Discharge line temperature is > 279°F. Confirm that the system is properly charged with refrigerant. Check system operating pressures and compare to unit charging charts in installation manual. Confirm that the outdoor unit is clean. The alarm clears after the discharge temperature is < 225°F.
E 415	The discharge line temperature has been consistently higher than the recommended upper limit of 279°F.	Discharge line high temperature error count reached 5 strikes. Confirm that the system is properly charged with refrigerant. Check system operating pressures and compare to unit charging charts in installation manual. Confirm that the outdoor unit is clean. The alarm clears after the discharge temperature is < 225°F. The alarm clears after a power reset.
E 416	The outdoor coil sensor is either open, short-circuited or the temperature is out of sensor range. As a result the outdoor unit control will not perform any defrost tempering.	Coil sensor being detected open or shorted, or temperature is out of coil sensor range. Outdoor unit control will not perform demand or time/temperature defrost operation. System will still heat or cool. Check the resistance of the coil sensor and compare to temperature resistance chart. Replace coil sensor if needed. The alarm clears when outdoor unit control detects proper coil sensor readings or after a power reset.
E 417	The outdoor unit discharge sensor is either open, short-circuited or the temperature is out of sensor range. As a result the outdoor unit control will not perform any defrost tempering.	Outdoor unit control detects open or shorted discharge sensor, or temperature that is out of discharge sensor range. Check the resistance of the discharge sensor and compare to temperature resistance chart - replace if needed. Reset by replacing the discharge sensor. This fault is detected by allowing the unit to run for 90 seconds before checking discharge sensor resistance. If the discharge sensor resistance is not within range after 90 seconds, the board will count one fault. After 5 faults, the board will lock out. Check for proper sensor reading and attachment to line. The alarm clears after a power reset.
E 418	There is a faulty <b>W</b> output circuit.	<b>W</b> terminal is energized <b>while in cooling mode</b> . Possible cause may be a stuck closed relay on the control, or something external to the control that is energizing W terminal when it should not be energized. Solution: Disconnect any wiring from the W terminal. If 24 volts is still on the terminal, then it is a stuck relay. If the 24 volts disappears, then there is a need to check any of the wires hooked up to the W terminal.
E 419	The <b>W</b> output on the outdoor unit has reported more than 5 errors. As a result, the system has shutdown the outdoor unit.	The <b>W</b> output (code E418) on the outdoor unit has reported more than 5-strikes. As a result, the system has shut-down the outdoor unit. Disconnect thermostat lines from W and verify 24VAC on the W. If 24VAC is present, replace the control.
E 420	The heat pump defrost cycle has taken more than 20 minutes to complete.	Defrost cycle lasts longer than 20 minutes. This alarm is applicable with non-communicating heat pump system only. Check heat pump defrost operation. The alarm is cleared after the "W1" signal is removed.
E 421	The <b>W</b> output terminal on the outdoor unit is not wired correctly.	Voltage sensed on <b>W</b> and <b>O</b> when <b>Y1</b> thermostat input is deactivated. Another device or wiring fault is energizing <b>W</b> Check wiring. The alarm clears when wiring is corrected or after a power reset.

*NOTE — Additional codes may be found in iComfort™ thermostat manual.*

**Table 17. Outdoor Control Seven-Segment Unit Status Displays**

Description	Example of Display
<p><b>Power up / Reset:</b> Unit type and number of stages is displayed. Verify configuration with information published on the unit name-plate. If the information is incorrect, refer to flow chart <i>Manually Configuration of Unit Type</i> to re-configure control.</p>	<p>1 Stage AC: <b>1AC</b>                      2 Stage AC: <b>2AC</b>                      1 Stage AC: <b>1HP</b>                      1 Stage AC: <b>2HP</b></p> <p>POWER-UP 7-SEGMENT DISPLAY STRING</p> 
<p><b>Power up / Reset following display of self-discovered configuration:</b> Unit nominal capacity is displayed, if not programmed then three horizontal lines and the decimal point are displayed for 2 seconds.</p>	<p>Power up nominal capacity display of an XP21-036: <b>36</b></p> <p>POWER-UP 7-SEGMENT DISPLAY STRING</p> 
<p><b>Power up / Reset following display of nominal capacity:</b> Fan Profile code. (a single or two digit number) See table 13 for applicable fan RPM profile.</p>	<p>Displays the number of the selected fan profile. <b>3</b></p> <p>POWER-UP 7-SEGMENT DISPLAY STRING</p> 
Description	Example of Display
<p><b>Idle Mode:</b> Decimal point blinks at 1 Hz</p>	<p>Idle Mode: Decimal point blinks at 1 Hz (0.5 second on, 0.5 second off). Display OFF.</p>
<p><b>Soft Disabled:</b> Top and bottom horizontal line and decimal point blink at 1 Hz.</p>	<p>Soft Disabled: Top and bottom horizontal line and decimal point blink at 1 Hz (0.5 second on, 0.5 second off). Note: Control should be replace.</p>
<p><b>O.E.M test mode</b></p>	<p>All segments flashing at 2 Hz (unless error is detected) Note: Control should be replace.</p>
<p><b>Anti-Short Cycle Delay</b></p>	<p>Middle line shall blink at 1 Hz for 2 seconds, followed by a 2 second display of the rounded up number of minutes left in the timer (2 minutes 1 second shall be displayed as "3"). The Anti-Short Cycle Delay time remaining is displayed whenever the delay is active.</p>
<p><b>Cooling Stage:</b> Shows what stage of cooling is currently operating.</p>	<p>Following string is repeated if second stage cooling is active with outdoor fan speed set at 700 RPM. Note: <b>A</b> - If available, displays outdoor ambient temperature.</p> <p>C 2 pause F 7 0 0 pause</p>
<p><b>Heat Pump Stage:</b> Shows what stage of heat pump is currently operating.</p>	<p>Following string is repeated if first stage heat pump is active with outdoor fan speed set at 600 RPM. Note: <b>A</b> - If available, displays outdoor ambient temperature.</p> <p>H 1 pause F 6 0 0 pause</p>
<p><b>Defrost Mode:</b> Shown only while in an active defrost.</p>	<p>Following string is repeated if defrost is active while unit was in 1<sup>st</sup> stage heat pump heating mode:</p> <p>d F pause H 1 pause</p>
<p><b>Dehumidification mode:</b> Shows that the unit is providing dehumidification instead of straight cooling.</p>	<p>Following string is repeated if dehumidification is active with outdoor fan speed set at 225 RPM:</p> <p>d pause F 2 2 5 pause</p>
<p><b>Diagnostic recall:</b> Shows the last 10 stored diagnostic error codes.</p>	<p>If first error is E250, second E231: E pause 2 5 0 pause E pause 2 3 1</p> <p>Next codes (up to 10) are show using same method.</p>
<p><b>Fault Memory clear</b></p>	<p>If there is no error codes stored. E pause 0 0 0                      After the fault memory is cleared following string is displayed with 0.5 seconds character on/off time:</p> <p>0 0 0 0 pause</p>

**Table 8. Outdoor Control Seven-Segment Unit Status Displays (continued)**

<b>Active error in outdoor control Idle mode:</b> Shown all active error(s) codes.	Following string is repeated if Error E125 and E201 are present: <i>E 1 2 5</i> pause <i>E 2 0 1</i>
<b>Active error in run mode:</b> Shown current status and all active error(s) codes.	Following string is repeated if Error E311 is present while blower speed at 700RPM: <i>F 7 0 0</i> pause <i>E 3 1 1</i>
<b>Outdoor Ambient Temperature (OAT):</b> Any time OAT is sensed in operating range value is displayed if unit is in diagnostic and non-diagnostic modes.	Following string is repeated if second stage cooling is active with outdoor fan speed set at 650 RPM and OAT is 104°F: <i>C 2</i> pause <i>F 6 5 0</i> pause <i>A 1 0 4</i> pause
<b>Outdoor Coil Temperature (OCT):</b> Any time OCT is sensed in operating range value is displayed if unit is in diagnostic mode.	Following string is repeated if 2nd stage heat is active with outdoor fan speed set at 550 RPM and OCT is 25° F: <i>H 2</i> pause <i>F 5 5 0</i> pause <i>c 2 5</i> pause
<b>Discharge Line Temperature (DIS):</b> Any time DIS is sensed in operating range value is displayed if unit is in diagnostic mode.	Following string is repeated if 2nd stage cooling is active with outdoor fan speed set at 650 RPM and DIS is 185° F: <i>C 2</i> pause <i>F 6 5 0</i> pause <i>d 1 8 5</i> pause

**Table 18. Error Recall Menu Options**

Error Code Recall Mode (Note - control must be in idle mode)		
<b>Solid</b>	<i>E</i>	To enter error code recall mode, push and hold button until solid <b>E</b> appears, then release button. Control will display up to 10 error codes stored in memory. If E000 is displayed, there are no stored error codes.
<b>Solid</b>	- - -	To exit error code recall mode push and hold button until solid three horizontal bars appear, then release button. Note - Error codes are not cleared.
<b>Solid</b>	<i>c</i>	To clear error codes stored in memory, continue to hold push button while the 3 horizontal bars are displayed. Release push button when solid <b>c</b> is displayed.
<b>Blinking</b>	<i>c</i>	Hold push button for three seconds to confirm command to delete codes. Error codes are cleared.

\*Note once the error history is deleted it cannot be recovered. After the history is deleted, the unit will reset itself.

**Table 19. Field Test and Program Menu Options**

Display	Display and action (normal operation)	Display and action (configuration and test mode)
<b>Power -UP</b>	Display string displays > number of unit stages > pause > <i>AC</i> or <i>HP</i> unit > pause > unit capacity in BTUs > pause > RPM setting of outdoor fan. If 3 horizontal bars are displayed during any sequence of this string, it indicates that the specific parameter is not configured.	
-	Idle mode — decimal blinks at 1 Hertz > 0.5 second ON, 0.5 second OFF	
<i>A</i>	<i>A</i> in the display string represents the ambient temperature in °F at the outdoor sensor on the outdoor unit.	Enter <i>A</i> test mode: Display will string active error code(s) <i>E</i> , ambient <i>A</i> , coil <i>c</i> and discharge <i>d</i> temperature in °F at outdoor unit.
<i>d</i>	<i>d</i> - dehumidification mode string > <i>d</i> pause > <i>F</i> (Outdoor fan) RPM > pause > <i>A</i> (ambient temp displayed) > pause > repeat mode. <b>IMPORTANT:</b> On 2-stage unit R to DS link must be cut and correct RPM outdoor fan profile selected for outdoor fan to operate at lower RPM speed when EDA is active.	Enter <i>d</i> test mode: Forced defrost. (System must be configured as HP. Unit must be running in heating mode). Test defrost will terminate when coil terminate temperature is reached (or 10 seconds, whichever is longer) or 14 minutes if coil temperature remains below terminate temperature or by pushing button down for less than 2 seconds. Enter <i>A</i> test mode: Display will string active error codes <i>E</i> , ambient <i>A</i> , coil <i>c</i> and discharge <i>d</i> temperature in °F at outdoor unit.
<i>d F</i>	<i>d F</i> displays when system is in defrost mode - unit must be running in heating mode, outdoor ambient must be below 65°F and outdoor coil temperature must be below defrost termination temperature.	
<i>F</i>	<i>F</i> in the display string indicates RPM setting output on terminals PWM and com (used with EBM motors). RPM displayed does not apply to motor connected on ECM Y1 and ECM Y2.	Enter <i>F</i> test mode: Control outputs DC Voltage onto PWM and com terminals. Outdoor fan will cycle ON for 10 minutes at 490 RPM. To exit test - Push and hold button until three horizontal bars display. Release button, outdoor fan will cycle OFF. (Test DOES NOT output DC voltage to ECM Y1 and ECM Y2 terminals)
<i>H 1</i>	Heat stage 1 string display > pause > <i>F</i> outdoor fan RPM displayed > pause > <i>A</i> (ambient temperature displayed > pause > repeat mode.	
<i>H 2</i>	Heat stage 2 string display > pause > <i>F</i> outdoor fan RPM displayed > pause > <i>A</i> ambient temperature displayed > pause > repeat mode.	

**Table 20. Field Test and Program Menu Options (continued)**

Display	Display and action (normal operation)	Display and action (configuration and test mode)
Ⓒ 1	Cool stage 1 string display > pause > F outdoor fan RPM displayed > pause > R (ambient temperature displayed > pause > repeat mode.	
Ⓒ 2	Cool stage 2 string display > pause > F outdoor fan RPM displayed > pause > R (ambient temperature displayed > pause > repeat mode.	
<b>Configuring Outdoor Fan Speed (Note - Control must be in Idle Mode)</b>		
Display	Code	Procedure
<b>Solid</b>	PF	Release push button — Allows user to select outdoor fan RPM profile. <b>IMPORTANT:</b> New control may need to be manually configured to validate outdoor unit fan RPM setting is correct for unit capacity. Refer to RPM table on unit wiring diagram.
<b>Blinking</b>	PF	Push and hold button — Outdoor control will display a fan RPM profile 3 seconds. When the correct fan RPM profile is displayed, release button. Selected code will flash for a 10 second period. During that period, hold push button for 3 seconds to store code. Once code is stored control will automatically exit field test mode. If 10 second period expires or push button is held less than 3 seconds, control will automatically exit field test mode and go into idle mode without storing fan RPM profile. Repeat procedure to correct.
<b>Configuring Unit Capacity (Note - Control must be in Idle Mode)</b>		
<b>Solid</b>	PC	Release push button — Allows user to select Unit Capacity. <b>IMPORTANT:</b> Field replacement control may need to be manually configured to validate outdoor unit capacity. Refer to unit nameplate model number for capacity in 1,000 of BTUs. (18, 24, 30 ,36,42 48, 60)
<b>Blinking</b>	PC	Push and hold button — Control will display unit capacity number 3 seconds. When the correct unit capacity number is displayed, release button. Selected code will flash for a 10 second period. During that period, hold push button for 3 seconds to store code. Once code is stored control will automatically exit <i>Field Test Mode</i> . If 10 second period expires or push button is held less than 3 seconds, control will automatically exit field test mode and go into idle mode without storing unit capacity Number. If this happens, configuring procedure must be repeated.
<b>Solid</b>	PL	Release push button — Allows user to select type and number of stages on outdoor unit.. <b>IMPORTANT:</b> Field replacement control may need to be manually configured to validate outdoor unit fan RPM setting is right for unit capacity. See RPM table on unit wiring diagram for proper RPM settings. Type and number of stages: 1AC, 2AC, 1HP, 2HP – AC – air conditioning and HP – Heat Pump
<b>Blinking</b>	PL	Push and hold button — Control will display type and number of stages 3 seconds. When the correct type and number of stages is displayed, release button. Selected code will flash for a 10 second period. During that period, hold push button for 3 seconds to store code. Once code is stored control will automatically exit <i>field test mode</i> . If 10 second period expires or push button is held less than 3 seconds, control will automatically exit field test mode and go into idle mode without storing type and number of stages. If this happens, configuring procedure must be repeated.



# APPLICABLE TO ALL VERSIONS

## Compressor Information and Testing

The XC21 uses either a ZPSK4 or ZPSK5 depending on model number. See table 22 for applicable compressor use by model number.

### ELECTRICAL CHARACTERISTICS

Table 21 provides information concerning the electrical characteristics of both the ZPSK4 and ZPSK5 (single-phase).

**Table 22. Compressor Electrical Characteristics Comparison**

Lennox Model	Lennox Compressor Part Number	Copeland Model	Voltage	Phase	LRA	RLA	Minimum Circuit Ampacity	Max Fuse / Ckt Bkr	Run Capacitor	Start Kit
XC21-024-230-01 thru -07	100504-01	ZPS20K4E-PFV	208/230	1	52	10.3	14.9	25	35/5 370	63W22
XC21-024-230-08	103137-01	ZPS20K5E-PFV			58.3	11.7	20	25	35/5 440	10J42
XC21-036-230-01 thru -07	100504-02	ZPS30K4E-PFV			82	16.7	22.9	35	40/5 440	63W23
XC21-036-230-08	103137-02	ZPS30K5E-PFV			83	15.3	21.1	35	40/5 440	10J42
XC21-048-230-01 thru -07	100504-03	ZPS40K4E-PFV			96	21.2	28.5	45	45/10 440	10J42
XC21-048-230-08	103137-03	ZPS40K5E-PFV			104	21.2	28.5	45	30/5 440	12J90
XC21-060-230-01 thru -07, -09	100504-04	ZPS51K4E-PFV			118	25.7	34.1	50	80/7.5 440	63W24


### ELECTRICAL CHARACTERISTICS

External mechanical differences between the ZPS\*K4 and ZPS\*K5 are minimal. The suction and discharge tube height differences are less than 0.75". The ZPS40K5 compressor is 0.50" taller than the ZPS40K4. All other ZPS\*K5 compressors are shorter than the equivalent ZPS\*K4 compressor. The mounting configuration is the same for both compressor families. The compressor frame sizes are different and a smaller crankcase heater may be required. In addition, there are difference in mounting grommets because of the different frame sizes.

### K4 COMPRESSOR MODULATING SOLENOID


**SOLENOID PLUG (24VDC INPUT)**

These controls convert the 24 volt AC power to 24 Volt DC. The solenoid is pulled in with 24 volts DC and then the coil is held in by pulsing the voltage between 6 and 18 volts DC.




**SOLENOID PLUG (24VDC / 24VAC INPUT AND 24VDC OUTPUT)**

This control outputs 24VAC on Y2 and OUT. The plug on the compressor has a rectifier that converts the 24VAC to 24VDC. The solenoid is pulled in with 24VDC.




**Figure 17. K4 Compressor Modulating Solenoid**

## K5 COMPRESSOR MODULATING SOLENOID



Standard wiring without LSOM or iComfort™-enabled control with built-in LSOM



Wiring with the LSOM or iComfort™-enabled control with the built-in LSOM




Figure 18. K4 Compressor Modulating Solenoid

### COMPRESSOR INTERNAL SOLENOID (L34) TEST PROCEDURE

#### ⚠ IMPORTANT

When checking compressor for two-stage operation, always cycle Y1 to Y2 from terminals on the outdoor control integrated LSOM function to the room thermostat connections. **DO NOT** cycle second-stage (Y2) of compressor by unplugging the 24VDC solenoid input to the outdoor control integrated LSOM function (E34) end of plug. The outdoor control integrated LSOM function will only output a 6 to 18VDC signal which will be insufficient voltage to pull the solenoid coil in for second stage.

#### ⚠ IMPORTANT

This performance check is **ONLY** valid on systems that have clean indoor and outdoor coils, proper airflow over coils, and correct system refrigerant charge. All components in the system must be functioning proper to correctly perform compressor modulation operational check. (Accurate measurements are critical to this test as indoor system loading and outdoor ambient can affect variations between low and high capacity readings).

### Tools required

- Refrigeration gauge set
- Digital volt/amp meter
- Electronic temperature thermometer
- On-off toggle switch

### STEP A — Confirm low to high capacity compressor operation

#### Procedure


1. Turn main power **OFF** to outdoor unit.
2. Adjust room thermostat set point above (heating operation on heat pump) or below (cooling operation) the room temperature.
3. Remove control access panel. Install refrigeration gauges on unit. Attach the amp meter to the common (black wire) wire of the compressor harness. Attach thermometer to discharge line as close as possible to the compressor.
4. Cycle main power **ON**.
5. Confirm **Y1** operation only.
6. Allow pressures and temperatures to stabilize before taking any measured reading (may take up to 10 minutes).

7. Record all of the readings for the **Y1** demand on table 24.
8. Energize **Y2** demand.
9. Allow pressures and temperatures to stabilize before taking any measured reading (this may take up to 10 minutes).
10. Record all of the readings of **Y2** demand on table 24.
11. Compare Y1 to Y2 readings. Readings match table 24 the proper operation is verified. If readings do not match, proceed to **Step A**.

*NOTE — On new installations or installations that have shut down for an extended period of time, if the compressor does not cycle from low-stage to high-stage on the first attempt, it may be necessary to recycle the compressor back down to low-stage and back up to high-stage a few times in order to get the bypass seals to properly seat. It might be necessary to restrict the air flow over the indoor coil (heating) or outdoor coil (cooling) to maintain pressures high enough to determine pressure differences between low and high stages.*

**STEP 2 — Verify Compressor Solenoid has Correct Ohm Values.**

1. Turn main power **OFF** to outdoor unit (main power and low voltage).
2. Unplug the 2-pin solenoid plug from the fusite connection on the compressor.



**Figure 19. Testing**

**Figure 20. Solenoid Pins**

3. Using a multi-meter set on ohms, check the ohms valve of the solenoid coil in the compressor and compare the value to table 23.


**Table 23. Ohm Reading**

Compressor Family	Compressor Model	Solenoid Resistance	
ZPS*K4	All Models	33.6 Ω	
ZPS*K5		Source A	1640 Ω
		Source B	350 Ω

*NOTE - There are 2 ohm readings for the solenoids used in the ZPS\*K5 compressor.*

**STEP 3 — Verify solenoid plug has DC output voltage.**

1. Turn main power **OFF** to outdoor unit (main power and low voltage).
2. Unplug the 2-pin solenoid plug from the fusite connection on the compressor.
3. Turn main power **ON** and input a 2-stage demand to the outdoor unit.
4. Using the multi-meter set on DC volts, check the DC volt value at the plug-in after the five (5) second Y2 delay. Voltage at the plug connections should be between 18 and 28 VDC for non-LSOM applications and 4 to 9 VDC in LSOM applications.



**Figure 21. Testing**

Table 24. Two-Stage Modulation Compressor Field Operational Checklist

<b>Two-Stage Modulation Compressors Field Operational Checklist</b>			
<b>Unit Readings</b>	<b>Y1 - First Stage</b>	<b>Expected results during Y2 demand (Toggle switch On)</b>	<b>Y2 - Second Stage</b>
<b>COMPRESSOR</b>			
Voltage		Same	
Amperage		Higher	
<b>CONDENSER FAN MOTOR</b>			
Amperage		Same or Higher	
<b>TEMPERATURE</b>			
Ambient		Same	
Outdoor Coil Discharge Air		Higher	
Compressor Discharge Line		Higher	
Indoor Return Air		Same	
Indoor Coil Discharge Air		Lower	
<b>PRESSURES</b>			
Suction (Vapor)		Lower	
Liquid		Higher	

**Maintenance**

**OUTDOOR UNIT MAINTENANCE**

**Outdoor Unit**

Maintenance and service must be performed by a qualified installer or service agency. At the beginning of each cooling season, the system should be checked as follows:

1. Outdoor unit fan motor is pre-lubricated and sealed. No further lubrication is needed.
2. Visually inspect all connecting lines, joints and coils for evidence of oil leaks.
3. Check all wiring for loose connections.
4. Check for correct voltage at unit (unit operating).
5. Check amperage draw on outdoor fan motor.

**Motor Nameplate:** \_\_\_\_\_ **Actual:** \_\_\_\_\_.

6. Inspect drain holes in coil compartment base and clean if necessary.

*NOTE - If insufficient cooling occurs, the unit should be gauged and refrigerant charge should be checked.*

**Outdoor Coil**

Clean and inspect outdoor coil (may be flushed with a water hose). Ensure power is off before cleaning.

*NOTE — It may be necessary to flush the outdoor coil more frequently if it is exposed to substances which are corrosive or which block airflow across the coil (e.g., pet urine, cottonwood seeds, fertilizers, fluids that may contain high levels of corrosive chemicals such as salts)*

**Sea Coast** — Moist air in ocean locations can carry salt, which is corrosive to most metal. Units that are located near the ocean require frequent inspections and maintenance. These inspections will determine the necessary need to wash the unit including the outdoor coil. Consult your installing contractor for proper intervals/procedures for your geographic area or service contract.

**INDOOR UNIT MAINTENANCE**

**Indoor Unit**

1. Clean or change filters.
2. Lennox blower motors are prelubricated and permanently sealed. No more lubrication is needed.
3. Adjust blower speed for cooling. Measure the pressure drop over the coil to determine the correct blower CFM. Refer to the unit information service manual for pressure drop tables and procedure.
4. *Belt Drive Blowers* - Check belt for wear and proper tension.
5. Check all wiring for loose connections.
6. Check for correct voltage at unit. (blower operating)
7. Check amperage draw on blower motor.

**Motor Nameplate:** \_\_\_\_\_ **Actual:** \_\_\_\_\_.

**Indoor Coil**

1. Clean coil if necessary.
2. Check connecting lines, joints and coil for evidence of oil leaks.
3. Check condensate line and clean if necessary.

**Checklists**

**Table 25. Start-Up and Performance Checklist**

<b>Start-Up and Performance Checklist</b>			
Customer _____	Address _____		
Indoor Unit Model _____	Serial _____		
Outdoor Unit Model _____	Serial _____		
Notes: _____			
<b>START UP CHECKS</b>			
Refrigerant Type: _____			
First Stage: Rated Load Amps _____	Actual Amps _____	Rated Volts _____	Actual Volts _____
Second Stage: Rated Load Amps _____	Actual Amps _____	Rated Volts _____	Actual Volts _____
Condenser Fan Full Load Amps _____	Actual Amps: First Stage _____ Second Stage _____		
<b>COOLING MODE</b>			
Suction Pressure: First Stage: _____		Second Stage: _____	
Liquid Pressure: First Stage: _____		Second Stage: _____	

## Start-Up and Performance Checklist

Supply Air Temperature: First Stage: \_\_\_\_\_

Second Stage: \_\_\_\_\_

Temperature: Ambient: \_\_\_\_\_

Return Air: \_\_\_\_\_

System Refrigerant Charge (Refer to manufacturer's information on unit or installation instructions for required subcooling and approach temperatures.)

Subcooling:	A	—	B	=	SUBCOOLING
Saturated Condensing Temperature (A) <i>minus</i> Liquid Line Temperature (B)					
Approach:	A	—	B	=	APPROACH
Liquid Line Temperature (A) <i>minus</i> Outdoor Air Temperature (B)					
Indoor Coil Temperature Drop (18 to 22°F)	A	—	B	=	COIL TEMP DROP
Return Air Temperature (A) <i>minus</i> Supply Air Temperature (B)					

# Unit Wiring Diagrams






Figure 22. Typical XC21 Wiring (non-iComfort™-enabled (XC21-XXX-230-04 build)



**Figure 23. Typical XC21 Wiring (with iComfort™ -enabled, Surge Protection and Fan Motor Control (A177) Rewired) (XC21-XXX-230-05 build)**





**Figure 24. Typical XC21 Wiring (with iComfort™-enabled, New Fan Motor with built-in surge protection and External Surge Protection Device Removed (XC21-XXX-230-06 and -07 build)**




Figure 25. Typical XC21 Wiring (XC21-XXX-230-08 build and later)

# Factory Wiring Diagrams





Figure 26. Typical Factory Wiring (XC21-XX-230-04)



**Figure 27. Typical Factory Wiring (XC21-XX-230-05)**






Figure 28. Typical Factory Wiring (XC21-XX-230-06 and -07)



FAN RPM PROFILE	STAGE 1 RPM	STAGE 2 RPM	STAGE 3 RPM	EDX STAGE 1 RPM	EDX STAGE 2 RPM	EDX STAGE 3 RPM	MODEL
0	55	400	55	400	55	400	
1	62	450	62	450	62	450	
2	69	500	69	500	69	500	
3	71	550	76	550	71	550	
4	83	600	83	600	83	600	
5	90	650	90	650	90	650	
6	92	675	92	675	92	675	
7	97	700	97	700	97	700	
8	48	350	55	400	27	225	
9	58	425	69	500	27	225	XC/XP21-024
11	65	475	76	550	27	225	
12	72	525	83	600	30	200	XC/XP21-036
13	79	575	90	650	30	200	
14	83	600	92	675	30	200	XC/XP21-048 - XP21-060
15	86	625	97	700	30	200	XC21-060

Figure 29. Typical Factory Wiring (XC21-XX-230-08)

**XC21 iComfort™ Outdoor Unit**  
**Wiring Detail with Utility Load Shedding - Preferred Wiring Method**



**Figure 30. Preferred Method - Outdoor Controls - 101796-xx, 101797-xx, 101798-xx, 101799-xx, 103369-01 and 103369-02)**

Information in this note shows the proper application and interface wiring of utility load control devices to Lennox iComfort™-enabled outdoor units installed on iComfort™-enabled communicating thermostat systems.

**PREFERRED WIRING (OUTDOOR CONTROLS - 101796-XX, 101797-XX, 101798-XX, 101799-XX, 103369-01 AND 103369-02)**


1. **Utility Load Shedding Mode ACTIVATED (Utility Cycled Unit OFF)** – The normally closed set of contacts in the utility load control receiver **open**. This interrupts the **R** iComfort™ communication wire between the indoor unit and iComfort™-enabled outdoor unit. The iComfort™-enabled outdoor unit will be cycled **OFF**. A "Lost Communication alert" will appear on the display of the iComfort Wi-Fi® thermostat. If the customer has selected the option to be notified when an alert occurs, the customer will be notified by email when the alert occurs.
2. **Utility Load Shedding Mode DEACTIVATED (Normal Equipment Operation)** – When load shedding is deactivated, the contacts in the utility load control receiver are closed. The **R** iComfort™ communication wire between the indoor unit and iComfort™ outdoor unit is connected and iComfort™ communication is restored. The outdoor unit will return to normal operation and the alert code will clear.

**PREFERRED WIRING (OUTDOOR CONTROL - 103369-03)**

1. **Utility Load Shedding Mode ACTIVATED (Utility Cycled Unit OFF)** – The normally closed set of contacts in the utility load control receiver “open”. This removes 24VAC from the coil of the field-provided relay (catalog # 69J79). The relay contacts close (terminal 7 to terminal 2), completing the circuit between terminals **R** and **L** on the outdoor control. This 24VAC input to terminal **L** activates the load shedding mode in the outdoor control and the outdoor unit will be cycled **OFF**. The 7-Segment display on the outdoor control will display a load shedding alert code **E600** and an alert will appear on the display of the iComfort Wi-Fi® thermostat. If the customer has selected the option to be notified when an alert occurs, the customer will be notified by email when the alert occurs.
2. **Utility Load Shedding Mode DEACTIVATED (Normal Equipment Operation)** – When load shedding not required, the contacts in the utility load control receiver are closed. This provides 24VAC to the coil of the field provided relay (catalog # 69J79).The relay contacts **OPEN** (terminal 7 to terminal 2) removing 24VAC from the **L** terminal on the outdoor control. This deactivates the load shedding mode in the outdoor control. The outdoor unit will return to normal operation and alert code will clear.

**XC21 iComfort™ Outdoor Unit**  
**Wiring Detail with Utility Load Shedding - Preferred and Only Wiring Method**

*Outdoor Control Part Number*  
**103369-03**



**Figure 31. Preferred Method - Outdoor Control - 103369-03**

**NON- PREFERRED WIRING (OUTDOOR CONTROLS - 103369-01 AND 103369-02 ONLY)**

1. **Utility Load Shedding Mode ACTIVATED (Utility Cycled Unit OFF)** – The normally closed set of contacts in the utility load control receiver **open**. This interrupts the 24VAC signal from the **Y1 Out** terminal on the outdoor control to the compressor contactor coil and the compressor will be cycled **OFF**. The outdoor fan will continue to operate during a thermostat demand. The 7-segment display on the outdoor control will **NOT** display an alert code and the iComfort Wi-Fi® thermostat will **NOT** display an alert. The

customer will not be notified by email when the load shedding mode is activated by the utility company.

**Note** - Some utilities may require the entire outdoor unit to cycle off during utility load shedding. If the entire outdoor unit is required to cycle off, the "preferred wiring method" shown in figure 31 must be used.

2. **Utility Load Shedding Mode DEACTIVATED (Normal Equipment Operation)** – When load shedding is not required, the contacts in the utility load control receiver are closed. The circuit is completed between the **Y1 Out** terminal on the outdoor control to the compressor contactor coil. The outdoor unit will return to normal operation.



## XC21 iComfort™ Outdoor Unit


### Wiring Detail with Utility Load Shedding - Alternate Wiring Method

*NOTE: This alternate wiring method is not applicable to early production XC17, XP17, XC21 and XP21 outdoor units that used outdoor control 101796-xx, 101797-xx, 101798-xx and 101799-xx.*

#### Outdoor Control Part Numbers

103369-01


103369-02



**Figure 32. Non-Preferred Method - Outdoor Control- 103369-01 and 103369-02 Only)**

## Unit Sequence of Operations

The following figures illustrated the overall unit sequence of operations along with various pressure switches and temperature sensor operations. The figures also illustration the use of the compressor anti-short cycle function in relations to unit Status, Fault and Lockout LED Codes system operations interaction.



**Figure 33. One-Stage and Two-Stage Cooling Sequence of Operation**




Figure 34. Low Pressure Switch (S87) Sequence of Operation (All Versions)





Figure 35. High Pressure (S4) Switch Sequence of Operation

\* If temperature is at or above 279°F.



<sup>1</sup> If 5-strike counter has four or less strikes when Y1 demand is terminated or satisfied, the strike counter will reset to zero. In a iComfort™ thermostat enabled setup, the thermostat will terminate demand when the compressor contactor is de-energized. If demand is satisfied when alarm is not active, the 5-strike counter will reset.

<sup>2</sup> Lockouts can be reset by either cycling power off to the air conditioner control's (A175) R terminal, or placing a jumper on the field test pins (E33) between 1 to 2 seconds.

Figure 36. High Discharge Temperature (RT28) Sensor Sequence of Operation

### III. INSTALLATION

#### Unit Placement

#### **CAUTION**

In order to avoid injury, take proper precaution when lifting heavy objects.

See *Unit Dimensions* on page 3 for sizing mounting slab, platforms or supports. Refer to Figure 37 for mandatory installation clearance requirements.

#### POSITIONING CONSIDERATIONS

Consider the following when positioning the unit:

- Some localities are adopting sound ordinances based on the unit's sound level registered from the adjacent property, not from the installation property. Install the unit as far as possible from the property line.
- When possible, do not install the unit directly outside a window. Glass has a very high level of sound transmission. For proper placement of unit in relation to a window see the provided illustration in Figure 38, Detail A.

#### PLACING UNIT ON SLAB




Figure 37. Installation Clearances

When installing unit at grade level, the top of the slab should be high enough above grade so that water from higher ground will not collect around the unit. The slab should have a slope tolerance as described in Figure 38, Detail B.

*NOTE — If necessary for stability, anchor unit to slab as described in Figure 38, Detail D.*

#### ELEVATING THE UNIT

Units are outfitted with elongated support feet as illustrated in Figure 38, Detail C.

If additional elevation is necessary, raise the unit by extending the height of the unit support feet. This may be achieved by using a 2 inch (50.8mm) Schedule 40 female threaded adapter.

The specified coupling will fit snugly into the recessed portion of the feet. Use additional 2 inch (50.8mm) Schedule 40 male threaded adaptors which can be threaded into the female threaded adaptors to make additional adjustments to the level of the unit.

*NOTE — Keep the height of extenders short enough to ensure a sturdy installation. If it is necessary to extend further, consider a different type of field-fabricated framework that is sturdy enough for greater heights.*

## STABILIZING UNIT ON UNEVEN SURFACES

### **⚠ IMPORTANT**

#### Unit Stabilizer Bracket Use (field-provided):

Always use stabilizers when unit is raised above the factory height. (Elevated units could become unstable in gusty wind conditions).

Stabilizers may be used on factory height units when mounted on unstable an uneven surface.

With unit positioned at installation site, perform the following:

1. Remove two side louvered panels to expose the unit base.
2. Install the brackets as illustrated in Figure 38, Detail D using conventional practices.
3. Replace the panels after installation is complete.

## ROOF MOUNTING

Install the unit a minimum of 6 inches (152 mm) above the roof surface to avoid ice build-up around the unit. Locate the unit above a load bearing wall or area of the roof that can adequately support the unit. Consult local codes for rooftop applications.


### **NOTICE**

#### Roof Damage!

This system contains both refrigerant and oil. Some rubber roofing material may absorbed oil and cause the rubber to swell when it comes into contact with oil. The rubber will then bubble and could cause leaks. Protect the roof surface to avoid exposure to refrigerant and oil during service and installation. Failure to follow this notice could result in damage to roof surface.

## DETAIL A

### Outside Unit Placement



## DETAIL B

### Slab Mounting at Ground Level

INSTALL UNIT LEVEL OR, IF ON A SLOPE, MAINTAIN SLOPE TOLERANCE OF 2 DEGREES (OR 2 INCHES PER 5 FEET [50 MM PER 1.5 M]) AWAY FROM BUILDING STRUCTURE.





Figure 38. Placement, Slab Mounting and Stabilizing Unit

## DETAIL C




Use additional 2" SCH 40 male threaded adapters which can be threaded into the female threaded adapters to make additional adjustments to the level of the unit.


### Elevated Slab Mounting using Feet Extenders

## DETAIL D

### Slab Side Mounting



### Deck Top Mounting



ONE BRACKET PER SIDE (MIN.); FOR EXTRA STABILITY, TWO BRACKETS PER SIDE, 2" (50.8MM) FROM EACH CORNER.

### Stabilizing Unit on Uneven Surfaces

**IMPORTANT** — To help stabilize an outdoor unit, some installations may require strapping the unit to the pad using brackets and anchors commonly available in the marketplace.

Figure 39. Placement, Slab Mounting and Stabilizing Unit




## Removing and Installing Panels

# PANELS

### ACCESS AND LOUVERED

#### ACCESS PANEL REMOVAL

Removal and reinstallation of the access panel is as illustrated.



REMOVE 4 SCREWS TO REMOVE PANEL FOR ACCESSING COMPRESSOR AND CONTROLS.

POSITION PANEL WITH HOLES ALIGNED; INSTALL SCREWS AND TIGHTEN.

#### WARNING

To prevent personal injury, or damage to panels, unit or structure, be sure to observe the following:

While installing or servicing this unit, carefully stow all removed panels out of the way, so that the panels will not cause injury to personnel, nor cause damage to objects or structures nearby, nor will the panels be subjected to damage (e.g., being bent or scratched).

While handling or stowing the panels, consider any weather conditions, especially windy conditions, that may cause panels to be blown around and battered.

**IMPORTANT** — Do not allow panels to hang on unit by top tab. Tab is for alignment and not designed to support weight of panel.

PANEL SHOWN SLIGHTLY ROTATED TO ALLOW TOP TAB TO EXIT (OR ENTER) TOP SLOT FOR REMOVING (OR INSTALLING) PANEL.

#### LOUVERED PANEL REMOVAL

Remove the louvered panels as follows:

1. Remove two screws, allowing the panel to swing open slightly.
2. Hold the panel firmly throughout this procedure. Rotate bottom corner of panel away from hinged corner post until lower three tabs clear the slots as illustrated in **Detail B**.
3. Move panel down until lip of upper tab clears the top slot in corner post as illustrated in **Detail A**.


#### LOUVERED PANEL INSTALLATION

Position the panel almost parallel with the unit as illustrated in **Detail D** with the screw side as close to the unit as possible. Then, in a continuous motion:

1. Slightly rotate and guide the lip of top tab inward as illustrated in **Detail A** and **C**; then upward into the top slot of the hinge corner post.
2. Rotate panel to vertical to fully engage all tabs.
3. Holding the panel's hinged side firmly in place, close the right-hand side of the panel, aligning the screw holes.
4. When panel is correctly positioned and aligned, insert the screws and tighten.

#### **Detail C**

MAINTAIN MINIMUM PANEL ANGLE (AS CLOSE TO PARALLEL WITH THE UNIT AS POSSIBLE) WHILE INSTALLING PANEL.



**IMPORTANT** — To help stabilize an outdoor unit, some installations may require strapping the unit to the pad using brackets and anchors commonly available in the marketplace.

#### **Detail A**



LIP

SCREW HOLES

#### **Detail B**



ROTATE IN THIS DIRECTION; THEN DOWN TO REMOVE PANEL

#### **Detail D**

ANGLE MAY BE TOO EXTREME

PREFERRED ANGLE FOR INSTALLATION

HOLD DOOR FIRMLY ALONG THE HINGED SIDE TO MAINTAIN FULLY-ENGAGED TABS




Figure 40. Removing and Installing Panels

## Electrical

In the U.S.A., wiring must conform with current local codes and the current National Electric Code (NEC). In Canada, wiring must conform with current local codes and the current Canadian Electrical Code (CEC).

Refer to the furnace or blower coil installation instructions


for additional wiring application diagrams and refer to unit nameplate for minimum circuit ampacity and maximum overcurrent protection size.

### 24VAC TRANSFORMER

Use the transformer provided with the furnace or air handler for low-voltage control power (24VAC - 40 VA minimum)

#### 1 SIZE CIRCUIT AND INSTALL DISCONNECT SWITCH


Refer to the unit nameplate for minimum circuit ampacity, and maximum fuse or circuit breaker (HACR per NEC). Install power wiring and properly sized disconnect switch.



*NOTE — Units are approved for use only with copper conductors. Ground unit at disconnect switch or to an earth ground.*

#### 2 INSTALL THERMOSTAT

Install room thermostat (ordered separately) on an inside wall approximately in the center of the conditioned area and 5 feet (1.5m) from the floor. It should not be installed on an outside wall or where it can be affected by sunlight or drafts.



*NOTE — 24VAC, Class II circuit connections are made in the control panel.*

### ⚠ WARNING



Electric Shock Hazard. Can cause injury or death. Unit must be grounded in accordance with national and local codes.

Line voltage is present at all components when unit is not in operation on units with single-pole contactors. Disconnect all remote electric power supplies before opening access panel. Unit may have multiple power supplies.

### ⚠ CAUTION

#### ELECTROSTATIC DISCHARGE (ESD) Precautions and Procedures

Physical contact with metal edges and corners while applying excessive force or rapid motion can result in personal injury. Be aware of, and use caution when working nearby these areas during installation or while servicing this equipment.

### 3 ROUTE CONTROL WIRES — NON-COMMUNICATING

Install low voltage control wiring from outdoor to indoor unit and from thermostat to indoor unit as illustrated.


- A Run 24VAC control wires through hole with grommet.
- B Make 24VAC control wire connections to main control (A175).

**NOTE** — Do not bundle any excess 24VAC control wires inside control box.

**NOTE** — Wire tie provides low voltage wire strain relief and to maintain separation of field installed low and high voltage circuits.

**NOTE** — For proper voltages, select control wires gauge per table below.

WIRE RUN LENGTH	AWG#	INSULATION TYPE
LESS THAN 100' (30 METERS)	18	TEMPERATURE RATING
MORE THAN 100' (30 METERS)	16	35°C MINIMUM.




### ROUTE CONTROL WIRES — COMMUNICATING


Maximum length of wiring (18 gauge) for all connections on the RSBus is limited to 1500 feet (457 meters). Color-coded, temperature rating 95°F (35°C) minimum, solid core. (Class II Rated Wiring)

### 4 ROUTE HIGH VOLTAGE AND GROUND WIRES


Any excess high voltage field wiring should be trimmed and secured away from any low voltage field wiring. To facilitate a conduit, a cutout is located in the bottom of the control box. Connect conduit to the control box using a proper conduit fitting.



## Field Control Wiring



**Figure 41. ComfortSense® 7000 Series Thermostat — Non-Communicating Connections - Air Handler/Two-Stage Air Conditioner**



1. Thermostat **T** terminals are used for outdoor sensor input. Use for thermostat's outdoor temperature display (optional).
2. **R** to **L** connection is required for this model when using the ComfortSense® 7000 - catalog number Y0349 only. Resistor Kit (catalog number 47W97) required and ordered separately.
3. Cut on-board link **W915** (clippable wire) for two-stage operation.
4. Cut loop jumper (clippable wire) **Short DS to R** for Humiditrol® applications. This will slow the outdoor unit's fan speed to a specific RPM. A wire must be installed between the **DS** terminals on the furnace and outdoor unit controls. See table 11 for fan speed based on unit capacity.
5. Cut on-board link (clippable wire) **DS-R** for Humiditrol® or Harmony III™ applications. This will slow the indoor blower motor to the lowest speed setting. See furnace installation instruction or Product Specification bulletin for lowest fan speed information.

**Figure 42. ComfortSense® 7000 Series Thermostat — Non-Communicating Connections - Furnace/Two-Stage Air Conditioner**

**New or Replacement Line Set**

**REFRIGERANT LINE SET**

This section provides information on installation or replacement of existing line set. If new or replacement line set is not being installed then proceed to *Brazing Connections* on page 72.

**⚠ IMPORTANT**

Lennox highly recommends changing line set when converting the existing system from HCFC-22 to HFC-410A. If that is not possible and the line set is the proper size as reference in table 2, use the procedure outlined under *Flushing the System* on page 13.

If refrigerant lines are routed through a wall, then seal and isolate the opening so vibration is not transmitted to the building. Pay close attention to line set isolation during installation of any HVAC system. When properly isolated from building structures (walls, ceilings, floors), the refrigerant lines will not create unnecessary vibration and subsequent sounds. See Figure 43 for recommended installation practices. Also, consider the following when placing and installing a high-efficiency outdoor unit.

Liquid lines that meter the refrigerant, such as RFC1 liquid lines, must not be used in this application. Existing line set of proper size as listed in table 26 may be reused. If system was previously charged with HCFC-22 refrigerant, then existing line set must be flushed (see *Flushing the System* on page 75).

Field refrigerant piping consists of liquid and vapor lines from the outdoor unit to the indoor unit coil (braze connections).

To obtain the correct information from Lennox, be sure to communicate the following information:

- Model (XC21) and size of unit (e.g. -036).
- Line set diameters for the unit being installed as listed in table 26 and total length of installation.
- Number of elbows vertical rise or drop in the piping.

**Table 26. Refrigerant Line Set Requirements**

Model Number (-xx*)	Valve Size Connections		Recommended Line Sets		
	Liquid Line	Suction Line	L15 Line Set Model	Line Set Length	Catalog Number
XC21-024-230-XX XC21-036-230-XX XC21-048-230-XX	3/8" (10 mm)	7/8" (22 mm)	L15-65-30	30 feet (9.1 m)	89J60
			L15-65-40	40 feet (12.2 m)	89J61
			L15-65-50	50 feet (15.2 m)	89J62
XC21-060-230-XX	3/8" (10 mm)	1-1/8" (29 mm) **	Field-fabricated	N/A	N/A

\* Applicable to all minor revision numbers unless otherwise specified.  
 \*\* Some applications may require a field-provided 1-1/8" to 7/8" adapter.

**NOTE** — When installing refrigerant lines longer than 50 feet, see the *Lennox Refrigerant Piping Design and Fabrication Guidelines, CORP. 9351-L9*, or contact *Lennox Technical Support Product Applications* for assistance.


**⚠ IMPORTANT**

Mineral oils are not compatible with HFC-410A. If oil must be added, it must be a Polyol ester oil.

The compressor is charged with sufficient Polyol ester oil for line set lengths up to 50 feet. Recommend adding oil to system based on the amount of refrigerant charge in the system. No need to add oil in system with 20 pounds of refrigerant or less. For systems over 20 pounds - add one ounce of every five pounds of refrigerant.


Recommended topping-off POE oils are Mobil EAL ARCTIC 22 CC or ICI EMKARATE™ RL32CF.

**⚠ WARNING**



Danger of fire. Bleeding the refrigerant charge from only the high side may result in the low side shell and suction tubing being pressurized. Application of a brazing torch while pressurized may result in ignition of the refrigerant and oil mixture - check the high and low pressures before unbrazing.

**⚠ WARNING**



When using a high pressure gas such as dry nitrogen to pressurize a refrigeration or air conditioning system, use a regulator that can control the pressure down to 1 or 2 psig (6.9 to 13.8 kPa).

**⚠ CAUTION**

Brazing alloys and flux contain materials which are hazardous to your health.

Avoid breathing vapors or fumes from brazing operations. Perform operations only in well ventilated areas.

Wear gloves and protective goggles or face shield to protect against burns.

Wash hands with soap and water after handling brazing alloys and flux.


# LINE SET

**IMPORTANT** — Refrigerant lines must not contact structure.

## INSTALLATION

**Line Set Isolation** — The following illustrations are examples of proper refrigerant line set isolation:


### REFRIGERANT LINE SET — TRANSITION FROM VERTICAL TO HORIZONTAL



### REFRIGERANT LINE SET — INSTALLING VERTICAL RUNS (NEW CONSTRUCTION SHOWN)



**NOTE** — Insulate liquid line when it is routed through areas where the surrounding ambient temperature could become higher than the temperature of the liquid line or when pressure drop is equal to or greater than 20 psig.

**IMPORTANT** — Refrigerant lines must not contact wall



### REFRIGERANT LINE SET — INSTALLING HORIZONTAL RUNS

To hang line set from joist or rafter, use either metal strapping material or anchored heavy nylon wire ties.



**NOTE** — Similar installation practices should be used if line set is to be installed on exterior of outside wall.

**WARNING** — Polyol ester (POE) oils used with HFC-410A refrigerant absorb moisture very quickly. It is very important that the refrigerant system be kept closed as much as possible. **DO NOT** remove line set caps or service valve stub caps until you are ready to make connections.

Figure 43. Line Set Installation

## Brazing Connections

Use the procedures outline in figures 44 and 45 for brazing line set connections to service valves.

### WARNING



Danger of fire. Bleeding the refrigerant charge from only the high side may result in pressurization of the low side shell and suction tubing. Application of a brazing torch to a pressurized system may result in ignition of the refrigerant and oil mixture - Check the high and low pressures before applying heat.

### WARNING



When using a high pressure gas such as dry nitrogen to pressurize a refrigeration or air conditioning system, use a regulator that can control the pressure down to 1 or 2 psig (6.9 to 13.8 kPa).

### CAUTION

Brazing alloys and flux contain materials which are hazardous to your health.

Avoid breathing vapors or fumes from brazing operations. Perform operations only in well-ventilated areas.

Wear gloves and protective goggles or face shield to protect against burns.

Wash hands with soap and water after handling brazing alloys and flux.

### IMPORTANT

Connect gauge set low pressure side to vapor line service valve and repeat procedure starting at paragraph 4 for brazing the liquid line to service port valve.

### IMPORTANT

Allow braze joint to cool before removing the wet rag from the service valve. Temperatures above 250°F can damage valve seals.

### IMPORTANT

Use silver alloy brazing rods with 5% minimum silver alloy for copper-to-copper brazing. Use 45% minimum alloy for copper-to-brass and copper-to-steel brazing.

### WARNING



Fire, Explosion and Personal Safety Hazard.



Failure to follow this warning could result in damage, personal injury or death.

Never use oxygen to pressurize or purge refrigeration lines. Oxygen, when exposed to a spark or open flame, can cause fire and/or an explosion, that could result in property damage, personal injury or death.



# 1 PIPING PANEL REMOVAL AND PREPARING LINE SET


Remove piping panel for easier access to service valves. Cut ends of the refrigerant lines square (free from nicks or dents) and debur the ends. The pipe must remain round. Do not crimp end of the line.



DO NOT CRIMP SERVICE VALVE CONNECTOR WHEN PIPE IS SMALLER THAN CONNECTION

# 2 CAP AND CORE REMOVAL

Remove service cap and core from both the suction and liquid line service ports.



# 3 ATTACH THE MANIFOLD GAUGE SET FOR BRAZING LIQUID AND SUCTION LINE SERVICE VALVES

- A Connect gauge set low pressure side to liquid line service valve (service port).
- B Connect gauge set center port to bottle of nitrogen with regulator.
- C With valve core removed from the suction line service port, nitrogen flow will have an exit point.




Figure 44. Brazing Procedures

## 4 WRAP SERVICE VALVES

To help protect service valve seals during brazing, wrap water saturated cloths around service valve bodies and copper tube stubs. Use additional water saturated cloths underneath the valve body to protect the base paint.

## 5 FLOW NITROGEN

Flow regulated nitrogen (at 1 to 2 psig) through the refrigeration gauge set into the valve stem port connection on the liquid service valve and out of the suction / vapor valve stem port. See steps 3A, 3B and 3C on previous page and below for manifold gauge setup.




**WARNING**

1. **FIRE, PERSONAL INJURY, OR PROPERTY DAMAGE** will result if you do not wrap a water saturated cloth around both liquid and suction line service valve bodies and copper tube stub while brazing in the line set! The braze, when complete, must be quenched with water to absorb any residual heat.
2. Do not open service valves until refrigerant lines and indoor coil have been leak-tested and evacuated. Refer to procedures provided in this supplement.

## 6 BRAZE LINE SET

Water saturated cloths must remain water saturated throughout the brazing and cool-down process.

- A Braze liquid line to liquid line service valve.
- B Braze suction / vapor line to suction / vapor service valve.



**IMPORTANT — Allow braze joint to cool. Apply additional water saturated cloths to help cool brazed joints. Do not remove water saturated cloths until piping has cooled. Temperatures above 250°F will damage valve seals.**

## 7 PREPARATION FOR NEXT STEP


After all connections have been brazed, disconnect manifold gauge set from service ports. Apply additional water saturated cloths to both services valves to cool piping. Once piping is cool, remove all water saturated cloths. Refer to the unit installation instructions for the next step in preparing the unit.

Figure 45. Brazing Procedures (Continued)

# FLUSHING


## LINE SET AND INDOOR COIL (1 OF 2)

### 1 TYPICAL FIXED ORIFICE REMOVAL PROCEDURE (Uncased Coil Shown)



- A On fully cased coils, remove the coil access and plumbing panels.
- B Remove any shipping clamps holding the liquid line and distributor assembly.
- C Using two wrenches, disconnect liquid line from liquid line orifice housing. Take care not to twist or damage distributor tubes during this process.
- D Remove and discard fixed orifice, valve stem assembly if present and Teflon washer as illustrated above.
- E Use a field-provided fitting to temporary reconnect the liquid line to the indoor unit's liquid line orifice housing.


### 2 CONNECT GAUGES AND EQUIPMENT FOR FLUSHING PROCEDURE



- A Inverted HCFC-22 cylinder with clean refrigerant\* to the vapor service valve.
- B HCFC-22 gauge set (low side) to the liquid line valve.
- C HCFC-22 gauge set center port to inlet on the recovery machine with an empty recovery tank to the gauge set.
- D Connect recovery tank to recovery machines per machine instructions.

**\*IMPORTANT - Clean refrigerant is any refrigerant in a system that has not had compressor burn out. If the system has experienced burn out, it is recommended that the existing line set and indoor coil be replaced.**

### TYPICAL CHECK EXPANSION VALVE REMOVAL PROCEDURE (Uncased Coil Shown)



- A On fully cased coils, remove the coil access and plumbing panels.
- B Remove any shipping clamps holding the liquid line and distributor assembly.
- C Disconnect the equalizer line from the check expansion valve equalizer line fitting on the vapor line.
- D Remove the vapor line sensing bulb.
- E Disconnect the liquid line from the check expansion valve at the liquid line assembly.
- F Disconnect the check expansion valve from the liquid line orifice housing. Take care not to twist or damage distributor tubes during this process.
- G Remove and discard check expansion valve and the two Teflon rings.
- H Use a field-provided fitting to temporary reconnect the liquid line to the indoor unit's liquid line orifice housing.

**CAUTION** —This procedure should not be performed on systems which contain contaminants (Example compressor burn out).

### 3 FLUSHING LINE SET

The line set and indoor unit coil must be flushed with at least the same amount of clean refrigerant\* that previously charged the system. Check the charge in the flushing cylinder before proceeding.

- A Set the recovery machine for liquid recovery and start the recovery machine. Open the gauge set valves to allow the recovery machine to pull a vacuum on the existing system line set and indoor unit coil.
- B Invert the cylinder of clean HCFC-22\* and open its valve to allow liquid refrigerant to flow into the system through the vapor line valve. Allow the refrigerant to pass from the cylinder and through the line set and the indoor unit coil before it enters the recovery machine.
- C After all of the liquid refrigerant has been recovered, switch the recovery machine to vapor recovery so that all of the HCFC-22 vapor is recovered. Allow the recovery machine to pull down to 0 the system.
- D Close the valve on the inverted HCFC-22 drum and the gauge set valves. Pump the remaining refrigerant out of the recovery machine and turn the machine off.



Figure 46. Flushing Procedures

## FLUSHING LINE SET AND INDOOR COIL (2 OF 2)

### 4 TYPICAL NEW CHECK EXPANSION VALVE INSTALLATION PROCEDURE

THIS OUTDOOR UNIT IS DESIGNED FOR USE IN SYSTEMS THAT USE A CHECK EXPANSION VALVE METERING DEVICE. SEE THE *LENNOX XC21 PRODUCT SPECIFICATION* FOR APPROVED EXPANSION VALVE KIT MATCH-UPS AND APPLICATION INFORMATION.

THE EXPANSION VALVE UNIT CAN BE INSTALLED INTERNAL OR EXTERNAL TO THE INDOOR COIL. IN APPLICATIONS WHERE AN UNCASSED COIL IS BEING INSTALLED IN A FIELD-PROVIDED PLENUM, INSTALL THE CHECK EXPANSION VALVE IN A MANNER WHICH PROVIDES ACCESS FOR FIELD SERVICING OF THE EXPANSION VALVE. REFER TO BELOW ILLUSTRATION FOR REFERENCE DURING INSTALLATION OF EXPANSION VALVE UNIT.





- REMOVE THE FIELD-PROVIDED FITTING THAT TEMPORARILY RECONNECTED THE LIQUID LINE TO THE INDOOR UNIT'S DISTRIBUTOR ASSEMBLY.
- INSTALL ONE OF THE PROVIDED TEFLON® RINGS AROUND THE STUBBED END OF THE EXPANSION VALVE AND LIGHTLY LUBRICATE THE CONNECTOR THREADS AND EXPOSE SURFACE OF THE TEFLON® RING WITH REFRIGERANT OIL.
- ATTACH THE STUBBED END OF THE EXPANSION VALVE TO THE LIQUID LINE ORIFICE HOUSING. FINGER TIGHTEN AND USE AN APPROPRIATELY SIZED WRENCH TO TURN AN ADDITIONAL 1/2 TURN CLOCKWISE AS ILLUSTRATED IN THE FIGURE ABOVE, OR 20 FT-LB.
- PLACE THE REMAINING TEFLON® WASHER AROUND THE OTHER END OF THE EXPANSION VALVE. LIGHTLY LUBRICATE CONNECTOR THREADS AND EXPOSE SURFACE OF THE TEFLON® RING WITH REFRIGERANT OIL.
- ATTACH THE LIQUID LINE ASSEMBLY TO THE EXPANSION VALVE. FINGER TIGHTEN AND USE AN APPROPRIATELY SIZED WRENCH TO TURN AN ADDITIONAL 1/2 TURN CLOCKWISE AS ILLUSTRATED IN THE FIGURE ABOVE OR 20 FT-LB.

### SENSING BULB INSTALLATION


- ATTACH THE VAPOR LINE SENSING BULB IN THE PROPER ORIENTATION AS ILLUSTRATED TO THE RIGHT USING THE CLAMP AND SCREWS PROVIDED.

*NOTE - CONFIRM PROPER THERMAL CONTACT BETWEEN VAPOR LINE AND CHECK EXPANSION BULB BEFORE INSULATING THE SENSING BULB ONCE INSTALLED.*

- CONNECT THE EQUALIZER LINE FROM THE EXPANSION VALVE TO THE EQUALIZER VAPOR PORT ON THE VAPOR LINE. FINGER TIGHTEN THE FLARE NUT PLUS 1/8 TURN (7 FT-LBS) AS ILLUSTRATED BELOW.



ON LINES SMALLER THAN 7/8", MOUNT SENSING BULB BETWEEN THE 9 AND 3 O'CLOCK POSITIONS.



ON 7/8" AND LARGER LINES, MOUNT SENSING BULB AT EITHER THE 4 OR 8 O'CLOCK POSITION. NEVER MOUNT THE SENSING BULB ON BOTTOM OF LINE.

*NOTE - NEVER MOUNT THE SENSING BULB ON BOTTOM OF LINE.*

### EQUALIZER LINE INSTALLATION

REMOVE AND DISCARD EITHER THE FLARE SEAL CAP OR FLARE NUT WITH COPPER FLARE SEAL BONNET FROM THE EQUALIZER LINE PORT ON THE VAPOR LINE AS ILLUSTRATED IN THE FIGURE TO THE RIGHT.




Figure 47. Flushing Procedures (Continued)

## INSTALLING ISOLATION GROMMETS

Locate the isolation grommets (provided). Slide grommets onto vapor and liquid lines. Insert grommets into piping panel to isolate refrigerant lines from sheet metal edges.




Figure 48. Isolation Grommets

### **⚠ IMPORTANT**

The Environmental Protection Agency (EPA) prohibits the intentional venting of HFC refrigerants during maintenance, service, repair and disposal of appliance. Approved methods of recovery, recycling or reclaiming must be followed.

### **⚠ IMPORTANT**

If this unit is being matched with an approved line set or indoor unit coil which was previously charged with mineral oil, or if it is being matched with a coil which was manufactured before January of 1999, the coil and line set must be flushed prior to installation. Take care to empty all existing traps. Polyol ester (POE) oils are used in Lennox units charged with HFC-410A refrigerant. Residual mineral oil can act as an insulator, preventing proper heat transfer. It can also clog the expansion device, and reduce the system performance and capacity.

Failure to properly flush the system per the instructions below will void the warranty.

## Leak Testing the System

### **⚠ IMPORTANT**

Leak detector must be capable of sensing HFC refrigerant.

### **⚠ WARNING**



When using a high pressure gas such as dry nitrogen to pressurize a refrigeration or air conditioning system, use a regulator that can control the pressure down to 1 or 2 psig (6.9 to 13.8 kPa).

### **⚠ WARNING**

Refrigerant can be harmful if it is inhaled. Refrigerant must be used and recovered responsibly.

Failure to follow this warning may result in personal injury or death.

### **⚠ WARNING**



Fire, Explosion and Personal Safety Hazard.

Failure to follow this warning could result in damage, personal injury or death.

Never use oxygen to pressurize or purge refrigeration lines. Oxygen, when exposed to a spark or open flame, can cause damage by fire and/or an explosion, that could result in personal injury or death.

# LEAK TEST

## LINE SET AND INDOOR COIL


*NOTE — Normally, the high pressure hose is connected to the liquid line port. However, connecting it to the vapor port better protects the manifold gauge set from high pressure damage.*

### 1 CONNECT GAUGE

**A** SET Connect an HFC-410A manifold gauge set high pressure hose to the vapor valve service port.

**B** With both manifold valves closed, connect the cylinder of HFC-410A refrigerant to the center port of the manifold gauge set.

*NOTE — Later in the procedure, the HFC-410A container will be replaced by the nitrogen container.*



### 2 TEST FOR LEAKS

After the line set has been connected to the indoor unit and air conditioner, check the line set connections and indoor unit for leaks. Use the following procedure to test for leaks:


- A** With both manifold valves closed, connect the cylinder of HFC-410A refrigerant to the center port of the manifold gauge set. Open the valve on the HFC-410A cylinder (vapor only).
- B** Open the high pressure side of the manifold to allow HFC-410A into the line set and indoor unit. Weigh in a trace amount of HFC-410A. [A trace amount is a maximum of two ounces (57 g) refrigerant or three pounds (31 kPa) pressure]. Close the valve on the HFC-410A cylinder and the valve on the high pressure side of the manifold gauge set. Disconnect the HFC-410A cylinder.
- C** Connect a cylinder of dry nitrogen with a pressure regulating valve to the center port of the manifold gauge set.
- D** Adjust dry nitrogen pressure to 150 psig (1034 kPa). Open the valve on the high side of the manifold gauge set in order to pressurize the line set and the indoor unit.
- E** After a few minutes, open one of the service valve ports and verify that the refrigerant added to the system earlier is measurable with a leak detector.
- F** After leak testing disconnect gauges from service ports.

## Evacuating the System

Evacuating the system of non-condensables is critical for proper operation of the unit. Non-condensables are defined as any gas that will not condense under temperatures and pressures present during operation of an air conditioning system. Non-condensables and water suction combine with refrigerant to produce substances that corrode copper piping and compressor parts.

## **⚠ WARNING**

**Danger of Equipment Damage.** Avoid deep vacuum operation. Do not use compressors to evacuate a system. Extremely low vacuums can cause internal arcing and compressor failure. Damage caused by deep vacuum operation will void warranty.



**Figure 49. Connecting Gauge Set**

### EVACUATE LINE SET AND INDOOR COIL

The unit is shipped with a factory refrigerant charge. The liquid and suction line valves were closed after final testing at the factory. Do not operate these valves until the line set and indoor coil have been evacuated and leak checked, or the charge is lost.

*Note: Do not use any portion of the factory charge for purging or leak testing. The factory charge is for filling the system only after a complete evacuation and leak check has been performed.*

Line set and indoor coil should be evacuated using the recommend deep vacuum method of 500 microns. If deep vacuum equipment is not available, the alternate triple evacuation method may be used by following the specified procedure.


If vacuum must be interrupted during the evacuation procedure, always break vacuum with dry nitrogen.

### **Deep Vacuum Method**

The deep vacuum method requires a vacuum pump capable of pulling a vacuum to 500 microns and a vacuum gauge capable of accurately measuring this vacuum level. The deep vacuum method is the most positive way of assuring a system is free of air and water.

Watch the vacuum gauge as the system is pulling down. The response of the gauge is an indicator of the condition of the system (refer to figure 50).


With no leaks in the system, allow the vacuum pump to run for 30 minutes minimum at the deep vacuum level.



**Figure 50. Deep Vacuum Gauge Response and System Conditions**

**Triple Evacuation Method**

The triple evacuation method should only be used when system does not contain any water in liquid form and vacuum pump is only capable of pulling down to 28 inches of mercury (711mm Hg). Refer to figure 51 and proceed as follows:



**Figure 51. Triple Evacuation Sequence**

1. Pull system down to 28 inches of mercury (711mm Hg) and allow pump to continue operating for an additional 15 minutes.
2. Close manifold valves or valve at vacuum pump and shut off vacuum pump.
3. Connect a nitrogen cylinder and regulator to system and fill with nitrogen until system pressure is 2 psig.
4. Close nitrogen valve and allow system to stand for one hour. During this time, dry nitrogen will diffuse throughout the system absorbing moisture.
5. Repeat this procedure as indicated in figure 51. System will then be free of any airborne containment and water vapor.
6. After the final evacuate sequence, confirm there are no leaks in the system. If a leak is found, repeat the entire process after repair is made.
7. Reconnect the manifold gauge to the vacuum pump, turn the pump on, and continue to evacuate the line set and indoor unit until the absolute pressure does not rise above 500 microns (29.9 inches of mercury) within a 20 – minute period after shutting off the vacuum pump and closing the manifold gauge valves.
8. Disconnect the manifold hose from the vacuum pump and connect it to an inverted cylinder of HFC – 410A positioned to deliver liquid refrigerant. Open the manifold gauge valve 1 to 2 psig in order to release the vacuum in the line set and indoor unit.
9. Perform the following:
  - Close manifold gauge valves.
  - Shut off HFC – 410A cylinder.
  - Slowly open the service valves.
  - Refer to the charging sticker on the unit to complete the outdoor unit installation.



## IV. SYSTEM CHARGE

### Serviceing Units Delivered Void of Charge

If the outdoor unit is void of refrigerant, clean the system using the procedure described below.

1. Leak check system using procedure outlined on page 77.
2. Evacuate the system using procedure outlined on page manual.
3. Use nitrogen to break the vacuum and install a new filter drier in the system.
4. Evacuate the system again using procedure outlined on page manual.
5. Weigh in refrigerant using procedure outlined in figure manual.
6. Monitor the system to determine the amount of moisture remaining in the oil. It may be necessary to replace the filter drier several times to achieve the required dryness level. **If system dryness is not verified, the compressor will fail in the future.**

### Unit Start-Up

#### ⚠ IMPORTANT

If unit is equipped with a crankcase heater, it should be energized 24 hours before unit start-up to prevent compressor damage as a result of slugging.

1. Rotate fan to check for binding.
2. Inspect all factory- and field-installed wiring for loose connections.

3. After evacuation is complete, open both the liquid and vapor line service valves to release the refrigerant charge contained in outdoor unit into the system.
4. Replace the stem caps and tighten to the value listed in table 1.
5. Check voltage supply at the disconnect switch. The voltage must be within the range listed on the unit's nameplate. If not, do not start the equipment until you have consulted with the power company and the voltage condition has been corrected.
6. Set the thermostat for a cooling demand. Turn on power to the indoor indoor unit and close the outdoor unit disconnect switch to start the unit.
7. Recheck voltage while the unit is running. Power must be within range shown on the nameplate.
8. Check system for sufficient refrigerant by using the procedures listed under *System Charge*.

### System Refrigerant

This section outlines procedures for:

1. Connecting gauge set for testing and charging as illustrated in figure 52.
2. Checking and adjusting indoor airflow as described in figure 53.
3. Add or remove refrigerant using the weigh in method provided in figure 55, and verifying charge using sub-cooling method described in figure 57.





Figure 52. Gauge Set Connections

## ADDING OR REMOVING REFRIGERANT


This system uses HFC-410A refrigerant which operates at much higher pressures than HCFC-22. The pre-installed liquid line filter drier is approved for use with HFC-410A only. Do not replace it with components designed for use with HCFC-22. This unit is NOT approved for use with coils which use capillary tubes or fixed orifices as a refrigerant metering device.

Check airflow using the Delta-T (DT) process using the illustration in Figure 53.



**Figure 53. Checking Indoor Airflow over Evaporator Coil using Delta-T Chart**

Use **WEIGH IN** to initially charge a system when the outdoor unit is void of charge. To verify charge and add or remove refrigerant use either **APPROACH** or **SUBCOOLING** methods.



**Figure 54. Determining Charge Method**

# WEIGH IN

**CHARGING METHOD** 64°F (17.7°C) and Below

**CALCULATING SYSTEM CHARGE FOR OUTDOOR UNIT VOID OF CHARGE**

If the system is void of refrigerant, first, locate and repair any leaks and then weigh in the refrigerant charge into the unit. To calculate the total refrigerant charge:

Amount specified on nameplate      Adjust amount for variation in line set length listed on line set length table below.      Total charge

\_\_\_\_\_ ± \_\_\_\_\_ = \_\_\_\_\_

**Refrigerant Charge per Line Set Length**

Liquid Line Set Diameter	Ounces per 5 feet (g per 1.5 m) adjust from 15 feet (4.6 m) line set*
3/8" (9.5 mm)	3 ounce per 5' (85 g per 1.5 m)

\*If line length is greater than 15 ft. (4.6 m), add this amount. If line length is less than 15 ft. (4.6 m), subtract this amount.

*NOTE — Insulate liquid line when it is routed through areas where the surrounding ambient temperature could become higher than the temperature of the liquid line or when pressure drop is equal to or greater than 20 psig.*

*NOTE — The exemplified nameplate is for illustration purposes only. Use data listed on actual unit nameplate for charging.*

**Figure 55. Using HFC-410A Weigh In Method (all builds)**

# APPROACH

## TEST AND CHARGE METHOD 65°F (18.3°C) and Above

1. Confirm proper airflow across coil using Figure 53.
2. Compare unit pressures with applicable charging sticker, *Normal Operating Pressures*.
3. Use APPROACH to correctly charge unit or to verify the charge is correct.
4. Set thermostat to call for heat (must have a cooling load between 70-80°F (21-26°C)).
5. Connect gauge set.
6. When heat demand is satisfied, set thermostat to call for cooling.
7. Allow temperatures and pressures to stabilize.
8. Record outdoor ambient temperature:

AMB° = \_\_\_\_\_

9. Record line temperature:

LIQ° = \_\_\_\_\_

10. Subtract to determine approach (APP°):

LIQ° \_\_\_\_\_ - AMB° \_\_\_\_\_ = APP° \_\_\_\_\_

11. Compare results with the applicable charging sticker.

**APP° (Approach) Values (F: +/-1.0° [C: +/-0.6°])  
Second Stage (High Capacity)**

If refrigerant added or removed, retest to confirm that unit is properly charged




If value is greater than shown (high approach), add refrigerant; if less than shown (liquid temp too close to ambient temp, low approach), remove refrigerant.



**Figure 56. Using HFC-410A Approach Method**

# SUBCOOLING

## TEST AND CHARGE METHOD 65°F (18.3°C) and Above



**BLOCK OUTDOOR COIL:** [sometimes necessary with lower temperatures] Use cardboard or plastic sheet to restrict the airflow through the outdoor coil to achieve pressures from 325-375 psig (2240-2585 kPa). Higher pressures are needed to check charge. Block equal sections of air intake panels and move coverings sideways until the liquid pressure is in the above noted ranges.

1. Confirm proper airflow across coil using Figure 53.
2. Compare unit pressures with applicable charging sticker, *Normal Operating Pressures*.
3. Use SUBCOOLING to correctly charge unit or to verify the charge is correct.
4. Set thermostat to call for heat (must have a cooling load between 70-80°F (21-26°C)).
5. Connect gauge set
6. Measure outdoor ambient temperature
7. When heat demand is satisfied, set thermostat to call for cooling
8. Allow temperatures and pressures to stabilize.

*NOTE - If necessary, block outdoor coil to maintain 325 - 375 psig.*

9. Record liquid line temperature:

LIQ° = \_\_\_\_\_

10. Measure liquid line pressure and use the value to determine saturation temperature (see charging table):

SAT° = \_\_\_\_\_

11. Subtract to determine subcooling (SC°):

SAT° \_\_\_\_\_ - LIQ° \_\_\_\_\_ = SC° \_\_\_\_\_

12. Compare results with the applicable table below.

**SC° (Subcooling) Values (F: +/-1.0° [C: +/-0.6°])  
Second Stage (High Capacity)**

If refrigerant added or removed, verify charge using the approach method



If value is greater than shown, remove refrigerant; if less than shown, add refrigerant



**Figure 57. Using HFC-410A Sub-cooling Method**

## APPENDIX A - UNIT CHARGING STICKERS

This section contains all published charging stickers for the various versions of this model. Below is a table listing the applicable sticker to unit model number.

**Table 27. Unit Charging Stickers by Model Number**

Unit Model Number	Unit Charging Sticker Numbers			
	401104S	580295-01	580449-01	580613-01
XC21-024-230-XX	-01, -02, -03, -04	-05, -06, -07	-08, -09	
XC21-036-230-XX	-01, -02, -03, -04	-05, -06, -07	-08, -09	
XC21-048-230-XX	-01, -02, -03, -04	-05, -06, -07	-08	-09
XC21-060-230-XX	-01, -02, -03, -04	-05, -06, -07, -09, -10	-08	-11

# XC21 CHARGING PROCEDURE

Units are factory charged with the amount of R-410A refrigerant indicated on the unit rating plate. This charge is based on a matching indoor coil and outdoor coil with 15 feet (4.6 m) line set.

The outdoor unit should be charged during warm weather. However, applications arise in which charging must occur in the colder months. *The method of charging is determined by the outdoor ambient temperature.* Before charging the unit, determine the liquid line temperature and the outdoor ambient temperature.

## Charge Using The Weigh-in Method—Outdoor Temperature < 65°F (18°C)

If the system is void of refrigerant, or if the outdoor ambient temperature is < 65°F (18°C), the refrigerant charge should be weighed into the unit. Do this after any leaks have been repaired.

- 1 - Recover the refrigerant from the unit.
  - 2 - Conduct a leak check, then evacuate the system as outlined in the installation instructions.
  - 3 - Weigh in the unit nameplate charge.
- If weighing facilities are not available or if you are charging the unit during warm weather, follow one of the other procedures outlined below.

## Charge Using The Subcooling Method—Outdoor Temperature < 65°F (18°C)

When the outdoor ambient temperature is below 65°F (18°C), use the subcooling method to charge the unit. It may be necessary to restrict the air flow through the outdoor coil to achieve pressures in the 325-375 psig (2240-2585 kPa) range. These higher pressures are necessary for checking the charge. Block equal sections of air intake panels and move obstructions sideways until the liquid pressure is in the 325-375 psig (2240-2585 kPa) range. See figure 1.

Block coil one side at a time with cardboard/plastic until proper testing pressures are reached.




Figure 1. Blocking Outdoor Coil

- 1 - With the manifold gauge hose still on the liquid service port and the unit operating stably, use a digital thermometer to record the liquid line temperature.
- 2 - At the same time, record the liquid line pressure reading.
- 3 - Use a temperature/pressure chart for R-410A to determine the saturation temperature for the liquid line pressure reading.
- 4 - Subtract the liquid line temperature from the saturation temperature (according to the chart) to determine subcooling (**Saturation temperature - Liquid line temperature = Subcooling Value**).
- 5 - Compare the subcooling value with those in table 1. If subcooling is greater than shown, recover some refrigerant. If subcooling is less than shown, add some refrigerant.

## Charge Using Normal Operating Pressures/Approach Method—Outdoor Temperature ≥ 65°F (18°C)

When the outdoor ambient temperature is above 65°F (18°C), use the approach method to charge the system. For best results, indoor temperature should be 70°F (21°C) to 80°F (26°C). Monitor system pressures while charging.

- 1 - Record outdoor ambient temperature using a digital thermometer.
- 2 - Attach high pressure gauge set and operate unit for several minutes to allow system pressures to stabilize.
- 3 - Compare stabilized pressures with those provided in table 3, "Normal Operating Pressures." Minor variations in these pressures may be expected due to differences in instal-

lations. Significant differences could mean that the system is not properly charged or that a problem exists with some component in the system. Pressures higher than those listed indicate that the system is overcharged. Pressures lower than those listed indicate that the system is undercharged. Verify adjusted charge using the approach method.


- 4 - Use the same digital thermometer used to check outdoor ambient temperature to check liquid line temperature. Verify the unit charge using the approach method.
- 5 - The difference between the liquid and ambient temperatures should match values given in table 2. If the values don't agree with the those in table 2, add refrigerant to lower the approach temperature or recover refrigerant from the system to increase the approach temperature.

## Using the Normal Operating Pressures Table


Use table 3 as a general guide when performing maintenance checks. This is not a procedure for charging the unit (Refer to Charging/Checking Charge section). Minor variations in these pressures may be expected due to differences in installations. Significant differences could mean that the system is not properly charged or that a problem exists with some component in the system.

Charging Temperatures and Pressures				
XC21 Model	-24	-36	-48	-60
<b>Table 1 - Subcooling Values</b>				
Saturation Temperature minus Liquid Line Temperature °F (°C) ± 1°F (0.5°C)				
Temp. °F (°C)	7.0 (3.9)	8.2 (4.6)	6.0 (3.3)	6.0 (3.3)
<b>Table 2 - Approach Values</b>				
Liquid Line Temperature minus Outdoor Ambient Temperature °F (°C) ± 1°F (0.5°C)				
Temp. °F (°C)	2.5 (1.4)	4.5 (2.5)	4.5 (2.5)	10 (5.5)
<b>Table 3 - Normal Operating Pressures (Liquid ±10 &amp; Suction ±5 psig)</b>				
Air Temperature Entering Outside Coil	The values below are typical pressures; indoor evaporator match up, indoor air quantity, and evaporator load will cause the pressures to vary.			
	Liquid Line Pressure / Vapor Line Pressure			
<b>First Stage (Low Capacity)</b>				
65°F (18°C)	205 / 148	214 / 148	215 / 140	228 / 137
75°F (24°C)	242 / 150	247 / 151	250 / 142	265 / 139
85°F (29°C)	281 / 152	286 / 152	288 / 144	396 / 142
95°F (35°C)	323 / 154	341 / 154	338 / 146	353 / 146
105°F (41°C)	372 / 156	381 / 156	387 / 149	400 / 149
115°F (46°C)	428 / 159	441 / 158	459 / 152	472 / 151
<b>Second Stage (Low Capacity)</b>				
65°F (18°C)	217 / 145	218 / 131	217 / 124	234 / 116
75°F (24°C)	250 / 147	253 / 141	251 / 133	273 / 125
85°F (29°C)	289 / 149	290 / 146	289 / 138	314 / 132
95°F (35°C)	336 / 151	339 / 149	336 / 141	360 / 139
105°F (41°C)	383 / 153	387 / 152	385 / 144	407 / 143
115°F (46°C)	438 / 155	443 / 154	437 / 146	461 / 147

04/05



401104S



# HFC-410A CHARGING PROCEDURE

**FOR COMPLETE CHARGING DETAILS, REFER TO THE OUTDOOR UNIT INSTALLATION INSTRUCTION.**

**AIRFLOW CHECK - Both airflow and refrigerant charge must be monitored for a proper system set-up. It may be necessary to alternately check and adjust the airflow and the refrigerant charge.**

*NOTE - Be sure that filters and indoor and outdoor coils are clean before testing.*

The unit is factory-charged with HFC-410A refrigerant in the amount indicated on the unit rating plate. This charge is based on a matching indoor coil and outdoor coil using a 15 foot (4.6 m) line set. The following charging procedure is intended as a general guide. It is intended for use on expansion valve systems only. For best results, indoor temperature should be between 70°F (21°C) and 80°F (27°C). Be sure to monitor system pressures while charging. Charging should be done with unit operating in the cooling mode.

- 1 - Connect the manifold gauge set to the service valves. Connect the low pressure gauge to vapor valve service port and the high pressure gauge to liquid valve service port. Connect the center manifold hose to an upright cylinder of HFC-410A. Close manifold gauge set valves.
- 2 - Set the room thermostat to call for heat. This will create the necessary load to properly charge the system in the cooling cycle.
- 3 - Use a digital thermometer to record the outdoor ambient temperature.
- 4 - When the heating demand has been satisfied, switch the thermostat to cooling mode with a set point of 68°F (20°C). When pressures have stabilized, use a digital thermometer to record the liquid line temperature.
- 5 - The outdoor temperature will determine which charging method to use. Proceed with the appropriate charging procedure.


**Using the Weigh-in Method—Outdoor Temperature 64°F (17.7°C) and below**

If the system is void of refrigerant, or if the outdoor ambient temperature is 64°F (17.7°C) and below, the refrigerant charge should be weighed into the unit. Do this after any leaks have been repaired.

- 1 - Recover the refrigerant from the unit.
  - 2 - Conduct a leak check, then evacuate as outlined in the installation instructions.
  - 3 - Weigh in the unit nameplate charge.
- If weighing facilities are not available or if you are charging the unit during warm weather, follow one of the other procedures outlined below.

**Using the Subcooling Method—Outdoor Temperature 65°F (18.3°C) and above**

Use the subcooling method to charge the unit. It may be necessary to restrict the air flow through the outdoor coil to achieve pressures in the 325-375 psig (2240-2585 kPa) range. These higher pressures are necessary for checking the charge. Block equal sections of air intake panels and move obstructions sideways until the liquid pressure is in the 325-375 psig (2240-2585 kPa) range. See figure 1.



Block coil one side at a time with cardboard/plastic until proper testing pressures are reached.

- 1 - With the manifold gauge hose still on the liquid service port and the unit operating stably, use a digital thermometer to record the liquid line temperature.
- 2 - At the same time, record the liquid line pressure reading.
- 3 - Use a temperature/pressure chart for HFC-410A to determine the saturation temperature for the liquid line pressure reading.
- 4 - Subtract the liquid line temperature from the saturation temperature (according to the chart) to determine subcooling (**Saturation temperature - Liquid line temperature = Subcooling Value**).
- 5 - Compare the subcooling value with those in table 1. If subcooling is greater than shown, recover some refrigerant. If subcooling is less than shown, add some refrigerant.

**Using the Approach Method—Outdoor Temperature 65°F (18.3°C) and above**


Monitor system pressures while charging.

- 1 - Record outdoor ambient temperature using a digital thermometer.
- 2 - Attach high pressure gauge set and operate unit for several minutes to allow system pressures to stabilize.
- 3 - Compare stabilized pressures with those provided in table 3, Normal Operating Pressures. Minor variations in these pressures may be expected due to differences in installations. Significant differences could mean that the system is not properly charged or that a problem exists with some component in the system. Pressures higher than those listed indicate that the system is overcharged. Pressures lower than those listed indicate that the system is undercharged. Verify adjusted charge using the approach method.
- 4 - Use the same digital thermometer used to check outdoor ambient temperature to check liquid line temperature. Verify the unit charge using the approach method.
- 5 - The difference between the liquid and ambient temperatures should match values given in table 2. If the values don't agree with the those in table 2, add refrigerant to lower the approach temperature or recover refrigerant from the system to increase the approach temperature.


## Charging Temperatures and Pressures

XC21 Model	-024	-036	-048	-060
<b>Table 1 - Subcooling Values</b>				
Saturation Temperature minus Liquid Line Temperature °F (°C) ± 1°F (0.5°C)				
Temp. °F (°C)	4.0 (2.2)	2.5 (1.4)	4.0 (2.2)	3.0 (1.7)
<b>Table 2 - Approach Values</b>				
Liquid Line Temperature minus Outdoor Ambient Temperature °F (°C) ± 1°F (0.5°C)				
Temp. °F (°C)	3.5 (1.9)	6.0 (3.3)	6.0 (3.3)	13.0 (7.2)
<b>Table 3 - Normal Operating Pressures (Liquid ±10 and Suction ±5 psig)</b>				
Air Temp*	The values below are typical pressures; indoor evaporator match up, indoor air quantity, and evaporator load will cause the pressures to vary.			
	Liquid Line Pressure / Vapor Line Pressure			
<b>First Stage (Low Capacity)</b>				
65°F (18°C)	209 / 144	211 / 142	215 / 140	229 / 134
75°F (24°C)	242 / 145	244 / 144	250 / 142	264 / 137
85°F (29°C)	281 / 146	285 / 146	288 / 144	306 / 140
95°F (35°C)	324 / 148	330 / 149	338 / 146	353 / 144
105°F (41°C)	372 / 151	380 / 151	387 / 149	405 / 146
115°F (46°C)	426 / 152	436 / 154	459 / 152	468 / 146
<b>Second Stage (High Capacity)</b>				
65°F (18°C)	213 / 138	214 / 137	217 / 124	238 / 130
75°F (24°C)	245 / 142	247 / 140	251 / 133	276 / 133
85°F (29°C)	285 / 142	288 / 141	289 / 138	317 / 135
95°F (35°C)	329 / 144	330 / 143	336 / 141	368 / 139
105°F (41°C)	376 / 147	384 / 145	385 / 144	420 / 141
115°F (46°C)	432 / 151	445 / 148	437 / 146	478 / 143
*Air temperature entering outside coil				

07/10



580295-01



# HFC-410A CHARGING PROCEDURE

**FOR COMPLETE CHARGING DETAILS, REFER TO THE OUTDOOR UNIT INSTALLATION INSTRUCTION.**

**AIRFLOW CHECK - Both airflow and refrigerant charge must be monitored for a proper system set-up. It may be necessary to alternately check and adjust the airflow and the refrigerant charge.**

*NOTE - Be sure that filters and indoor and outdoor coils are clean before testing.*

The unit is factory-charged with HFC-410A refrigerant in the amount indicated on the unit rating plate. This charge is based on a matching indoor coil and outdoor coil using a 15 foot (4.6 m) line set. The following charging procedure is intended as a general guide. It is intended for use on expansion valve systems only. For best results, indoor temperature should be between 70°F (21°C) and 80°F (27°C). Be sure to monitor system pressures while charging. Charging should be done with unit operating in the cooling mode.

- Connect the manifold gauge set to the service valves. Connect the low pressure gauge to vapor valve service port and the high pressure gauge to liquid valve service port. Connect the center manifold hose to an upright cylinder of HFC-410A. Close manifold gauge set valves.
- Set the room thermostat to call for heat. This will create the necessary load to properly charge the system in the cooling cycle.
- Use a digital thermometer to record the outdoor ambient temperature.
- When the heating demand has been satisfied, switch the thermostat to cooling mode with a set point of 68°F (20°C). When pressures have stabilized, use a digital thermometer to record the liquid line temperature.
- The outdoor temperature will determine which charging method to use. Proceed with the appropriate charging procedure.


**Using the Weigh-in Method—Outdoor Temperature 64°F (17.7°C) and below**

If the system is void of refrigerant, or if the outdoor ambient temperature is 64°F (17.7°C) and below, the refrigerant charge should be weighed into the unit. Do this after any leaks have been repaired.

- Recover the refrigerant from the unit.
  - Conduct a leak check, then evacuate as outlined in the installation instructions.
  - Weigh in the unit nameplate charge.
- If weighing facilities are not available or if you are charging the unit during warm weather, follow one of the other procedures outlined below.

**Using the Subcooling Method—Outdoor Temperature 65°F (18.3°C) and above**

Use the subcooling method to charge the unit. It may be necessary to restrict the air flow through the outdoor coil to achieve pressures in the 325-375 psig (2240-2585 kPa) range. These higher pressures are necessary for checking the charge. Block equal sections of air intake panels and move obstructions sideways until the liquid pressure is in the 325-375 psig (2240-2585 kPa) range. See figure 1.



Block coil one side at a time with cardboard/plastic until proper testing pressures are reached.

- With the manifold gauge hose still on the liquid service port and the unit operating stably, use a digital thermometer to record the liquid line temperature.
- At the same time, record the liquid line pressure reading.
- Use a temperature/pressure chart for HFC-410A to determine the saturation temperature for the liquid line pressure reading.
- Subtract the liquid line temperature from the saturation temperature (according to the chart) to determine subcooling (**Saturation temperature - Liquid line temperature = Subcooling Value**).
- Compare the subcooling value with those in table 1. If subcooling is greater than shown, recover some refrigerant. If subcooling is less than shown, add some refrigerant.

**Using the Approach Method—Outdoor Temperature 65°F (18.3°C) and above**

Monitor system pressures while charging.

- Record outdoor ambient temperature using a digital thermometer.
- Attach high pressure gauge set and operate unit for several minutes to allow system pressures to stabilize.
- Compare stabilized pressures with those provided in table 3, Normal Operating Pressures. Minor variations in these pressures may be expected due to differences in installations. Significant differences could mean that the system is not properly charged or that a problem exists with some component in the system. Pressures higher than those listed indicate that the system is overcharged. Pressures lower than those listed indicate that the system is undercharged. Verify adjusted charge using the approach method.
- Use the same digital thermometer used to check outdoor ambient temperature to check liquid line temperature. Verify the unit charge using the approach method.
- The difference between the liquid and ambient temperatures should match values given in table 2. If the values don't agree with the those in table 2, add refrigerant to lower the approach temperature or recover refrigerant from the system to increase the approach temperature.

## Charging Temperatures and Pressures

XC21 Model	-024	-036	-048	-060
<b>Table 1 - Subcooling Values</b>				
Saturation Temperature minus Liquid Line Temperature °F (°C) ± 1°F (0.5°C)				
Temp. °F (°C)	4.0 (2.2)	4.0 (2.2)	4.0 (2.2)	4.0 (2.2)
<b>Table 2 - Approach Values</b>				
Liquid Line Temperature minus Outdoor Ambient Temperature °F (°C) ± 1°F (0.5°C)				
Temp. °F (°C)	3.5 (1.9)	6.0 (3.3)	6.0 (3.3)	12.0 (6.7)
<b>Table 3 - Normal Operating Pressures (Liquid ±10 and Suction ±5 psig)</b>				
Air Temp*	The values below are typical pressures; indoor evaporator match up, indoor air quantity, and evaporator load will cause the pressures to vary.			
	Liquid Line Pressure / Vapor Line Pressure			
<b>First Stage (Low Capacity)</b>				
65°F (18°C)	209 / 144	211 / 142	215 / 140	229 / 134
75°F (24°C)	242 / 145	244 / 144	250 / 142	264 / 131
85°F (29°C)	281 / 146	285 / 146	288 / 144	306 / 133
95°F (35°C)	324 / 148	330 / 149	338 / 146	353 / 136
105°F (41°C)	372 / 151	380 / 151	387 / 149	405 / 137
115°F (46°C)	426 / 152	436 / 154	459 / 152	459 / 141
<b>Second Stage (High Capacity)</b>				
65°F (18°C)	213 / 138	214 / 137	217 / 124	238 / 130
75°F (24°C)	245 / 142	247 / 140	251 / 133	276 / 133
85°F (29°C)	285 / 142	288 / 141	289 / 138	317 / 135
95°F (35°C)	329 / 144	330 / 143	336 / 141	368 / 139
105°F (41°C)	376 / 147	384 / 145	385 / 144	420 / 141
115°F (46°C)	432 / 151	445 / 148	437 / 146	478 / 143
*Air temperature entering outside coil				

3/2012

2/2/32012/2

580449-01

2/580449-01/2



# HFC-410A CHARGING PROCEDURE

**FOR COMPLETE CHARGING DETAILS, REFER TO THE OUTDOOR UNIT INSTALLATION AND SERVICE PROCEDURE (CORP 1007-L2).**

**AIRFLOW CHECK - Both airflow and refrigerant charge must be monitored for a proper system set-up. It may be necessary to alternately check and adjust the airflow and the refrigerant charge.**

*NOTE - Be sure that filters and indoor and outdoor coils are clean before testing.*

The unit is factory-charged with HFC-410A refrigerant in the amount indicated on the unit rating plate. This charge is based on a matching indoor coil and outdoor coil using a 15 foot (4.6 m) line set. The following charging procedure is intended as a general guide. It is intended for use on expansion valve systems only. For best results, indoor temperature should be between 70°F (21°C) and 80°F (27°C). Be sure to monitor system pressures while charging. Charging should be done with unit operating in the cooling mode.

- 1 - Connect the manifold gauge set to the service valves. Connect the low pressure gauge to vapor valve service port and the high pressure gauge to liquid valve service port. Connect the center manifold hose to an upright cylinder of HFC-410A. Close manifold gauge set valves.
- 2 - Set the room thermostat to call for heat. This will create the necessary load to properly charge the system in the cooling cycle.
- 3 - Use a digital thermometer to record the outdoor ambient temperature.
- 4 - When the heating demand has been satisfied, switch the thermostat to cooling mode with a set point of 68°F (20°C). When pressures have stabilized, use a digital thermometer to record the liquid line temperature.
- 5 - The outdoor temperature will determine which charging method to use. Proceed with the appropriate charging procedure.


**Using the Weigh-in Method—Outdoor Temperature 64°F (17.7°C) and below**

If the system is void of refrigerant, or if the outdoor ambient temperature is 64°F (17.7°C) and below, the refrigerant charge should be weighed into the unit. Do this after any leaks have been repaired.

- 1 - Recover the refrigerant from the unit.
  - 2 - Conduct a leak check, then evacuate as outlined in the installation instructions.
  - 3 - Weigh in the unit nameplate charge.
- If weighing facilities are not available or if you are charging the unit during warm weather, follow one of the other procedures outlined below.

**Using the Subcooling Method—Outdoor Temperature 65°F (18.3°C) and above**

Use the subcooling method to charge the unit. It may be necessary to restrict the air flow through the outdoor coil to achieve pressures in the 325-375 psig (2240-2585 kPa) range. These higher pressures are necessary for checking the charge. Block equal sections of air intake panels and move obstructions sideways until the liquid pressure is in the 325-375 psig (2240-2585 kPa) range. See figure 1.



Block coil one side at a time with cardboard/plastic until proper testing pressures are reached.

- 1 - With the manifold gauge hose still on the liquid service port and the unit operating stably, use a digital thermometer to record the liquid line temperature.
- 2 - At the same time, record the liquid line pressure reading.
- 3 - Use a temperature/pressure chart for HFC-410A to determine the saturation temperature for the liquid line pressure reading.
- 4 - Subtract the liquid line temperature from the saturation temperature (according to the chart) to determine subcooling (**Saturation temperature - Liquid line temperature = Subcooling Value**).
- 5 - Compare the subcooling value with those in table 1. If subcooling is greater than shown, recover some refrigerant. If subcooling is less than shown, add some refrigerant.


**Using the Approach Method—Outdoor Temperature 65°F (18.3°C) and above**



Monitor system pressures while charging.

- 1 - Record outdoor ambient temperature using a digital thermometer.
- 2 - Attach high pressure gauge set and operate unit for several minutes to allow system pressures to stabilize.
- 3 - Compare stabilized pressures with those provided in table 3, Normal Operating Pressures. Minor variations in these pressures may be expected due to differences in installations. Significant differences could mean that the system is not properly charged or that a problem exists with some component in the system. Pressures higher than those listed indicate that the system is overcharged. Pressures lower than those listed indicate that the system is undercharged. Verify adjusted charge using the approach method.
- 4 - Use the same digital thermometer used to check outdoor ambient temperature to check liquid line temperature. Verify the unit charge using the approach method.
- 5 - The difference between the liquid and ambient temperatures should match values given in table 2. If the values don't agree with the those in table 2, add refrigerant to lower the approach temperature or recover refrigerant from the system to increase the approach temperature.

## Charging Temperatures and Pressures

XC21 Model	-024	-036	-048	-060
<b>Table 1 - Subcooling Values</b>				
Saturation Temperature minus Liquid Line Temperature °F (°C) ± 1°F (0.5°C)				
Temp. °F (°C)	4.0 (2.2)	4.0 (2.2)	4.0 (2.2)	4.0 (2.2)
<b>Table 2 - Approach Values</b>				
Liquid Line Temperature minus Outdoor Ambient Temperature °F (°C) ± 1°F (0.5°C)				
Temp. °F (°C)	3.5 (1.9)	6.0 (3.3)	6.0 (3.3)	12.0 (6.7)
<b>Table 3 - Normal Operating Pressures (Liquid ±10 and Suction ±5 psig)</b>				
Air Temp*	The values below are typical pressures; indoor evaporator match up, indoor air quantity, and evaporator load will cause the pressures to vary.			
	Liquid Line Pressure / Vapor Line Pressure			
<b>First Stage (Low Capacity)</b>				
65°F (18°C)	209 / 144	211 / 142	215 / 140	229 / 134
75°F (24°C)	242 / 145	244 / 144	250 / 142	264 / 131
85°F (29°C)	281 / 146	285 / 146	288 / 144	306 / 133
95°F (35°C)	324 / 148	330 / 149	338 / 146	353 / 136
105°F (41°C)	372 / 151	380 / 151	387 / 149	405 / 137
115°F (46°C)	426 / 152	436 / 154	459 / 152	459 / 141
<b>Second Stage (High Capacity)</b>				
65°F (18°C)	213 / 138	214 / 137	217 / 124	238 / 130
75°F (24°C)	245 / 142	247 / 140	251 / 133	276 / 133
85°F (29°C)	285 / 142	288 / 141	289 / 138	317 / 135
95°F (35°C)	329 / 144	330 / 143	336 / 141	368 / 139
105°F (41°C)	376 / 147	384 / 145	385 / 144	420 / 141
115°F (46°C)	432 / 151	445 / 148	437 / 146	478 / 143
*Air temperature entering outside coil				



580449-01  
 580449-01 

# HFC-410A CHARGING PROCEDURE

**FOR COMPLETE CHARGING DETAILS, REFER TO THE OUTDOOR UNIT INSTALLATION AND SERVICE PROCEDURE (CORP 1007-L2).**

**AIRFLOW CHECK - Both airflow and refrigerant charge must be monitored for a proper system set-up. It may be necessary to alternately check and adjust the airflow and the refrigerant charge.**

*NOTE - Be sure that filters and indoor and outdoor coils are clean before testing.*

The unit is factory-charged with HFC-410A refrigerant in the amount indicated on the unit rating plate. This charge is based on a matching indoor coil and outdoor coil using a 15 foot (4.6 m) line set. The following charging procedure is intended as a general guide. It is intended for use on expansion valve systems only. For best results, indoor temperature should be between 70°F (21°C) and 80°F (27°C). Be sure to monitor system pressures while charging. Charging should be done with unit operating in the cooling mode.

- 1 - Connect the manifold gauge set to the service valves. Connect the low pressure gauge to vapor valve service port and the high pressure gauge to liquid valve service port. Connect the center manifold hose to an upright cylinder of HFC-410A. Close manifold gauge set valves.
- 2 - Set the room thermostat to call for heat. This will create the necessary load to properly charge the system in the cooling cycle.
- 3 - Use a digital thermometer to record the outdoor ambient temperature.
- 4 - When the heating demand has been satisfied, switch the thermostat to cooling mode with a set point of 68°F (20°C). When pressures have stabilized, use a digital thermometer to record the liquid line temperature.
- 5 - The outdoor temperature will determine which charging method to use. Proceed with the appropriate charging procedure.

**Using the Weigh-in Method**—Outdoor Temperature 64°F (17.7°C) and below


If the system is void of refrigerant, or if the outdoor ambient temperature is 64°F (17.7°C) and below, the refrigerant charge should be weighed into the unit. Do this after any leaks have been repaired.

- 1 - Recover the refrigerant from the unit.
- 2 - Conduct a leak check, then evacuate as outlined in the installation instructions.
- 3 - Weigh in the unit nameplate charge.

If weighing facilities are not available or if you are charging the unit during warm weather, follow one of the other procedures outlined below.

**Using the Subcooling Method**—Outdoor Temperature 65°F (18.3°C) and above

Use the subcooling method to charge the unit. It may be necessary to restrict the air flow through the outdoor coil to achieve pressures in the 325-375 psig (2240-2585 kPa) range. These higher pressures are necessary for checking the charge. Block equal sections of air intake panels and move obstructions sideways until the liquid pressure is in the 325-375 psig (2240-2585 kPa) range. See figure 1.



**Figure 1. Blocking Outdoor Coil**

Block coil one side at a time with cardboard/plastic until proper testing pressures are reached.

- 1 - With the manifold gauge hose still on the liquid service port and the unit operating stably, use a digital thermometer to record the liquid line temperature.
- 2 - At the same time, record the liquid line pressure reading.
- 3 - Use a temperature/pressure chart for HFC-410A to determine the saturation temperature for the liquid line pressure reading.
- 4 - Subtract the liquid line temperature from the saturation temperature (according to the chart) to determine subcooling (**Saturation temperature - Liquid line temperature = Subcooling Value**).
- 5 - Compare the subcooling value with those in table 1. If subcooling is greater than shown, recover some refrigerant. If subcooling is less than shown, add some refrigerant.

**Using the Approach Method**—Outdoor Temperature 65°F (18.3°C) and above

Monitor system pressures while charging.

- 1 - Record outdoor ambient temperature using a digital thermometer.
- 2 - Attach high pressure gauge set and operate unit for several minutes to allow system pressures to stabilize.
- 3 - Compare stabilized pressures with those provided in table 3, Normal Operating Pressures. Minor variations in these pressures may be expected due to differences in installations. Significant differences could mean that the system is not properly charged or that a problem exists with some component in the system. Pressures higher than those listed indicate that the system is overcharged. Pressures lower than those listed indicate that the system is undercharged. Verify adjusted charge using the approach method.
- 4 - Use the same digital thermometer used to check outdoor ambient temperature to check liquid line temperature. Verify the unit charge using the approach method.
- 5 - The difference between the liquid and ambient temperatures should match values given in table 2. If the values don't agree with the those in table 2, add refrigerant to lower the approach temperature or recover refrigerant from the system to increase the approach temperature.

## Charging Temperatures and Pressures

XC21 Model	-024	-036	-048	-060
<b>Table 1 - Subcooling Values</b>				
Saturation Temperature minus Liquid Line Temperature °F (°C) ± 1°F (0.5°C)				
Temp. °F (°C)	4.0 (2.2)	4.0 (2.2)	4.0 (2.2)	5.0 (2.7)
<b>Table 2 - Approach Values</b>				
Liquid Line Temperature minus Outdoor Ambient Temperature °F (°C) ± 1°F (0.5°C)				
Temp. °F (°C)	3.5 (1.9)	6.0 (3.3)	6.0 (3.3)	12.0 (6.7)
<b>Table 3 - Normal Operating Pressures (Liquid +10 and Suction ±5 psig)</b>				
Air Temp*	The values below are typical pressures; indoor evaporator match up, indoor air quantity, and evaporator load will cause the pressures to vary.			
	Liquid Line Pressure / Vapor Line Pressure			
<b>First Stage (Low Capacity)</b>				
65°F (18°C)	209 / 144	211 / 142	215 / 140	233 / 133
75°F (24°C)	242 / 145	244 / 144	250 / 142	269 / 136
85°F (29°C)	281 / 146	285 / 146	288 / 144	312 / 137
95°F (35°C)	324 / 148	330 / 149	338 / 146	359 / 140
105°F (41°C)	372 / 151	380 / 151	387 / 149	408 / 144
115°F (46°C)	426 / 152	436 / 154	459 / 152	462 / 149
<b>Second Stage (High Capacity)</b>				
65°F (18°C)	213 / 138	214 / 137	217 / 124	243 / 129
75°F (24°C)	245 / 142	247 / 140	251 / 133	282 / 132
85°F (29°C)	285 / 142	288 / 141	289 / 138	325 / 135
95°F (35°C)	329 / 144	330 / 143	336 / 141	373 / 138
105°F (41°C)	376 / 147	384 / 145	385 / 144	424 / 141
115°F (46°C)	432 / 151	445 / 148	437 / 146	480 / 144

\*Air temperature entering outside coil

