

## **EL180UHNE**

**ELITE® SERIES** 

## Upflow / Horizontal - Constant Torque Blower Motor - 60 Hz

RESIDENTIAL PRODUCT SPECIFICATIONS


Bulletin No. 210801 June 2022 Supersedes November 2021





AFUE - 80% Meets NOx Limit of 14 ng/J Input - 40,000 to 100,000 Btuh Nominal Add-on Cooling - 1.5 to 5 Tons

## MODEL NUMBER IDENTIFICATION



<sup>&</sup>lt;sup>1</sup> Indoor coils with the same letter designation will physically match the furnace.

## **CONTENTS**

Blower Data	14
Approvals And Warranty	3
Dimensions	10
- Furnace/Coil Combined Dimensions	13
- Optional Accessories	12
- Unit - Horizontal Position	11
- Unit - Upflow Position	10
Features	
Gas Heat Accessories	
High Altitude Operation	
nstallation Clearances	8
Model Number Identification	1
Optional Accessories - Order Separately	
Specifications	

NOTE - EL180UHNE FURNACES ARE NOT AVAILABLE IN CANADA! NOTE - EL180UHNE 40K and 100K FURNACES ARE NATURAL GAS ONLY!

NOTE - NOT AVAILABLE IN ALL AREAS! CONTACT YOUR NEAREST LENNOX SALES OFFICE FOR DETAILS.

#### APPROVALS AND WARRANTY

#### **APPROVALS**

- · AHRI Certified
- Tested and rated according to US DOE test procedures and FTC labeling regulations
- Approved by the California Energy Commission and meets California Nitrogen Oxides Standard (NOx) limits of 14 ng/J
- ISO 9001 Registered Manufacturing Quality System
- · Blower data from unit tests conducted in Lennox Laboratory air test chamber

### California Only

 These furnaces meet the South Coast Air Quality Management District (SCAQMD) Rule 1111 and San Joaquin Valley Air Pollution Control District (SJVAPCD) Rule 4905 NOx emission limit (14 ng/J) and can be installed within the SCAQMD and SJVAPCD areas

## **WARRANTY**

- · Heat Exchanger:
- Limited twenty years in residential applications
- · Limited ten years in non-residential applications
- · All other covered components:
  - Limited five years in residential installations
  - · Limited one year in non-residential installations

NOTE - Refer to Lennox® Basic Limited Warranty at www.Lennox.com for additional details.

#### **FEATURES**

## **APPLICATIONS**

- Input capacities of 44,000, 66,000, 88,000, 110,000 and 132,000 Btuh
- Energy efficiency (AFUE) 80%
- Compact cabinet for upflow, horizontal-left or horizontalright applications
- Utility room, alcove, closet, crawl space, basement or attic installation
- Lennox add-on indoor coils, high-efficiency air cleaners and humidifiers can easily be added to furnace
- Shipped factory assembled with all controls installed and wired
- Ready for installation in upflow or horizontal position without any modifications
- Removable bottom seal panel shipped in place for side return air is easily removed for bottom/end return air applications
- Each unit factory test operated to ensure proper operation

#### **HEATING SYSTEM**

NOTE - Units Are Natural Gas Only!

## Heat Exchanger Assembly

- Heavy gauge aluminized steel heat exchanger
- Tubular type design
- Designed for normal expansion and contraction
- Round surfaces create minimum resistance to air flow for excellent heat transfer
- Heat exchanger has been laboratory life cycle tested in excess of industry standards
- Compact size of heat exchanger permits low overall design of furnace cabinet

## Burner Orifice/Air Intake Assembly

- Burner assembly has a single orifice located between the gas valve and the air intake assembly
- · Orifice is precisely matched to the burner input
- Burner can be removed for servicing

#### SureLight® Hot Surface Ignitor

- Tough, reliable, long-life, trouble-free performance
- Silicon nitride ignitor
- Cemented to steatite block for protection against current leakage
- Ignition leads are constructed of nickel plated copper and are enclosed in high temperature Teflon<sup>®</sup> insulation for dependable operation

## Modulating Gas Control Valve

 24 volt redundant combination modulating gas control valve combines manual shut off switch (On-Off), automatic electric valve (dual) and gas pressure regulation into a compact combination control

#### Variable-Speed Combustion Air Inducer

- Heavy duty variable-speed blower prepurges heat exchanger and safely vents flue products
- Pressure switch proves blower operation before allowing gas valve to open
- Operates only during heating cycle

### Thermal Switch

- · Factory installed on air/fuel intake assembly
- · Automatic reset
- Switch provides protection from abnormal operating conditions

## **HEATING SYSTEM (continued)**

#### Limit Control

- Primary limit is accurately located on vestibule panel on all units
- · Automatic reset

#### **Optional Accessories**

#### High Altitude Pressure Switch Kit

 Required on 40K and 100K natural gas units for proper operation at altitudes from 4501 to 7500 ft.

# Natural Gas to LPG/Propane Conversion Kit (60K and 80K Input Furnaces Only)

 Required for field changeover from natural gas to LPG/ Propane

6 in.

(152 mm)

7 in.

(178 mm)

· Includes gas and air orifices

## Vent Adaptor (Upflow Applications Only)

- Allows venting through a masonry chimney without the need of a flue liner
- Manual reset temperature sensor protects against abnormal operating conditions
- Sensor wiring may be routed from either side of adaptor
- Minimum winter design temperatures:
  - -10°F when used with interior masonry chimneys
  - +5°F when used with exterior masonry chimneys

**NOTE** - Refer to Winter Design Temperatures Map on page 8 for application information. Also refer to the installation instructions for detailed information.

#### **BLOWER**

- · Direct drive blower
- · Statically and dynamically balanced
- · Resiliently mounted
- Blower assembly easily removed for servicing

#### Power Saver™ Constant Torque Blower Motor

- DC Brushless Motor
- High Efficiency Constant Torque
- ECM (Electronically Commutated Motor)
- Motor is programmed to provide constant torque at each of the selectable speeds
- Motor is controlled by the Integrated Furnace Control
- Blower speeds are easily changed on the integrated furnace control
- See blower performance tables

#### **CONTROLS**

## SureLight® Integrated Furnace Control

- Control contains all necessary controls and relays to operate furnace
- Combustion air inducer is operated by the integrated furnace control
- Prior to ignition, a pre-purge cycle for 15 seconds is initiated
- After the main burners are turned off, a post-purge cycle for 5 seconds is run
- Flame sensor assures safe and reliable operation
- Should loss of flame occur the integrated furnace control will initiate 4 re-attempts at ignition before locking out unit operation for 60 minutes
- Watchguard type circuit automatically resets ignition controls after one hour of continuous thermostat demand after unit lockout, eliminating nuisance calls for service
- Fan control consists of adjustable blower timed-off delay (60, 90, 120, 180 seconds - factory setting 90 seconds) and fixed blower timed-on delay (30 seconds heating, 2 seconds - cooling)
- For air-conditioning applications, blower is automatically energized on thermostat demand for cooling
- Control has low speed continuous blower speed setting for humidifier or air cleaner operation
- Two accessory terminals furnished for additional power supply requirements for 120 volt (less than 1 amp) power humidifiers and powered air cleaners.
   One additional terminal is furnished for power supply requirements for 24V (less than 0.5 amp) low voltage accessories
- Ignition control has single red LED to indicate status and as an aid in troubleshooting
- Last five codes are stored in non-volatile memory (accessible by recall button on control) for servicing

#### 24 Volt Transformer

 Furnished and factory installed on outside of control box. 40VA transformer has circuit breaker wired in series

#### Field Wiring Make-up Box

- Furnished for line voltage wiring
- · Factory installed internally on left side of furnace
- · Box may be installed on right side of furnace

## **CONTROLS** (continued)

## Optional Accessories

## E30 Smart Wi-Fi Thermostat

- Wi-Fi enabled, electronic 7-day, universal, multi-stage, programmable, touchscreen thermostat
- · 3 Heat/2 Cool
- · Auto-changeover
- Controls dehumidification during cooling mode and humidification during heating mode
- Offers enhanced capabilities including humidification / dehumidification / dewpoint measurement and control, Humiditrol® control, and equipment maintenance reminders
- · Easy to read 7 in. color touchscreen (measured diagonally)
- LCD display with backlight shows the current and set temperature, time, inside relative humidity, system status (operating mode and schedules) and outside temperature (optional outdoor sensor required)
- Smooth Setback Recovery starts system early to achieve setpoint at start of program period
- Compressor short-cycle protection (5 minutes)
- Up to four separate schedules are available plus Schedule IO™
- One-Touch Away Mode A quick and easy way to set the cooling and heating setpoints while away
- Smart Away<sup>™</sup> Uses geo-fencing technology to determine when the homeowner is within a predetermined distance from the home to operate the system when leaving, away and arriving
- Wi-Fi remote monitoring and adjustment through a home wireless network for desktop PCs, laptops and apps for smartphones or tablets
- Smart home automation compatible with Apple HomeKit<sup>™</sup>, Amazon Alexa<sup>®</sup>, Google Assistant and IFTTT
- Service Dashboard features online real-time monitoring of installed Lennox<sup>®</sup> thermostats
- High Definition Color Display and Subbase, Smart Hub Controller, wallplate (for retrofit installations) furnished for easy installation
- See the E30 Smart Wi-Fi Thermostat Product Specifications bulletin for more information

#### Remote Outdoor Temperature Sensor

- Used with the E30 Smart Wi-Fi Thermostat
- When installed outdoors, sensor allows thermostat to display outdoor temperature





#### Thermostat

7:28 pm 🔐

- · Thermostat is not furnished with unit
- See Lennox Price Book for selection

## Blower Relay Kit (For Use With Two-Stage Outdoor Units)

 Allows furnace blower speed changes when matched with two-stage air conditioners or heat pumps

### **Furnace Twinning Panel**

- Required to operate two identical furnaces simultaneously from a single thermostat
- For single stage conventional (1 heat/1 cool), multistage conventional (2 heat/2 cool) and heat pump (3 heat/2 cool) equipment
- · Can be used with common or separate ducted systems
- Contains PC Control Board with terminal strip connections for thermostat and HVAC equipment
- · LEDs indicate system operating status
- Uses standard 18-gauge thermostat wire
- Power Supply: 24 VAC, 40VA (transformer not furnished)
- Mounting base with hardware furnished
- Dimensions (H x W x D): 10 x 5 x 2 in.

NOTE - Only identical furnaces should be twinned in order to ensure that both furnace blowers start at the same time. If furnaces are not identical, back draft dampers can be installed in either the supply or return duct.

Up to four identical furnaces can be twinned. Requires two panels that are wired together.

## Furnace Twinning Kit

- Required to operate two furnaces simultaneously
- Kit consists of twinning relays, quick connect terminals and mounting hardware
- Used for single-stage heating/single-stage cooling with a single-stage thermostat

#### Night Service Kit

- Contains most commonly used service parts:
  - Furnace Control
  - Ignitor
  - · Flame Sensor
- Gas Valve
- Transformer

## FILTER (not furnished)

Filter and provisions for external mounting must be field provided

### **Optional Accessories**

# Air Filter and Rack Kit for Horizontal Return Air (End) Applications

- Washable or vacuum cleanable polyurethane frame type filter and external end return air rack
- · Rack has filter door for servicing
- Flanges on rack for duct connection
- · Field installed
- · See dimension drawing

# Air Filter and Rack Kit for Upflow Side Return Air **NOTE** - Not for use with Return Air Base

- Washable or vacuum cleanable polyurethane frame type filter and external side return air rack available for field installation
- · Available in single and ten pack kits
- · Rack has filter door for servicing
- Flanges on rack for duct connection
- · Field installs on either side of unit cabinet
- · See dimension drawing

## **CABINET**

- NOTE Flue outlet is on top of cabinet only! If furnace is installed horizontally, the flue must be vented vertically after exiting the top of the cabinet (upflow furnace position) or end of the cabinet (horizontal furnace position)!
- Low-profile, narrow width cabinet allows easy installation
- · Heavy-gauge, cold rolled steel construction
- · Pre-painted cabinet finish
- Flanges provided on supply air opening for ease of plenum connection or alignment with indoor coil
- Insulated cabinet with foil faced insulation on sides and back of heating compartment and mat faced insulation in blower compartment
- Sealed blower compartment
- Inner blower compartment access panel seals blower compartment from air leakage
- · Cabinet door can be removed without any tools
- · Complete service access
- Safety interlock switch automatically shuts off power to unit when blower compartment access panel is removed
- Gas piping and electrical inlets are provided in both sides of cabinet on "B" and "C" width models.

**NOTE** - Gas piping is only available on the left side of the cabinet on "A" width models.

### Bottom/Side Return Air Entry:

- Upflow/horizontal with bottom return air entry:
  - Remove furnished bottom seal panel from cabinet
- · Upflow only with side return-air entry:
  - Corners are marked on either side of cabinet for return air cut-out
- See dimension drawings

**NOTE** - 60C size units that require air volumes over 1800 cfm must have one of the following:

- Single side return air and Optional Return Air Base with transition that must accommodate required 20 x 25 x 1 inch air filter to maintain proper velocity
- · Bottom return air
- · Return air from both sides
- · Bottom and one side return air
- See Blower Performance Tables for additional information

## Coil Match-Up

- All furnaces exactly match Lennox cased upflow indoor coils and horizontal indoor coils with same letter designation (A, B, C, D) in model number
- · No adaptor required
- · Engaging holes furnished on cabinet for alignment
- Lennox uncased coils match furnaces without any overhang but require an optional adaptor base or field fabricated transition to match furnace opening
- · See coil bulletin for additional information

## Low Leakage Cabinet

- · All models have less than 2% air leakage
- Meets ANSI/ASHRAE Standard 193-2010 "Method of Test for Determining the Air Tightness of HVAC Equipment"

### CABINET (continued)

## Optional Accessories

## Horizontal Suspension Kit

- Provides suspension of unit and indoor coil in horizontal applications
- Allows complete service access
- Consists of corner mounted hanging brackets with vibration isolators, return air end support rail and hardware for assembly
- Metal hanging straps must be field provided

#### Return Air Base

NOTE - On furnaces with side return air and condensate trap on the same side of the cabinet, a field fabricated transition or Return Air Base is required when using an IAQ product higher than 14-3/16 inches installed next to the unit and serviced from the front. IAQ products higher than 20 inches require a field fabricated transition.

**NOTE** - Must be used for 60C size models with air volumes over 1800 cfm in upflow applications when only one side return is required.

- · Cabinet is shipped flat for easy field assembly
- · Pre-painted steel to match the furnace
- · See Dimension Drawing

# High Performance Economizer (Commercial Applications Only)

- Designed for applications requiring outdoor air to be utilized in a commercial HVAC system
- Allows the entry of fresh outdoor air for free cooling, reducing the requirement for mechanical cooling
- Heavy gauge galvanized steel cabinet lined with thick fiberglass insulation
- Mixed air sensor, outdoor air sensor and 24VAC transformer furnished
- Approved for California Title 24 building standards. ASHRAE 90.1-2010 compliant
- See separate Product Specifications bulletin for additional information and available control and sensor options

#### 99% WINTER DESIGN TEMPERATURES FOR THE CONTIGUOUS UNITED STATES



This map is a necessarily generalized guide to temperatures in the contiguous Unites States. Temperatures shown for areas such as mountainous regions and large urban centers may not be accurate. The data used to develop this map was taken from the 1993 ASHRAE Fundamentals Handbook (Chapter 24, Table 1: Climate Conditions for the United States). Reprinted with permission from NFPA 54: National Fuel Gas Code 1999, National Fire Protection Association, Quincy, MA 02269. This reprinted material is not the complete and official position of the National Fire Protection Association on the referenced subject, which is represented only by the standard in its entirety.

## **INSTALLATION CLEARANCES**

#### **UPFLOW POSITION**

01 1 2011 1 00111011		
Vent Type	Type B1	Type C
Sides	1 (25)	<sup>1</sup> 1 (25)
Rear	1 (25)	1 (25)
Тор	1 (25)	1 (25)
Front	<sup>1</sup> 2-1/4 (57)	<sup>2</sup> 2-1/4 (57)
Front (service/alcove)	24 (610)	24 (610)
Floor	Combustible	Combustible
Flue	1 (25)	6 (152)

NOTE – Air for combustion must conform to the methods outlined in the National Fuel Gas Code (NFPA 54/ANSI-Z223.1).

## HORIZONTAL POSITION

Vent Type	Type B1	Type C
End	1 2	1 2
Rear	1 (25)	1 (25)
Тор	<sup>1</sup> 1 (25)	<sup>1</sup> 1 (25)
Front	2-1/4 (57)	2-1/4 (57)
Front (service)	24 (610)	24 (610)
Floor	Combustible	Combustible
Flue	1 (25)	6 (152)

NOTE – Air for combustion must conform to the methods outlined in the National Fuel Gas Code (NFPA 54/ANSI-Z223.1).

NOTE – In the U.S. flue sizing must conform to the methods outlined in the current National Fuel Gas Code (NFPA 54/ANSI-Z223.1) or applicable provisions of local building codes.

NOTE – In the U.S. flue sizing must conform to the methods outlined in the current National Fuel Gas Code (NFPA 54/ANSI-Z223.1) or applicable provisions of local building codes.

<sup>&</sup>lt;sup>1</sup> Left side requires 3 in. if single wall vent is used on 14-1/2 in. cabinets, 2 in. on 17-1/2 in. cabinets.

<sup>&</sup>lt;sup>2</sup> 4-1/2 in. if single wall vent pipe is used.

<sup>&</sup>lt;sup>1</sup> Line contact installation permissible between jacket top or sides and building joists.

SPECIFIC	ATIONS				
Gas	Model No.	EL180UH040NE36A	EL180UH060NE36A	EL180UH080NE48B	EL180UH100NE60C
Heating	AHRI Ref. No.	202028472	202028473	202028474	202028475
Performance	<sup>1</sup> AFUE	80%	80%	80%	80%
	Input - Btuh	40,000	60,000	80,000	100,000
	Output - Btuh	32,000	48,000	64,000	80,000
	Temperature rise range - °F	20 - 50	30 - 60	35 – 65	35 – 65
Gas Manifold I	Pressure (in. w.g.) Nat. Gas Only	1.8	3.4	3.4	304
High Static - in. w.g.		0.50	0.50	0.50	0.50
Connections	Flue connection - in. round	4	4	4	4
in.	Gas pipe size IPS	1/2	1/2	1/2	1/2
Indoor	Wheel nominal dia. x width - in.	10 x 8	10 x 8	10 x 10	11-1/2 x 10
Blower	Motor Type	DC Brushless	DC Brushless	DC Brushless	DC Brushless
	Motor output - hp	1/2	1/2	3/4	1
	Tons of add-on cooling	1.5 - 3	1.5 - 3	2.5 - 4	3 - 5
	Air Volume Range - cfm	350 - 1380	395 - 1415	750 - 1785	920 - 2315
Electrical	Voltage		120 volts - 60	hertz - 1 phase	
Data Blower motor full load amps		6.8	6.8	8.4	10.9
Maximum ove	rcurrent protection	15	15	15	15
Shipping Data	a lbs 1 package	113	113	125	149

NOTE - Filters and provisions for mounting are not furnished and must be field provided.

Annual Fuel Utilization Efficiency based on DOE test procedures and according to FTC labeling regulations. Isolated combustion system rating for non-weatherized furnaces.

## Car Width Models ## Width Models ## ## Models ## ## Models ## M	OPTIONAL ACCESS	ORIES - ORDER SEPARAT	FIY		
Horizontal Suspension Kit - Horizontal only   S1W10   S1W10   S1W10   Return Air Base - Upflow only   G5W75   50W98   50W98   50W98   50W98   High Performance Economizer (Commercial Only)   10U53	0. 1.011/12 /1.00200		"A" Width		"C" Width Models
Return Air Base - Upflow only	CABINET ACCESSORIES		'	'	'
High Performance Economizer (Commercial Only)   10U53   10U5	Horizontal Suspension Kit -	· Horizontal only	51W10	51W10	51W10
CONTROLS   E30 Smart Wi-Fi Thermostat   20A65   20A65   20A65   20A65   Remote Outdoor Temperature Sensor   X2658			65W75	50W98	50W99
E30 Smart Wi-Fi Thermostat   20A65   20A65   20A65   Remote Outdoor Temperature Sensor   X2658   X26	High Performance Econom	izer (Commercial Only)	10U53	10U53	10U53
Remote Outdoor Temperature Sensor   X2658   X2658   X2658   Blower Relay Kit (for two-stage outdoor units)   85W66	CONTROLS				
Blower Relay Kit (for two-stage outdoor units)   85W66   85W	E30 Smart Wi-Fi Thermosta	t	20A65	20A65	20A65
Y3653	Remote Outdoor Temperatu	ıre Sensor	X2658	X2658	X2658
Furnace Twinning Kit  FILTERS  Air Filter and Rack Kit  Horizontal (end) Size of filter - in.  Side Return Single Ten Pack Size of filter - in.  Size of filter - in.  16 x 25 x 1  17 x 25 x 1  18 x 25	Blower Relay Kit (for two-st	age outdoor units)	85W66	85W66	85W66
FILTERS  1 Air Filter and Rack Kit	Furnace Twinning Panel		Y3653	Y3653	Y3653
Air Filter and Rack Kit         Horizontal (end)         87L95         87L96         87L97           Size of filter - in.         14 x 25 x 1         18 x 25 x 1         20 x 25           Side Return Single Ten Pack         44J22         44J22         44J22           Size of filter - in.         16 x 25 x 1         16 x 25 x 1         16 x 25 x 1           SERVICE KIT           Night Service Kit         84W47         84W47         84W47           VENTING         44J22         44J22         44J22         44J22         44J22           44J22         <	Furnace Twinning Kit		16W72	16W72	16W72
Size of filter - in.       14 x 25 x 1       18 x 25 x 1       20 x 25         Side Return Single Ten Pack       44J22       44J22 </td <td>FILTERS</td> <td></td> <td></td> <td>•</td> <td>'</td>	FILTERS			•	'
Side Return Ten Pack         Single G6K63         44J22	<sup>1</sup> Air Filter and Rack Kit	Horizontal (end)	87L95	87L96	87L97
Ten Pack 66K63 66K63 66K63 Size of filter - in. 16 x 25 x 1 16 x 25 x 1 16 x 25 x 1  SERVICE KIT  Night Service Kit 84W47 84W47  VENTING		Size of filter - in.	14 x 25 x 1	18 x 25 x 1	20 x 25 x 1
Size of filter - in.       16 x 25 x 1       16 x 25 x 1       16 x 25 x 1         SERVICE KIT       84W47       84W47       84W47         VENTING       84W47       84W47		Side Return Single	44J22	44J22	44J22
SERVICE KIT Night Service Kit 84W47 84W47 84W47		Ten Pack	66K63	66K63	66K63
Night Service Kit 84W47 84W47 84W47 VENTING		Size of filter - in.	16 x 25 x 1	16 x 25 x 1	16 x 25 x 1
VENTING	SERVICE KIT				
	Night Service Kit		84W47	84W47	84W47
Vent Adaptor – 6 in. conn. size upflow applications only 18M79 18M79 18M79	VENTING				
Temporary Tempor	Vent Adaptor - 6 in. conn. s	size upflow applications only	18M79	18M79	18M79

<sup>&</sup>lt;sup>1</sup> Cleanable polyurethane, frame-type filter.

## HIGH ALTITUDE OPERATION

Units may be installed at altitudes up to 7500 ft. above sea level without any modification.


40K and 100K units installed at altitudes of 4501 to 7500 feet require a field installed High Altitude Pressure Switch. See table below.

GAS HEAT ACCESSORIES										
Input		Pressure Switch Kit 1 - 7500 ft.)	Natural Gas to LPG/Propane Kit							
	Natural Gas	LPG/Propane	0 - 7500 ft.							
040	20K91	N/A	N/A							
060	No Change	No Change	20P40							
080	No Change	N/A	20P41							
100	20K91	N/A	N/A							


- <sup>1</sup> NOTE 60C size units that require air volumes over 1800 cfm must have one of the following:
- 1. Single side return air and Optional Return Air Base with transition that must accommodate required 20 x 25 x 1 inch (508 x 635 x 25 mm) air filter to maintain proper velocity.
- 2. Bottom return air.
- 3. Return air from both sides.
- 4. Bottom and one side return air.


See Blower Performance Tables for additional information.

- <sup>2</sup> Flue outlet may be horizontal but furnace must be vented vertically
- 3 Optional External Side Return Air Filter Kit is not for use with the optional Return Air Base.
- 3 NOTE Gas entry is only available on the left side of the cabinet for "A" width cabinet models.



#### **TOP VIEW**






**FRONT VIEW** SIDE VIEW


Model No.	A	A	В		(		D	
	in.	mm	in.	mm	in.	mm	in.	mm
EL180UH040NE36A EL180UH060NE36A	14-1/2	368	13-3/8	340	13	330	4-3/4	121
EL180UH080NE48B	17-1/2	446	16-3/8	416	16	406	6-1/4	159
EL180UH100NE60C	21	533	19-7/8	504	19-1/2	495	8	203

#### **LEFT-HAND AIR DISCHARGE**




Model No	A	Α		В		;	D	
Model No.	in.	mm	in.	mm	in.	mm	in.	mm
EL180UH040NE36A EL180UH060NE36A	14-1/2	368	13-3/8	340	13	330	4-3/4	121
EL180UH080NE48B	17-1/2	446	16-3/8	416	16	406	6-1/4	159
EL180UH100NE60C	21	533	19-7/8	504	19-1/2	495	8	203

0/16



Furnace Cabinet Width	Catalog	A	A	E	3
	Number	in.	mm	in.	mm
Α	87L95	14	356	12-3/4	324
В	87L96	18	457	16-3/4	425
С	87L97	21	533	18-3/4	476

# Optional Return Air Base (Upflow Applications Only - For use with A, B and C width cabinets)



NOTE- Optional Side Return Air Filter Kits are not for use with Optional Return Air Base.

<sup>&</sup>lt;sup>1</sup> Both the unit return air opening and the base return air opening must be covered by a single plenum or IAQ cabinet.

Minimum unit side return air opening dimensions for units requiring 1800 cfm or more of air (W x H): 23 x 11 in. (584 x 279 mm).


The opening can be cut as needed to accommodate plenum or IAQ cabinet while maintaining dimensions shown.

Side return air openings must be cut in the field. There are cutting guides stenciled on the cabinet for the side return air opening. The size of the opening must not extend beyond the markings on the furnace cabinet.

<sup>&</sup>lt;sup>2</sup> To minimize pressure drop, the largest opening height possible, up to 14 in. (356 mm), is preferred.

## **UPFLOW POSITION**

		C35/CX35 Cased				_	35 ased	
Model No	Α		В		Α		В	
	in.	mm	in.	mm	in.	mm	in.	mm
C35/CX35-18/24A C35/CX35-18/24B	16-1/2	419	49-1/2	1257	14-1/8	359	47-1/8	1197
C35/CX35-24A C35/CX35-24B	18-1/2	470	51-1/2	1308	16-3/8	416	49-3/8	1254
	20-1/2	521	53-1/2	1359				
C35/CX35-30A C35/CX35-30B	22-1/2	572	55-1/2	1410	20-3/4	527	53-3/4	1365
C35/CX35-30/36A C35/CX35-30/36B C35/CX35-30/36C	24-1/2	622	57-1/2	1461	22-1/4	565	55-1/4	1403
C35/CX35-36A C35/CX35-36B	24-1/2	622	57-1/2	1461	22-3/8	568	55-3/8	1407
	24-1/2	622	57-1/2	1461				
C35/CX35-48B C35/CX35-48C	27-1/2	699	60-1/2	1537	26-1/4	667	59-1/4	1505
	24-1/2	622	57-1/2	1461				
C35/CX35-49C	29-1/2	749	62-1/2	1588	28-1/2	724	61-1/2	1562
C35/CX35-50/60C	27-1/2	699	60-1/2	1537	25-7/8	657	58-7/8	1495
CX35-60C	31-1/2	800	64-1/2	1638	30-5/8	778	63-5/8	1616



## **HORIZONTAL POSITION**

Ma	<i>A</i>	A	В		
IVIO	del No.	in.	mm	in.	mm
	С	H35			
CH35-18A, CH35-24A, CH35-24B, CH35-30B,	CH35-36A, CH35-36B, CH35-36C, CH35-42C, CH35-48C	26-1/2	673	59-1/2	1511
CH35-30A, CH35-42B, CH35-48B,	CH35-51C	31-1/2	880	64-1/2	1638
	CH	1X35			
CHX35-18A, CHX35-24A, CHX35-24B, CHX35-30B,	CHX35-36A, CHX35-36B, CHX35-36C, CHX35-42C, CHX35-48C	26-1/2	673	59-1/2	1511
CHX35-30A, CHX35-42B, CHX35-48B,	CHX35-51/61C	31-1/2	880	64-1/2	1638

## **BLOWER DATA**

## EL180UH040NE36A PERFORMANCE (Less Filter)

External				Air Volume	/ Watts at \	/arious Blo	wer Speeds	<b>;</b>		
Static Pressure	atic High					Medium (Blue)		<b>m-Low</b> low)		<b>DW</b> ed)
in. w.g.	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts
0.00	1430	243	1200	140	1025	86	945	66	945	45
0.10	1395	253	1165	151	1005	99	940	75	930	50
0.20	1370	264	1130	157	930	99	825	80	795	68
0.30	1345	278	1100	170	895	110	775	85	650	63
0.40	1320	289	1085	182	875	120	745	90	615	70
0.50	1295	302	1035	189	820	126	705	102	545	76
0.60	1245	308	1010	200	795	135	655	107	515	85
0.70	1220	320	980	210	755	147	615	115	445	87
0.80	1200	332	930	215	700	152	570	121	400	95

## EL180UH060NE36A PERFORMANCE (Less Filter)

External	Air Volume / Watts at Various Blower Speeds														
Static Pressure		<b>gh</b> ack)		<b>m-High</b> own)		<b>lium</b> ue)	111001101	<b>m-Low</b> low)	Low (Red)						
in. w.g.	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts					
0.00	1410	243	1190	141	1030	86	930	73	835	55					
0.10	1380	251	1165	150	990	95	890	89	790	65					
0.20	1360	264	1115	158	950	99	840	78	730	68					
0.30	1315	278	1090	171	910	110	790	89	660	61					
0.40	1295	290	1070	182	865	122	740	93	600	71					
0.50	1270	300	1025	191	825	127	695	103	545	75					
0.60	1235	300	1000	197	785	136	650	108	495	84					
0.70	1215	317	975	208	750	147	615	118	450	88					
0.80	1185	331	920	216	700	153	555	121	390	96					

#### EL180UH080NE48B PERFORMANCE (Less Filter)

External Static Pressure		Air Volume / Watts at Various Blower Speeds														
		<b>gh</b> ack)		<b>m-High</b> own)		<b>lium</b> ue)		<b>m-Low</b> low)	Low (Red)							
in. w.g.	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts						
0.00	1785	344	1570	236	1455	183	1390	161	1230	116						
0.10	1745	360	1535	249	1420	194	1360	172	1190	129						
0.20	1725	373	1500	266	1375	212	1310	189	1145	135						
0.30	1695	386	1475	279	1340	224	1280	201	1100	146						
0.40	1665	405	1440	293	1305	237	1235	208	1065	156						
0.50	1640	418	1410	307	1275	250	1190	223	1015	170						
0.60	1595	433	1370	323	1235	263	1160	234	970	182						
0.70	1570	446	1330	336	1190	277	1120	249	930	187						
0.80	1530	461	1300	349	1155	289	1095	260	900	201						

## **BLOWER DATA**

## EL180UH100NE60C (Less Filter)

				,																
							Air V	olume	/ Wat	ts at D	iffere	nt Blo	wer S	peeds						
Evtornol	Bottom Return Air, Side Return Air with Return Air from Both Sides or Return Air from Bottom and One Side.											Single Side Return Air - Air volumes in <b>bold</b> require Optional Return Air Base <u>and</u> field fabricated transition to accommodate 20 x 25 x 1 in. air filter in order to maintain proper air velocity.								
Pressure in. w.g.	High (Black) Mediu		edium- High Brown) Medium (Blue)			Medium- Low (Yellow)		Low (Red)		High (Black)		Medium- High (Brown)		Medium (Blue)		Medium- Low (Yellow)		Low (Red)		
	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts
0.00	2205	623	1950	415	1710	275	1575	220	1425	160	2235	595	1945	382	1725	262	1590	202	1430	165
0.10	2175	639	1910	427	1685	287	1545	234	1400	176	2205	611	1915	397	1695	280	1550	218	1400	193
0.20	2145	658	1885	449	1635	309	1490	246	1325	181	2165	629	1885	424	1660	293	1510	235	1335	175
0.30	2100	681	1845	466	1605	327	1465	259	1275	196	2135	652	1850	441	1615	312	1475	247	1275	182
0.40	2095	700	1815	481	1565	337	1415	280	1225	204	2085	676	1800	456	1580	330	1430	261	1240	197
0.50	2045	717	1780	499	1525	356	1375	286	1195	218	2055	685	1775	474	1535	347	1395	281	1195	206
0.60	2025	737	1735	516	1500	374	1350	304	1145	230	2025	700	1755	494	1505	359	1355	300	1155	222
0.70	1995	746	1715	533	1465	389	1320	323	1090	248	1990	720	1725	515	1480	377	1310	308	1120	237
0.80	1950	769	1675	547	1430	401	1255	331	1065	259	1965	742	1685	532	1445	396	1275	325	1060	248

REVISIONS						
Sections	Description of Change					
Specifications	Outputs updated.					







Visit us at <a href="https://www.Lennox.com">www.Lennox.com</a>
For the latest technical information, <a href="https://www.LennoxPros.com">www.LennoxPros.com</a>
Contact us at 1-800-9-LENNOX