

*IMPORTANT – The conduit hole must be positioned carefully to avoid contact between the blocked vent switch wiring and the combustion air inducer or hot* 

VENT ADAPTER KIT CONDUIT PLACEMENT TEMPLATE



