

©2016 Lennox Industries Inc. Dallas, Texas, USA



AWARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life.

Installation and service must be performed by a licensed professional HVAC installer (or equivalent) or service agency. Be sure that power supply has been turned off before beginning installation.

Do not operate equipment with wet hands.

INSTALLATION/ OPERATION

INSTRUCTIONS

HHE Relay Kit V0CTRL92P-1

VRF SYSTEMS -- HHE Relay Kit 507568-02 05/2016

THIS MANUAL MUST BE LEFT WITH THE OWNER FOR FUTURE REFERENCE

AWARNING Do not install equipment in areas where heavy oil, vapor, or gases containing sulfur may exist or it may be damaged.

IMPORTANT!

These instructions are intended as a general guide and do not supersede local codes in any way. Consult authorities having jurisdiction before installation. Read all of the information in this manual before operating this equipment.

Shipping and Packing List

Package 1 of 1 contains:

- 1 Four-Dry Contact board
- 1 Plastic mounting base (VWMA installation)
- 1 Double-sided tape
- 1 Mounting bracket (VMDA007-012 installation)
- 4 Plastic feet
- 1 14-1/2 inches (370 mm) cable
- 1 Installation manual

General

The installation location of the HHE relay kit varies between indoor units.

Installation steps are similar for each indoor unit. See indoor unit sections of this guide for specific indoor unit installation information.

See HHE Relay Kit Submittal for equipment compatibility.



VMDA007-012 Use Provided Mounting Bracket



VWMA Use Provided Plastic Mounting Box

Installation




Figure 1. Principle Electrical Diagram of HHE Relay

- 1. Turn off power to the unit.
- 2. Access the indoor unit electrical control box and remove the phillips-head screws securing the cover.
- Attach the four plastic mounting feet to the bottom of the four-dry contact control board (except for VWMA and V22A units) by pressing the pointed end of the plastic foot through the provided hole in the board and securing the clip to the edge of the board. See figure 2.
- Connect one end of the provided wiring harness to the four-dry contact control board.
- Secure the four-dry contact control board inside the indoor unit control box by pressing the four plastic feet attached to the bottom of the control board

through four holes provided in the unit control box (except for VWMA and VMDA007-012 units). See figure 2 and individual indoor unit sections. **NOTE** - Each indoor unit style has a specific location for mounting. See the next pages for detailed installation images depending on style.

- Locate the indoor unit main board, Yellow CN labeled "HEATER RELAY" and connect the other end of the provided wiring harness. See figure 3.
- Use the phillips-head screws previously removed to secure indoor unit electrical control box cover and close any indoor unit panels.
- 8. Restore power to the unit.



Figure 2. Mounting Feet Installed





Figure 3. Completed Installation (VCFA Shown)

V33A Cassette




The four-dry contact board mounting location is located in the control box on the opposite side from the transformer.

NOTE- Removal of indoor unit main board is required for connection.

Figure 4. V33 Cassette Installation

V22A Compact Cassette



The four-dry contact board mounting location is located between the blower fan housing and the control box edge.


NOTE- Removal of indoor unit main board is required for connection.

Partial installation shown.

- 1. Open clip.
- 2. Slide four-dry contact board into slot.
- 3. Close clip.

Figure 5. V22 Compact Cassette Installation Location


V22A Compact Cassette Cont.



Complete installation shown.

Figure 6. V22 Compact Cassette Installation Complete

VHIA Ducted VHIA024-054



The four-dry contact board mounting location is located below and to the right side of the LED display in the control box.

Figure 7. VHIA024-054 Ducted Installation Complete

VHIA Ducted VHIA072-096



The four-dry contact board mounting location is located next to the transformer in the control box.

Figure 8. VHIA072-096 Ducted Installation Complete


VCFA Ceiling/Floor Mount VCFA012-048



The four-dry contact board mounting location is located next to the transformer in the control box.

Figure 9. VCFA012-048 Ceiling/Floor Mount Installation Complete

VCFA Ceiling/Floor Mount VCFA054



The four-dry contact board mounting location is located near the fan relay board in the control box.

Figure 10. VCFA054 Ceiling/Floor Mount Installation Complete

VMDA Medium Static Ducted VMDA007-012




Figure 11. VMDA007-012 Medium Static Ducted Installation Complete

Medium Static Ducted VMDA007-012 units installation requires the use of a factory-supplied mounting bracket.

The four-dry contact board mounting location is located on the top of the electrical box above the main board.

Follow these steps for installation.

- 1. Secure mounting bracket using two screws (field-supplied).
- Mount the four-dry contact board directly to the mounting bracket following the instructions on page 2.

VMDA Ducted VMDA015-048



The four-dry contact board mounting location is located on the side of the electrical box opposite the power wiring terminal block.

Figure 12. VMDA Ducted VMDA015-048

VWMA Wall-Mounted

NOTE- Removal of indoor unit main board is required for connection.




Figure 13. VWMA Required Kit Contents

Wall-mounted indoor unit models 3. require the four-dry contact board to be installed using the provided plastic box.

- 1. Turn off power to the indoor unit.
- 2. Raise the indoor unit front panel and remove the phillips-head screws securing the indoor unit control box cover.

Locate the indoor unit main board, CN labeled "HEATER RELAY" and connect one end of the provided wiring harness. See figure 3.

 Secure four-dry contact board control board into plastic box using double sided tape. See figures 14 and 15.




Figure 14. VWMA007-018 Install Inside of Control Box

VWMA Wall-Mounted Cont.



- Connect other end of provided 7. wiring harness to the yellow connection on the four-dry contact control board. See fig- 8. ure 3.
- VWMA07-018 units Use a field-provided screw to secure the plastic box inside the indoor unit control box. See figure 14.
 VWMA024-030 units - Use a field-provided screw to secure the plastic box to the outside of the indoor unit control box cover. See figure 15.
- Use phillips-head screws to secure indoor unit electrical control box cover.
- Restore power to the unit.

Figure 15. VWMA024-030 Install Outside of Control Box

VVCA Vertical Air Handler



The four-dry contact board mounting location is located near the transformer in the control box.

Figure 16. VVCA Vertical Air Handler Installation Complete

Dry Contact Connections

The dry contact connections are used to provide a signal to up to four devices. Use these instructions for connecting a device to the four-dry contact board.

- 1. Turn off power to the unit.
- 2. Access the indoor unit electrical control box and remove the phillips-head screws securing the cover.
- Make connections. See figure 16.
- Use phillips-head screws to secure indoor unit electrical control box cover and close any indoor unit panels.
- 5. Restore power to the unit.

Table 1. Dry Contact Specifications

Max Amps	1A
Max Voltage	e 24V




Figure 17. Dry Contact Connection