



Replacement Guide for iComfort S30 HD Display (12X97)

WARNING: Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a qualified installer, service agency or the gas supplier



REMOVING EXISTING HD DISPLAY

1. Disconnect power to the entire system.
2. To remove HD display from MAG-MOUNT base rotate in either direction the HD display 30 degrees and pull away from wall to remove. **Failure to rotate display before pulling off requires much more force to be used and may pull out wall anchors.**

HD DISPLAY INSTALLATION

1. Line up HD display with MAG-MOUNT base.
2. Insert bottom of the HD display at 30 degree angle into tabs at bottom of the MAG-MOUNT wall base.
3. Rotate the HD display upward until it snaps into place by pressing on sides.
4. Do not remove the label covering the HD Display screen until after power is applied to the system.
5. Restore power to system.
6. Remove label covering the HD Display screen.

0815



507542-01