






KEY	DESCRIPTION	COMPONENT
K32-1	RELAY-ELECTRIC HEAT	

NOTE: USE COPPER CONDUCTORS ONLY
HEAT RELAY CONTROLS 4 AND 2 MUST BE USED WITH CONTROL BOILER WHEN CONFIGURED WITH Icomfort ONLY



KEY	DESCRIPTION	COMPONENT
K32-1	RELAY-ELECTRIC HEAT	

NOTE: USE COPPER CONDUCTORS ONLY
HEAT RELAY CONTROLS 4 AND 2 MUST BE USED WITH CONTROL BOILER WHEN CONFIGURED WITH Icomfort ONLY



HEATING-ELECTRIC	
HOT WATER ON DEMAND	
1211	Supersedes
New Form No.	
537516-01	

HEATING-ELECTRIC	
HOT WATER ON DEMAND	
1211	Supersedes
New Form No.	
537516-01	