



J/P	JACKPLUG DESCRIPTION
2	HEAT
18	EXHAUST FAN COMP1
24	EXHAUST FAN
35	TEST
36	TEST COOL
47	OUTDOOR FAN 1
52	OUTDOOR FAN 2
86	OUTDOOR FANS 1,2,3
106	OUTDOOR FAN 3
132	EXHAUST FAN MOTOR 1
133	EXHAUST FAN MOTOR 2
246	POWER TO VFD
247	POWER VFD TO MOTOR
248	VFD CONTROL
249	CONTACTOR BYPASS
250	SMOKE DETECTOR ONE
251	SMOKE DETECTOR ONE
252	SMOKE DETECTOR TWO
253	SMOKE DETECTOR TWO
255	MODULE CONTROL SMOKE DETECTION
324	VFD OPTION CONNECTION
325	K3 BLOWER CONTROL
326	PHASE MONITOR VFD CONTROL ADD ON
327	PHASE MONITOR VFD CONTROL ADD ON
328	VFD BLOWER CONTROL

KEY	COMPONENT
A42	MONITOR, PHASE PROTECTION
A46	CONTROL INVERTER
A171	SENSOR ONE, SMOKE RETURN AIR
A172	SENSOR TWO, SMOKE SUPPLY AIR
A173	MODULE CONTROL SMOKE DETECTION
A183	CONTROL, VFD BOARD
B1	COMPRESSOR 1
B2	COMPRESSOR 2
B3	MOTOR, BLOWER
B4	MOTOR, OUTDOOR FAN 1
B5	MOTOR, OUTDOOR FAN 2
B10	MOTOR, EXHAUST FAN 1
B11	MOTOR, EXHAUST FAN 2
B13	COMPRESSOR 3
B21	MOTOR, OUTDOOR FAN 3
C1	CAPACITOR, OUTDOOR FAN 1
C2	CAPACITOR, OUTDOOR FAN 2
C6	CAPACITOR, EXHAUST FAN 1
C8	CAPACITOR, EXHAUST FAN 2
C18	CAPACITOR, OUTDOOR FAN 3
C88	CIRCUIT, BREAKER T1
CB10	CIRCUIT, BREAKER MAIN DISCONNECT
CB18	DELAY, OVERFLOW SWITCH
DL46	FUSE, EXHAUST FANS
F6	HEADER 2, LVCI
H2	HEATER, COMPRESSOR 1
HR1	HEATER, COMPRESSOR 2
HR2	HEATER, COMPRESSOR 3
HR5	HEATER, COMPRESSOR 3
J11	JACK, GFI RECEPTACLE
J261	JACK, SMOKE DETECTOR JUMPER
K1-1	CONTACTOR, COMPRESSOR 1
K2-1	CONTACTOR, COMPRESSOR 2 & 3
K3-1	CONTACTOR, BLOWER
K10-1,2	RELAY, OUTDOOR FAN
K14-1	CONTACTOR, COMPRESSOR 3
K14-2	RELAY, EXHAUST FAN 1
K68-1,2	RELAY, STAGE COOL 1
K67-1	RELAY, STAGE COOL 2
K67-2	RELAY, OUTDOOR FAN 2
K203-2	RELAY, VFD RUN
K220-1	RELAY, OVERFLOW SWITCH
K232	RELAY, INVERTER PROTECTION
S4	SWITCH, LIMIT HI PRESS COMP (MANUAL RESET)
S7	SWITCH, LIMIT HI PRESS COMP 2 (MANUAL RESET)
S11	SWITCH, LOW PRESS, LOW AMBIENT KIT COMP 1
S28	SWITCH, LIMIT HI PRESS COMP 3 (MANUAL RESET)
S48	SWITCH, DISCONNECT
S49	SWITCH, FREEZE/STAT COMP 1
S50	SWITCH, FREEZE/STAT COMP 2
S53	SWITCH, FREEZE/STAT COMP 3
S54	SWITCH, LOW PRESS, LOW AMBIENT KIT COMP 2
S85	SWITCH, LOW PRESS, LOW AMBIENT KIT COMP 3
S149	SWITCH, OVERFLOW
T1	TRANSFORMER, CONTROL
T18	TERMINAL STRIP, POWER DISTRIBUTION
TB13	TERMINAL STRIP, POWER DISTRIBUTION

NOTE - FOR USE WITH COPPER CONDUCTORS ONLY REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE.

P21 IS USED ON KCA UNITS ONLY

CONNECT A172 SENSOR TO J261 ON SUPPLY AIR

SMOKE DETECTOR ONLY

S48 OR CB10 MAY BE USED

F6 ONLY USED ON "V" VOLTAGE UNITS WITH FIELD INSTALLED POWER EXHAUST

TO BYPASS A96 VFD: DISCONNECT ALL POWER UNPLUG - J246 FROM P246; AND UNPLUG J247 FROM P247. UNPLUG - P249 INTO J246; AND PLUG J249 INTO P247. UNPLUG - J326 FROM P324; AND UNPLUG J324 FROM P327 PLUG - P324 INTO J324

mitsubishi vfd

10/14

WIRING DIAGRAM

537605-01

COOLING

KCA/KGA - 210S,156H - G,J,Y - VFD

SECTION B

Supersedes

New Form No. 537605-01

REV. 2

NOTE - IF ANY WIRE IN THIS APPLIANCE IS REPLACED IT MUST BE REPLACED WITH WIRE OF LIKE SIZE, RATING, TERMINATION AND INSULATION THICKNESS

WARNING - ELECTRIC SHOCK HAZARD, CAN CAUSE INJURY OR DEATH UNIT MUST BE GROUNDED IN ACCORDANCE WITH NATIONAL AND LOCAL CODES

DISCONNECT ALL POWER BEFORE SERVICING.

DENOTES OPTIONAL COMPONENTS

LINE VOLTAGE FIELD INSTALLED

