



- ▲ NOTE - FOR USE WITH COPPER CONDUCTORS ONLY REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE.
- ▲ IMPORTANT: TO PREVENT MOTOR BURNDOUT, NEVER CONNECT MORE THAN ONE MOTOR LEAD TO ANY ONE CONNECTION. TAPE UNUSED MOTOR LEADS
- ▲ P.Y VOLT T1 WITH 208V TAP
- ▲ T3 USED ON 480V AND 600V UNITS
- ▲ LOW AMBIENT KIT
- ▲ THERMOSTAT/SENSOR SUPPLIED BY USER
- ▲ TIME CLOCK CONTACTS (OPT) CLOSED OCCUPIED
- ▲ OUTDOOR AIR TEMPERATURE SENSOR RT26 OR USED. OUTDOOR AIR ENTHALPY SENSOR A7 MAY BE USED. MAKE CONNECTION AS SHOWN.
- ▲ K72 AND GV1 2 STG ARE USED ON TWO STAGE UNITS.
- ▲ ADD J21, P21 AND S43 FOR TWO STAGE LIQUID PROPANE UNITS. USE FOR EXHAUST FAN 2 OUTPUT OR ERV OR SYSTEM ALARM OUTPUT.
- ▲ ZGA 036,048,060 ONLY.
- ▲ ZGB MODELS ONLY.
- ▲ ZGA 072 ONLY.Y,DL48 NOT USED.

01/15  
 WIRING DIAGRAM  
 537710-02  
 UNIT DIAGRAM  
 ZGA 036,048,060,072  
 ZGB 036,048,060  
 SECTION ALL  
 REV. 0



Supersedes  
 537710-01  
 New Form No.  
 537710-02