



- ⚠ K3 CONTACTOR IS DISABLED AND IS BEING USED AS A TERMINAL BLOCK
- ⚠ ENERGIZING K3 COIL WILL BLOW THE INVERTER

KEY	COMPONENT
A96	INVERTER
A133	CONTROL, GENERAL PURPOSE
B3	MOTOR, BLOWER
K3, -1	CONTACTOR, BLOWER
K203	RELAY, INVERTER CONTROL
L29	COIL, CHOKE

J/P	JACK/PLUG DESCRIPTION
248	VFD CONTROL

← DENOTES OPTIONAL COMPONENTS
 — LINE VOLTAGE FIELD INSTALLED

09/14		WIRING DIAGRAM	09/14
		537746-01	
COOLING			
MSAV BLOWER - NO BYPASS			
SECTION B3			REV. 0
Supersedes		New Form No. 537746-01	