



LGH/LCH094U, 122U, 152U Parts Arrangement


(ALL COMPONENTS SHOWN; NOT ALL COMPONENTS ARE ON EACH UNIT)




DISCONNECT BOX PRESSURE SWITCHES




TOP VIEW




END VIEW




FRONT VIEW



CONTROL AREA



HINGED PANEL IN CONTROL AREA



BACK VIEW - ECONOMIZER SECTION