

## Running the Software

Select **Start - Programs - Lennox - Commercial Controls - L Connection Software** or double click the L Connection Software icon on the desktop if one has been created.

If the program is running correctly the following start-up screen will be displayed.

Click on **Manuals** to view manuals; click on **Network Control Panel Software** to start the NCP software; or click **Exit** to exit program.

*Note - Unit Controller Software will only appear if it is installed (purchased separately).*



# NCP Software

Version 2.08



505,079M

7/2006

Supersedes 8/2005

TP Technical  
Publications  
Litho U.S.A  
© 2006

## Application

Network Control Panel (NCP) Software (96L82) is used locally or remotely to monitor the network and setup programs with new day schedules and holidays to the NCP.

Holidays, programs, and day schedules can be created off-site, saved to a text file, transported to the job site, and uploaded to the NCP.

*IMPORTANT - For serial port connection, PC to L Connection Converter Kit (96L78) is required to access the NCP. Connect the converter between the PC RS232 port and the L Connection network port on the NCP using the spiral phone cord provided with the converter kit.*

## Installation

Install the NCP software to a PC hard drive:

- 1- Place the CD in the CD-ROM drive and it will auto-run. If the CD does not auto-run, select **Start-Run**, browse the CD, and locate the "Setup.exe" file. Click **OK**.
- 2- Follow the installation instructions on the screen.


07/06



505,079M



## SOFTWARE SCREEN INDEX



**NOTE - Page numbers refer to Software User's Manual.**