


# C2ECON23K

# **High Performance Economizer Dampers**

Bulletin No. 210750 June 2016 Supersedes April 2016

#### PRODUCT SPECIFICATIONS



## **FEATURES**

#### **Approvals**

Approved for California Title 24 building standards. ASHRAE 90.1-2010 compliant.

#### **Application**

Designed for applications requiring outdoor air to be utilized in a HVAC system. The economizer unit will allow the entry of fresh outdoor air for free cooling, reducing the requirement for mechanical cooling.

Economizer dampers will modulate to maintain 55°F supply air when outdoor air is suitable.

Economizer features rack and pinion operation, high torque 24-volt fully-modulating spring return damper motor, return air and outdoor air dampers, nylon bearings, enhanced neoprene blade edge seals and flexible stainless steel jamb seals to minimize air leakage.

NOTE - Economizer is not approved for use with enthalpy controls in Title 24 applications.

#### Cabinet

Damper cabinet is constructed of heavy gauge galvanized steel and is lined with thick fiberglass insulation.

Duct Connections have flanges for ease of installation.

Large access panels on both sides of the cabinet provide complete service entry. Panels have handles for ease of removal.

## **Mixed Air Sensor**

Furnished for installation in the supply air duct.

#### **Outdoor Air Sensor**

Furnished for installation in the outdoor air inlet. Sensor is a CEC approved, California Title 24 fixed dry bulb device

#### **Transformer**

Transformer (120/24V/75VA) is furnished for replacement of existing 40VA transformer in furnace or air handler.

#### **FEATURES**

# High Performance Economizer Control Module

Module provides inputs and outputs to control economizer based on parameter settings.

Module automatically detects sensors by polling to determine which sensors are installed in system.



Module displays any alarm messages (fault detection and diagnostics) as an aid in troubleshooting.

Non-volatile memory retains parameter settings in case of power failure.

Keypad with four navigation buttons and LCD screen is furnished for setting economizer parameters.

- Menu Up/Exit button returns to the main menu.
- Arrow Up ▲ button moves to the previous or next parameter within the selected menu.
- Arrow Down ▼ button moves to the next parameter within the selected menu.
- Select (enter) ← button confirms parameter selection.

#### Main Menu Structure:

- STATUS (economizer and system operation status)
- SETPOINTS (settings for various setpoint parameters)
- SYSTEM SETUP (settings/information about the system)
- ADVANCED SETUP (freeze protection, CO<sub>2</sub> settings, stage 3 delay and additional calibration settings)
- CHECKOUT (damper positions)
- ALARMS (output signal that can be configured for remote alarm monitoring)

NOTE - The Free Cooling setpoint for Title 24 applications must be set based on the Climate Zone where the system is installed. See Section 140.4 "Prescriptive Requirements for Space Conditioning Systems" of the California Energy Commission's 2013 Building Energy Efficiency Standards.

Refer to Installation Instructions for complete setup information and menu parameters available.

# **Options/Accessories**

# Single Enthalpy Temperature Control (Not for Title 24)

Outdoor air enthalpy sensor enables Economizer if the outdoor enthalpy is less than the setpoint of the control.

# **Differential Enthalpy Control (Not for Title 24)**

Use two Single Enthalpy Controls. One is field installed in the return air section, the other in the outdoor air section. Allows the economizer control board to select between outdoor air or return air, whichever has lower enthalpy.

#### **IAQ Sensor**


An IAQ sensor is used when demand control ventilation (DCV) is required. See Options/Accessories table.

AIR RESISTANCE		
Air Volume - cfm	Total Resistance - in.w g.	
600	.02	
800	.03	
100	.05	
1200	.06	
1400	.07	
1600	.10	
1800	.12	
2000	.15	
2200	.18	
2400	.23	
2600	.28	

ORDERING INFORMATION				
Description	Model No.	Catalog No.		
Economizer	C2ECON23K	10U53		
OPTIONS/ACCESSORIES				
Item	Model No.	Catalog No.		
Economizer Controls (Not for Title 24)	·			
Single Enthalpy Control	C1SNSR60FF1	10Z75		
Differential Enthalpy Control (order 2)	C1SNSR60FF1	10Z75		
Indoor Air Quality (CO <sub>2</sub> ) Sensors				
Wall-mount, off-white plastic cover with LCD display	C0SNSR50AE1L	77N39		
Wall-mount, off-white plastic cover, no display	C0SNSR52AE1L	87N53		
Black plastic case with LCD display, rated for plenum mounting	C0SNSR51AE1L	87N52		
Wall-mount, black plastic case, no display, rated for plenum mounting	C0MISC19AE1	87N54		
Aspiration Box - for duct mounting non-plenum rated sensors (87N53 or 77N39)	C0MISC16AE1-	90N43		

Item		Model No.	Catalog No.
COMFORTSENSE® 7	500 COMMERCIAL 7-DAY PROGRAMMABLE THERMOSTAT	NO.	NO.
7.28 pm   fri	<ul> <li>Full Seven-Day Programming</li> <li>Four Time Periods Per Day</li> <li>Occupancy Scheduling with Economizer Relay Control</li> <li>Away Mode</li> <li>Holiday Scheduling</li> <li>Smooth Setback Recovery (SSR)</li> <li>Performance Reports</li> <li>Notifications/Reminders</li> <li>Dehumidification/Humiditrol® Control for Split Systems and Rooftop Units</li> <li>Economizer Relay Control</li> <li>Backlit Display</li> </ul>	COSTATO6FF1L	13H15
Optional Accessories	Wallplate Furnished		
•	e wall mount 20k temperature sensor	C0SNZN01AE2-	47W36
-	·	COSNZN73AE1-	47W37
<sup>1</sup> Remote non-adjustable wall mount 10k temperature sensor		COSNDC00AE1-	19L22
Remote non-adjustable discharge air (duct mount) temperature sensor		COSNSR03AE1-	X2658
Outdoor temperature se Locking cover (clear)	TISOI	COMISC15AE1-	39P21
<sup>1</sup> Remote sensors can be appl One Sensor - (1) 47W36 Two Sensors - (2) 47W37 Three Sensors - (2) 47W36 Four Sensors - (4) 47W36 Five Sensors - (3) 47W36 a			
	000 COMMERCIAL 5-2 DAY PROGRAMMABLE THERMOSTAT		
NOTU WE IN ITS AS	<ul> <li>Two-Stage Heating / Two-Stage Cooling Conventional Systems</li> <li>Intuitive Interface</li> <li>5-2 Day Programming</li> <li>Program Hold</li> <li>Remote Indoor Temperature Sensing</li> <li>Smooth Setback Recovery (SSR)</li> <li>Economizer Relay Control</li> <li>Maintenance/Filter/Service Reminders</li> <li>Backlit Display</li> <li>Wallplate Furnished</li> <li>Simple Up and Down Temperature Control.</li> </ul>	C0STAT05FF1L	11Y05
<b>Optional Accessories</b>			
Remote non-adjustable	wall mount 10k averaging temperature sensor	C0SNZN73AE1-	47W37
Optional wall mounting	Note	C0MISC17AE1-	X2659

# **DIMENSIONS - INCHES (MM)**



REVISIONS		
Sections	Description of Change	
Air Resistance	Added.	



Visit us at www.lennox.com

For the latest technical information, www.lennoxdavenet.com

Contact us at 1-800-4-LENNOX