

Service Literature

LGH092H through 152U

The LGH092H, 094U, 102H, 120H, 122U, 150S, 150H and 152U units are configured to order units (CTO) with a wide selection of factory-installed options. Units are available in 130,000, 180,000 Btuh or 240,000 Btuh (38.1, 52.7 or 70.3 kW) heating inputs. Gas heat sections are designed with aluminized steel tube heat exchangers with stainless steel as an option.

Cooling capacities range from 7.5 to 12.5 tons (38.1 to 70.3 kW). All units are equipped with two compressors.

Ultra-high efficiency units are available with an optional direct drive blower or belt drive blower equipped with a supply air inverter. Standard and high efficiency units are available with a belt drive blower equipped with an optional supply air inverter. The blower will operate at lower speeds when demand is low and increase to higher speeds when demand is high.

The following examples show the model numbers of ten-ton units with all available blower options:

- LGH120H4B High Efficiency Belt Drive
- LGH120H4M High Efficiency Belt Drive with Inverter
- LGH122U4M Ultra High Efficiency Belt Drive with Inverter
- LGH122U4E Ultra High Efficiency Direct Drive

Note - Ten-ton units are available in high and ultra high efficiencies only.

Standard and high efficiency units come standard with a lightweight, all-aluminum condenser coil; optional, fin/tube condenser coils are available. Ultra-high efficiency units come standard with a tube/fin condenser coil.

Ultra high efficiency units come standard with two single-speed compressors plumbed in tandem to form a single refrigerant circuit.

Units are also designed for R410A refrigerant. See unit nameplate. Operating pressures and pressure switch settings are significantly higher than R22 charged units. Service equipment must be rated for R410A.

Standard and high efficiency units offer mechanical cooling down to 0°F when properly equipped. Ultra-high efficiency units offer mechanical cooling down to 40°F.

All LGH units are designed to accept any of several different energy management thermostat control systems with minimum field wiring. Factory or field provided control options connect to the unit with jack plugs. When "plugged in" the controls become an integral part of the unit wiring.

Information contained in this manual is intended for use by qualified service technicians only. All specifications are subject to change. Procedures outlined in this manual are presented as a recommendation only and do not supersede or replace local or state codes.

If the unit must be lifted for service, rig unit by attaching four cables to the holes located in the unit base rail (two holes at each corner). Refer to the installation instructions for the proper rigging technique.




Table of Contents

| | |
|---|---------|
| Options / Accessories | Page 2 |
| Specifications | Page 8 |
| Blower Tables | Page 14 |
| Electrical Data | Page 19 |
| Parts Arrangement | Page 25 |
| I-Unit Components | Page 28 |
| II-Placement and Installation | Page 47 |
| III-Charging | Page 47 |
| IV-Start Up - Operation | Page 55 |
| V-System Service Checks | Page 57 |
| High Altitude | Page 59 |
| VI-Maintenance | Page 59 |
| VII-Accessories | Page 60 |
| VIII-Belt Drive Supply Air Inverter | Page 67 |
| IX-Direct Drive Supply Air Blower | Page 70 |
| X-Staged Supply Air Operation | Page 71 |
| XI-Wiring and Operation Sequence | Page 72 |

⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional HVAC installer or equivalent, service agency, or the gas supplier

⚠ CAUTION

As with any mechanical equipment, contact with sharp sheet metal edges can result in personal injury. Take care while handling this equipment and wear gloves and protective clothing.

OPTIONS / ACCESSORIES

| Item Description | Model Number | Catalog Number | Unit Model No | | | |
|---|--|----------------|---------------|-----|-----|-----|
| | | | 092 | 102 | 120 | 150 |
| COOLING SYSTEM | | | | | | |
| Condensate Drain Trap | PVC - C1TRAP20AD2 | 76W26 | OX | OX | OX | OX |
| | Copper - C1TRAP10AD2 | 76W27 | OX | OX | OX | OX |
| Conventional Fin/Tube Condenser Coil (replaces Environ™ Coil System) | | Factory | O | O | O | |
| Corrosion Protection | | Factory | O | O | O | O |
| Drain Pan Overflow Switch | E1SNSR71AD1 | 68W88 | OX | OX | OX | OX |
| Refrigerant Type | | R-410A | O | O | O | O |
| Service Valves (not for Environ™ Coil System or Humiditrol® equipped units) | | Factory | O | O | O | O |
| HEATING SYSTEM | | | | | | |
| Bottom Gas Piping Kit | C1GPKT01B-01 | 54W95 | OX | OX | OX | OX |
| Combustion Air Intake Extensions | T1EXTN10AN1 | 19W51 | X | X | X | X |
| Gas Heat Input | 130,000 Btuh | Factory | O | O | O | O |
| | 180,000 Btuh | Factory | O | O | O | O |
| | 240,000 Btuh | Factory | O | O | O | O |
| Low Temperature Vestibule Heater | 208/230V-3ph - C1LTVH10B-2Y | 13X63 | OX | OX | OX | OX |
| | 460V - C1LTVH10B-2G | 13X64 | OX | OX | OX | OX |
| | 575V - C1LTVH10B-2J | 13X65 | OX | OX | OX | OX |
| LPG/Propane Conversion Kits | Standard Heat - C1PROP23BS1 | 14N22 | X | X | X | X |
| | Medium Heat - C1PROP22BS1 | 14N23 | X | X | X | X |
| | High Heat - C1PROP21BS1 | 14N25 | X | X | X | X |
| Stainless Steel Heat Exchanger | | Factory | O | O | O | O |
| Vertical Vent Extension Kit | C1EXTN2021 | 42W16 | X | X | X | X |
| BLOWER - SUPPLY AIR | | | | | | |
| Blower Option | CAV (Constant Air Volume) | Factory | O | O | O | O |
| | MSAV® (Multi-Stage Air Volume) supply air blower option (With VFD Bypass Control) | Factory | O | O | O | O |
| | MSAV® (Multi-Stage Air Volume) supply air blower option (Without VFD Bypass Control) | Factory | O | O | O | O |
| Motors - Constant Air Volume (CAV) | Belt Drive (standard efficiency) - 2 hp | Factory | O | O | O | O |
| | Belt Drive (standard or high efficiency) - 3 hp | Factory | O | O | O | O |
| | Belt Drive (standard efficiency) - 5 hp | Factory | O | O | O | O |
| Motors - MSAV® Multi-Stage Air Volume | Belt Drive (standard efficiency) - 2 hp | Factory | O | O | O | O |
| | Belt Drive (standard efficiency) - 3 hp | Factory | O | O | O | O |
| | Belt Drive (standard efficiency) - 5 hp | Factory | O | O | O | O |
| Drive Kits | Kit #1 590-890 rpm | Factory | O | O | O | O |
| See Blower Data Tables for selection | Kit #2 800-1105 rpm | Factory | O | O | O | O |
| | Kit #3 795-1195 rpm | Factory | O | O | O | O |
| | Kit #4 730-970 rpm | Factory | O | O | O | O |
| | Kit #5 940-1200 rpm | Factory | O | O | O | O |
| | Kit #6 1015-1300 rpm | Factory | O | O | O | O |
| | Kit #7 730-970 rpm | Factory | O | O | O | O |
| | Kit #8 940-1200 rpm | Factory | O | O | O | O |
| | Kit #9 1015-1300 rpm | Factory | O | O | O | O |
| | Kit #10 900-1135 rpm | Factory | O | O | O | O |
| | Kit #11 1040-1315 rpm | Factory | O | O | O | O |
| | Kit #12 1125-1425 rpm | Factory | O | O | O | O |
| | Blower Belt Auto-Tensioner | Factory | O | O | O | O |
| CABINET | | | | | | |
| Combination Coil/ Hail Guards | Furnish Environ™ Coil System - C1GARD52B-1 | 13T05 | X | X | X | |
| | Optional Conventional Fin/Tube Condenser Coil - E1GARD51B-1 | 13T04 | X | X | X | |
| | Furnished Conventional Fin/Tube Condenser Coil System - C1GARD52B-1 | 13T05 | | | | X |
| Horizontal Discharge Kit | K1HECK00B-1 | 51W25 | X | X | X | X |
| Return Air Adaptor Plate (for LC/LG/LH and TC/TG/TH unit replacement) | C1CONV10B-1 | 54W96 | OX | OX | OX | OX |

NOTE - Catalog and model numbers shown are for ordering field installed accessories.

OX - Configure To Order (Factory Installed) or Field Installed

O = Configure To Order (Factory Installed)

X = Field Installed

OPTIONS / ACCESSORIES

| Item Description | Model Number | Catalog Number | Unit Model No | | | |
|--|---|----------------|---------------|-----|-----|-----|
| | | | 092 | 102 | 120 | 150 |
| CONTROLS | | | | | | |
| Blower Proving Switch | C1SNSR35FF1 | 53W65 | OX | OX | OX | OX |
| Commercial Controls | L Connection® Building Automation System | | X | X | X | X |
| | Prodigy® Control System - BACnet® Module - C0CTRL60AE1L | 59W51 | OX | OX | OX | OX |
| | Prodigy® Control System - LonTalk® Module - C0CTRL65FF1 | 54W27 | OX | OX | OX | OX |
| | Novar® ETM-2051 - E0CTRL30B1 | 64W73 | OX | OX | OX | OX |
| | Novar® LSE | Factory | O | O | O | O |
| Dirty Filter Switch | E1SNSR55B-1 | 53W67 | OX | OX | OX | OX |
| General Purpose Control Kit | E1GPBK30C1 | 13J78 | X | X | X | X |
| Fresh Air Tempering | C1SNSR75AD1 | 58W63 | OX | OX | OX | OX |
| Smoke Detector - Supply or Return (Power board and one sensor) | C1SNSR44B-2 | 11K76 | OX | OX | OX | OX |
| Smoke Detector - Supply and Return (Power board and two sensors) | C1SNSR43B-2 | 11K80 | OX | OX | OX | OX |
| INDOOR AIR QUALITY | | | | | | |
| Air Filters | | | | | | |
| Healthy Climate® High Efficiency Air Filters | MERV 8 - C1FLTR15B-1 | 50W61 | OX | OX | OX | OX |
| 20 x 25 x 2 (Order 4 per unit) | MERV 13 - C1FLTR40B-1 | 52W41 | OX | OX | OX | OX |
| Replacement Media Filter With Metal Mesh Frame (includes non-pleated filter media) | C1FLTR30B-1- | Y3063 | X | X | X | X |
| Indoor Air Quality (CO ₂) Sensors | | | | | | |
| Sensor - Wall-mount, off-white plastic cover with LCD display | C0SNSR50AE1L | 77N39 | X | X | X | X |
| Sensor - Wall-mount, off-white plastic cover, no display | C0SNSR52AE1L | 87N53 | X | X | X | X |
| Sensor - Black plastic case with LCD display, rated for plenum mounting | C0SNSR51AE1L | 87N52 | X | X | X | X |
| Sensor - Wall-mount, black plastic case, no display, rated for plenum mounting | C0MISC19AE1 | 87N54 | X | X | X | X |
| CO ₂ Sensor Duct Mounting Kit - for downflow applications | C0MISC19AE1- | 85L43 | X | X | X | X |
| Aspiration Box - for duct mounting non-plenum rated CO ₂ sensors (87N53 or 77N39) | C0MISC16AE1- | 90N43 | X | X | X | X |
| UVC Germicidal Lamps | | | | | | |
| ¹ Healthy Climate® UVC Light Kit (208/230v-1ph) | C1UVCL10B-1 | 54W62 | OX | OX | OX | OX |
| ELECTRICAL | | | | | | |
| Voltage 60 hz | 208/230V - 3 phase | Factory | O | O | O | O |
| | 460V - 3 phase | Factory | O | O | O | O |
| | 575V - 3 phase | Factory | O | O | O | O |
| HACR Circuit Breakers | | Factory | O | O | O | O |
| Disconnect Switch | 80 amp - C1DISC080B-1 | 54W56 | OX | OX | OX | OX |
| | 150 amp - C1DISC150B-1 | 54W57 | OX | OX | OX | OX |
| GFI Service Outlets | 15 amp non-powered, field-wired (208/230V, 460V only) | LTAGFIK10/15 | 74M70 | OX | OX | OX |
| | 20 amp non-powered, field-wired (575V only) | C1GFIC120FF1 | 67E01 | OX | OX | OX |
| Weatherproof Cover for GFI | C1GFIC199FF1 | 10C89 | X | X | X | X |
| Phase/Voltage Detection (Optional for CAV options only, furnished with MSAV® option) | | Factory | O | O | O | O |

¹ Lamps operate on 110-230V single-phase power supply. Step-down transformer may be ordered separately for 460V and 575V units. Alternately, 110V power supply may be used to directly power the UVC ballast(s)

NOTE - Catalog and model numbers shown are for ordering field installed accessories.

OX - Configure To Order (Factory Installed) or Field Installed

O = Configure To Order (Factory Installed)

X = Field Installed

OPTIONS / ACCESSORIES

| Item Description | Model Number | Catalog Number | Unit Model No | | | |
|--|-----------------------------|----------------|---------------|-----|-----|-----|
| | | | 092 | 102 | 120 | 150 |
| ECONOMIZER | | | | | | |
| Standard Economizer (Not for Title 24) | | | | | | |
| Standard Economizer | E1ECON15B-2 | 13U46 | OX | OX | OX | OX |
| Downflow or Horizontal - Includes Outdoor Air Hood and Downflow Barometric Relief Dampers with Exhaust Hood Order Horizontal Barometric Relief Dampers separately | | | | | | |
| High Performance Economizer (Approved for California Title 24 Building Standards / AMCA Class 1A Certified) | | | | | | |
| High Performance Economizer | E1ECON17B-1 | 10U59 | OX | OX | OX | OX |
| Downflow or Horizontal - Includes Outdoor Air Hood and Downflow Barometric Relief Dampers with Exhaust Hood Order Horizontal Barometric Relief Dampers separately | | | | | | |
| Horizontal Barometric Relief Dampers | | | | | | |
| Horizontal Low Profile Barometric With Exhaust Hood | LAGEDH03/15 | 53K04 | X | X | X | X |
| Economizer Controls (Not for Title 24) | | | | | | |
| Differential Enthalpy | Order 2 - C1SNSR64FF1 | 53W64 | OX | OX | OX | OX |
| Sensible Control | Sensor is Furnished | Factory | O | O | O | O |
| Single Enthalpy | C1SNSR64FF1 | 53W64 | OX | OX | OX | OX |
| Building Pressure Control | E1GPBK20C1 | 13J77 | X | X | X | X |
| Outdoor Air CFM Control | E1GPBK10C1 | 13J76 | X | X | X | X |
| Global Control | Sensor Field Provided | Factory | O | O | O | O |
| OUTDOOR AIR | | | | | | |
| Outdoor Air Dampers With Outdoor Air Hood | | | | | | |
| Motorized | C1DAMP20B-1 | 14G28 | OX | OX | OX | OX |
| Manual | C1DAMP10B-2 | 14G29 | OX | OX | OX | OX |
| POWER EXHAUST | | | | | | |
| Standard Static | 208/230V-3ph - K1PWRE10B-1Y | 53W44 | OX | OX | OX | OX |
| | 460V-3ph - K1PWRE10B-1G | 53W45 | OX | OX | OX | OX |
| | 575V-3ph - K1PWRE10B-1J | 53W46 | OX | OX | OX | OX |
| HUMIDITROL® CONDENSER REHEAT OPTION | | | | | | |
| Humiditrol Dehumidification Option | | Factory | O | O | O | O |
| Humidity Sensor Kit, Remote mounted (required) | C0SNSR31AE-1 | 17M50 | X | X | X | X |
| ROOF CURBS | | | | | | |
| Hybrid Roof Curbs, Downflow | | | | | | |
| 8 in. height | C1CURB70B-1 | 11F54 | X | X | X | X |
| 14 in. height | C1CURB71B-1 | 11F55 | X | X | X | X |
| 18 in. height | C1CURB72B-1 | 11F56 | X | X | X | X |
| 24 in. height | C1CURB73B-1 | 11F57 | X | X | X | X |
| Adjustable Pitch Curb, Downflow | | | | | | |
| 14 in. height | C1CURB55B-1 | 54W50 | X | X | X | X |
| CEILING DIFFUSERS | | | | | | |
| Step-Down - Order one | RTD11-95S | 13K61 | X | | | |
| | RTD11-135S | 13K62 | | X | X | |
| | RTD11-185S | 13K63 | | | | X |
| Flush - Order one | FD11-95S | 13K56 | X | | | |
| | FD11-135S | 13K57 | | X | X | |
| | FD11-185S | 13K58 | | | | X |
| Transitions (Supply and Return) - Order one | C1DIFF30B-1 | 12X65 | X | | | |
| | C1DIFF31B-1 | 12X66 | | X | X | |
| | C1DIFF32B-1 | 12X67 | | | | X |

NOTE - Catalog and model numbers shown are for ordering field installed accessories.
OX - Configure To Order (Factory Installed) or Field Installed
O = Configure To Order (Factory Installed)
X = Field Installed

OPTIONS / ACCESSORIES - 094U, 122U, 152U

| Item Description | Model Number | Catalog Number | Unit Model No | | |
|---|---|----------------|---------------|-----|-----|
| | | | 094 | 122 | 152 |
| COOLING SYSTEM | | | | | |
| Condensate Drain Trap | PVC - C1TRAP20AD2 | 76W26 | OX | OX | OX |
| | Copper - C1TRAP10AD2 | 76W27 | OX | OX | OX |
| Corrosion Protection | | Factory | O | O | O |
| Drain Pan Overflow Switch | E1SNSR71AD1 | 68W88 | OX | OX | OX |
| Refrigerant Type | | R-410A | O | O | O |
| HEATING SYSTEM | | | | | |
| Bottom Gas Piping Kit | C1GPKT01B-01 | 54W95 | OX | OX | OX |
| Combustion Air Intake Extensions | T1EXTN10AN1 | 19W51 | X | X | X |
| Gas Heat Input | 130,000 Btuh | Factory | O | O | O |
| | 180,000 Btuh | Factory | O | O | O |
| | 240,000 Btuh | Factory | O | O | O |
| Low Temperature Vestibule Heater | 208/230V-3ph - C1LTVH10B-1Y | 55W91 | OX | OX | OX |
| | 460V - C1LTVH10B-1G | 55W92 | OX | OX | OX |
| | 575V - C1LTVH10B-1J | 55W93 | OX | OX | OX |
| LPG/Propane Conversion Kits | Standard Heat - E1LPCO10B-1 | 53W07 | X | X | X |
| | Medium Heat - E1LPCO20B-1 | 53W08 | X | X | X |
| | High Heat - E1LPCO30B-1 | 53W09 | X | X | X |
| Stainless Steel Heat Exchanger | | Factory | O | O | O |
| Vertical Vent Extension Kit | C1EXTN2021 | 42W16 | X | X | X |
| BLOWER - SUPPLY AIR | | | | | |
| Blower | Direct Drive supply air blower | Factory | O | O | O |
| | Belt Drive supply air blower (With VFD Bypass Control) | Factory | O | O | O |
| | Belt Drive supply air blower (Without VFD Bypass Control) | Factory | O | O | O |
| Motors - Multi-Stage Air Volume supply air | Direct Drive ECM 3.75 hp | Factory | O | O | O |
| | Belt Drive (high efficiency) - 2 hp | Factory | O | O | O |
| | Belt Drive (standard or high efficiency) - 3 hp | Factory | O | O | O |
| | Belt Drive (standard efficiency) - 5 hp | Factory | O | O | O |
| Drive Kits | Kit #1 590-890 rpm | Factory | O | O | O |
| See Blower Data Tables for selection | Kit #2 800-1105 rpm | Factory | O | O | O |
| | Kit #3 795-1195 rpm | Factory | O | O | O |
| | Kit #4 730-970 rpm | Factory | O | O | O |
| | Kit #5 940-1200 rpm | Factory | O | O | O |
| | Kit #6 1015-1300 rpm | Factory | O | O | O |
| | Kit #7 730-970 rpm | Factory | O | O | O |
| | Kit #8 940-1200 rpm | Factory | O | O | O |
| | Kit #9 1015-1300 rpm | Factory | O | O | O |
| | Kit #10 900-1135 rpm | Factory | O | O | O |
| | Kit #11 1040-1315 rpm | Factory | O | O | O |
| | Kit #12 1125-1425 rpm | Factory | O | O | O |
| | Blower Belt Auto-Tensioner | | Factory | O | O |

NOTE - Catalog and model numbers shown are for ordering field installed accessories.
OX - Configure To Order (Factory Installed) or Field Installed
O = Configure To Order (Factory Installed)
X = Field Installed

OPTIONS / ACCESSORIES - 094U, 122U, 152U

| Item Description | Model Number | Catalog Number | Unit Model No | | |
|--|---|----------------|---------------|-----|-----|
| | | | 094 | 122 | 152 |
| CABINET | | | | | |
| Combination Coil/Hail Guards | E1GARD51BP1 | 13T06 | X | X | X |
| Horizontal Discharge Kit | K1HECK00B-1 | 51W25 | X | X | X |
| Return Air Adaptor Plate (for LC/LG and TC/TG/TH unit replacement) | C1CONV10B-1 | 54W96 | OX | OX | OX |
| CONTROLS | | | | | |
| Blower Proving Switch | C1SNSR35FF1 | 53W65 | OX | OX | OX |
| Commercial Controls | L Connection® Building Automation System | | X | X | X |
| | System - BACnet® Module - C0CTRL60AE1L | 59W51 | OX | OX | OX |
| | System - LonTalk® Module - C0CTRL65FF1 | 54W27 | OX | OX | OX |
| | | | | OX | OX |
| Dirty Filter Switch | E1SNSR55B-1 | 53W67 | OX | OX | OX |
| Fresh Air Tempering | C1SNSR75AD1 | 58W63 | OX | OX | OX |
| General Purpose Control Kit | E1GPBK30C1 | 13J78 | X | X | X |
| Smoke Detector - Supply or Return (Power board and one sensor) | C1SNSR44B-2 | 11K76 | OX | OX | OX |
| Smoke Detector - Supply and Return (Power board and two sensors) | C1SNSR43B-2 | 11K80 | OX | OX | OX |
| INDOOR AIR QUALITY | | | | | |
| Air Filters | | | | | |
| High Efficiency Air Filters 20 x 25 x 2 (Order 4 per unit) | MERV 8 - C1FLTR15B-1 | 50W61 | OX | OX | OX |
| | MERV 13 - C1FLTR40B-1 | 52W41 | OX | OX | OX |
| Replacement Media Filter With Metal Mesh Frame (includes non-pleated filter media) | C1FLTR30B-1- | Y3063 | X | X | X |
| Indoor Air Quality (CO₂) Sensors | | | | | |
| Sensor - Wall-mount, off-white plastic cover with LCD display | C0SNSR50AE1L | 77N39 | X | X | X |
| Sensor - Wall-mount, off-white plastic cover, no display | C0SNSR52AE1L | 87N53 | X | X | X |
| Sensor - Black plastic case with LCD display, rated for plenum mounting | C0SNSR51AE1L | 87N52 | X | X | X |
| Sensor - Wall-mount, black plastic case, no display, rated for plenum mounting | C0MISC19AE1 | 87N54 | X | X | X |
| CO ₂ Sensor Duct Mounting Kit - for downflow applications | C0MISC19AE1- | 85L43 | X | X | X |
| Aspiration Box - for duct mounting non-plenum rated CO ₂ sensors (87N53 or 77N39) | C0MISC16AE1- | 90N43 | X | X | X |
| UVC Germicidal Lamps | | | | | |
| ¹ UVC Light Kit (208/230v-1ph) | C1UVCL10B-1 | 54W62 | OX | OX | OX |
| ELECTRICAL | | | | | |
| Voltage 60 hz | 208/230V - 3 phase | Factory | O | O | O |
| | 460V - 3 phase | Factory | O | O | O |
| | 575V - 3 phase | Factory | O | O | O |
| HACR Circuit Breakers | | Factory | O | O | O |
| Disconnect Switch | 80 amp - C1DISC080B-1 | 54W56 | OX | OX | OX |
| | 150 amp - C1DISC150B-1 | 54W57 | OX | OX | OX |
| GFI Service Outlets | 15 amp non-powered, field-wired (208/230V, 460V only) | LTAGFIK10/15 | 74M70 | OX | OX |
| | 20 amp non-powered, field-wired (575V only) | C1GFCI20FF1 | 67E01 | OX | OX |
| Weatherproof Cover for GFI | C1GFCI99FF1 | 10C89 | X | X | X |

¹ Lamps operate on 110-230V single-phase power supply. Step-down transformer may be ordered separately for 460V and 575V units. Alternately, 110V power supply may be used to directly power the UVC ballast(s)

ECONOMIZER

Standard Economizer (Not for Title 24)

NOTE - Catalog and model numbers shown are for ordering field installed accessories.

OX - Configure To Order (Factory Installed) or Field Installed

O = Configure To Order (Factory Installed)

X = Field Installed

OPTIONS / ACCESSORIES - 094U, 122U, 152U

| Item Description | Model Number | Catalog Number | Unit Model No | | |
|--|---|----------------|---------------|-----|-----|
| | | | 094 | 122 | 152 |
| Standard Economizer Downflow or Horizontal - Includes Outdoor Air Hood and Downflow Barometric Relief Dampers with Exhaust Hood Order Horizontal Barometric Relief Dampers separately | E1ECON15B-1 | 55W05 | OX | OX | OX |
| High Performance Economizer (Approved for California Title 24 Building Standards) | | | | | |
| High Performance Economizer Downflow or Horizontal - Includes Outdoor Air Hood and Downflow Barometric Relief Dampers with Exhaust Hood Order Horizontal Barometric Relief Dampers separately | E1ECON17B-1 | 10U59 | OX | OX | OX |
| Economizer Controls | | | | | |
| Differential Enthalpy (Not for Title 24) | Order 2 - C1SNSR64FF1 | 53W64 | OX | OX | OX |
| Sensible Control | Sensor is Furnished | Factory | O | O | O |
| Single Enthalpy (Not for Title 24) | C1SNSR64FF1 | 53W64 | OX | OX | OX |
| Global Control | Sensor Field Provided | Factory | O | O | O |
| Building Pressure Control | E1GPBK20C1 | 13J77 | X | X | X |
| Outdoor Air CFM Control | E1GPBK10C1 | 13J76 | X | X | X |
| Horizontal Barometric Relief Dampers | | | | | |
| Horizontal Low Profile Barometric Relief Dampers With Exhaust Hood | LAGEDH03/15 | 53K04 | X | X | X |
| OUTDOOR AIR | | | | | |
| Outdoor Air Dampers | | | | | |
| Motorized Dampers (Hood furnished) | E1DAMP20B-1 | 63W60 | OX | OX | OX |
| Manual Dampers (Hood furnished) | C1DAMP10B-1 | 53W48 | OX | OX | OX |
| POWER EXHAUST | | | | | |
| Standard Static | 208/230V-3ph - K1PWRE10B-1Y | 53W44 | OX | OX | OX |
| | 460V-3ph - K1PWRE10B-1G | 53W45 | OX | OX | OX |
| | 575V-3ph - K1PWRE10B-1J | 53W46 | OX | OX | OX |
| ROOF CURBS | | | | | |
| Hybrid Roof Curbs, Downflow | | | | | |
| 8 in. height | C1CURB70B-1 | 11F54 | X | X | X |
| 14 in. height | C1CURB71B-1 | 11F55 | X | X | X |
| 18 in. height | C1CURB72B-1 | 11F56 | X | X | X |
| 24 in. height | C1CURB73B-1 | 11F57 | X | X | X |
| Adjustable Pitch Curb, Downflow | | | | | |
| 14 in. height | C1CURB55B-1 | 54W50 | X | X | X |
| CEILING DIFFUSERS | | | | | |
| Step-Down - Order one | RTD11-95 | 29G04 | X | | |
| | RTD11-135 | 29G05 | | X | |
| | RTD11-185 | 29G06 | | | X |
| Flush - Order one | FD11-95 | 29G08 | X | | |
| | FD11-135 | 29G09 | | X | |
| | FD11-185 | 29G10 | | | X |
| Transitions (Supply and Return) - Order one | C1DIFF30B-1 | 12X65 | X | | |
| | C1DIFF31B-1 | 12X66 | | X | |
| | C1DIFF32B-1 | 12X67 | | | X |
| Sunsource® Commercial Energy System | | | | | |
| Solar Module One 285W Solar Module (silver frame), One PanelClaw Polar Bear III Mounting CE Kit | System and One Enphase M250 Microinverter | 10U67 | X | X | X |
| Solar Power Entry with Disconnect | Factory | | O | O | O |
| Enphase Envoy Communications Gateway (with Wireless Capability) | | 13L89 | X | X | X |
| Line Communication Filter (external) | C1C400D11A | 10F93 | X | X | X |
| Transformer (6 kW) | E1TRFM15AD3Y (208Y to 208 VAC Delta) | 11H71 | X | X | X |
| | E1TRFM15AD2Y (230 VAC Delta) | 11H28 | X | X | X |
| | E1TRFM15AD3G (460 VAC Delta or Wye) | 11H29 | X | X | X |

NOTE - Catalog and model numbers shown are for ordering field installed accessories.

OX - Configure To Order (Factory Installed) or Field Installed

O = Configure To Order (Factory Installed)

X = Field Installed

SPECIFICATIONS - 092H, 102H

| General Data | | Nominal Tonnage | 7.5 Ton | 7.5 Ton | 8.5 Ton | 8.5 Ton |
|---|--|-----------------|---|--------------------------|-------------------------|--------------------------|
| | | Model Number | LGH092H4B | LGH092H4M | LGH102H4B | LGH102H4M |
| | | Efficiency Type | High | High | High | High |
| | | Blower Type | Constant Air Volume CAV | (Multi-Stage Air Volume) | Constant Air Volume CAV | (Multi-Stage Air Volume) |
| Cooling Performance | Gross Cooling Capacity - Btuh | | 93,000 | 93,000 | 103,800 | 103,800 |
| | ¹ Net Cooling Capacity - Btuh | | 90,000 | 90,000 | 100,000 | 100,000 |
| | AHRI Rated Air Flow - cfm | | 3000 | 2800 | 3400 | 3400 |
| | Total Unit Power - kW | | 7.5 | 7.5 | 8.1 | 8.1 |
| | ¹ EER (Btuh/Watt) | | 12.5 | 12.5 | 12.2 | 12.2 |
| | ² IEER (Btuh/Watt) | | 13.0 | 14.0 | 12.9 | 14.0 |
| | Refrigerant Type | | R-410A | R-410A | R-410A | R-410A |
| Refrigerant Charge | All-Aluminum Coil System | Circuit 1 | 7 lbs. 8 oz. | 7 lbs. 8 oz. | 7 lbs. 8 oz. | 7 lbs. 8 oz. |
| | | Circuit 2 | 7 lbs. 8 oz. | 7 lbs. 8 oz. | 7 lbs. 8 oz. | 7 lbs. 8 oz. |
| | Conventional Fin/Tube Coil Option | Circuit 1 | 13 lbs. 8 oz. | 13 lbs. 8 oz. | 13 lbs. 8 oz. | 13 lbs. 8 oz. |
| | | Circuit 2 | 12 lbs. 8 oz. | 12 lbs. 8 oz. | 12 lbs. 8 oz. | 12 lbs. 8 oz. |
| | Conventional Fin/Tube With Humiditrol® | Circuit 1 | 17 lbs. 0 oz. | 17 lbs. 0 oz. | 17 lbs. 0 oz. | 17 lbs. 0 oz. |
| | | Circuit 2 | 12 lbs. 8 oz. | 12 lbs. 8 oz. | 12 lbs. 8 oz. | 12 lbs. 8 oz. |
| Gas Heating Options Available - See page 10 | | | Standard (2 Stage), Medium (2 Stage), High (2 Stage) | | | |
| Compressor Type (number) | | | Scroll (2) | | | |
| Outdoor Coils Aluminum (Fin/Tube) | Net face area (total) - sq. ft. | | 28.0 (29.33) | 28.0 (29.33) | 28.0 (29.33) | 28.0 (29.33) |
| | Number of rows | | 1 (3) | 1 (3) | 1 (3) | 1 (3) |
| | Fins per inch | | 20 (20) | 20 (20) | 20 (20) | 20 (20) |
| | Motor - (No.) hp | | (2) 1/3 | (2) 1/3 | (2) 1/3 | (2) 1/3 |
| Outdoor Coil Fans | Motor rpm | | 1075 | 1075 | 1075 | 1075 |
| | Total Motor watts | | 800 | 800 | 800 | 800 |
| | Diameter - (No.) in. | | (2) 24 | (2) 24 | (2) 24 | (2) 24 |
| | Number of blades | | 3 | 3 | 3 | 3 |
| | Total Air volume - cfm | | 8800 | 8800 | 8800 | 8800 |
| | | | | | | |
| Indoor Coils | Net face area (total) - sq. ft. | | 12.78 | 12.78 | 12.78 | 12.78 |
| | Tube diameter - in. | | 3/8 | 3/8 | 3/8 | 3/8 |
| | Number of rows | | 4 | 4 | 4 | 4 |
| | Fins per inch | | 14 | 14 | 14 | 14 |
| Drain connection - Number and size | | | (1) 1 in. NPT coupling | | | |
| Expansion device type | | | Balance port TXV, removable head | | | |
| ³ Indoor Blower and Drive Selection | Nominal motor output | | 2 hp, 3 hp, 5 hp | | | |
| | Maximum usable motor output (US Only) | | 2.3 hp, 3.45 hp, 5.75 hp | | | |
| | Motor - Drive kit number | | 2 hp Kit 1 590-890 rpm (std. and high efficiency) Kit 2 800-1105 rpm (std. and high efficiency) Kit 3 795-1195 rpm (std. and high efficiency) 3 hp Kit 4 730-970 rpm (std. efficiency) Kit 5 940-1200 rpm (std. efficiency) Kit 6 1015-1300 rpm (std. efficiency) Kit 7 730-970 rpm (high efficiency) Kit 8 940-1200 rpm (high efficiency) Kit 9 1015-1300 rpm (high efficiency) 5 hp Kit 10 900-1135 rpm (std. efficiency) Kit 11 1040-1315 rpm (std. efficiency) Kit 12 1125-1425 rpm (std. efficiency) | | | |
| Blower wheel nominal diameter x width - in. | | | (1) 15 X 15 | (1) 15 X 15 | (1) 15 X 15 | (1) 15 X 15 |
| Filters | Type of filter | | Disposable | | | |
| | Number and size - in. | | (4) 20 x 25 x 2 | | | |
| Electrical characteristics | | | 208/230V, 460V or 575V - 60 hertz - 3 phase | | | |

NOTE - Net capacity includes evaporator blower motor heat deduction. Gross capacity does not include evaporator blower motor heat deduction.

¹ AHRI Certified to AHRI Standard 340/360; 95°F outdoor air temperature and 80°F db/67°F wb entering evaporator air; minimum external duct static pressure.

² Integrated Energy Efficiency Ratio certified and tested according to AHRI Standard 340/360.

³ Using total air volume and system static pressure requirements determine from blower performance tables rpm and motor output required. Maximum usable output of motors furnished are shown. In Canada, nominal motor output is also maximum usable motor output. If motors of comparable output are used, be sure to keep within the service factor limitations outlined on the motor nameplate.

NOTE - Units equipped with Multi-Stage Air Volume option are limited to a motor service factor of 1.0.

SPECIFICATIONS 120H, 150H

| General Data | | Nominal Tonnage | 10 Ton | 10 Ton | 12.5 Ton | 12.5 Ton |
|--|--|---------------------------------|---|--------------------------------|-------------------------|--------------------------------|
| Model Number | | | LGH120H4B | LGH120H4M | LGH150H4B | LGH150H4M |
| Efficiency Type | | | High | High | High | High |
| Blower Type | | | Constant Air Volume CAV | MSAV® (Multi-Stage Air Volume) | Constant Air Volume CAV | MSAV® (Multi-Stage Air Volume) |
| Cooling Performance | Gross Cooling Capacity - Btuh | | 122,000 | 122,000 | 146,000 | 146,000 |
| | ¹ Net Cooling Capacity - Btuh | | 118,000 | 118,000 | 140,000 | 140,000 |
| | AHRI Rated Air Flow - cfm | | 3600 | 3300 | 3950 | 3950 |
| | Total Unit Power - kW | | 9.9 | 9.8 | 13.0 | 13.0 |
| | ¹ EER (Btuh/Watt) | | 12 | 12.0 | 10.8 | 10.8 |
| | ² IEER (Btuh/Watt) | | 13.0 | 13.8 | 12.2 | 13.5 |
| AHRI Reference No. | | | 202088989 | 202090495 | 10569905 | 10569907 |
| Refrigerant Charge | | Refrigerant Type | R-410A | R-410A | R-410A | R-410A |
| Charge | Environ™ Coil System | Circuit 1 | 7 lbs. | 7 lbs. | --- | --- |
| | | Circuit 2 | 6 lbs. 12 oz. | 6 lbs. 12 oz. | --- | --- |
| | Environ™ Coil System with Humiditrol® | Circuit 1 | 7 lbs. | 7 lbs. | --- | --- |
| | | Circuit 2 | 6 lbs. 12 oz. | 6 lbs. 12 oz. | --- | --- |
| | Conventional Fin/Tube Coil Option | Circuit 1 | 14 lbs. 8 oz. | 14 lbs. 8 oz. | 12 lbs. 8 oz. | 12 lbs. 8 oz. |
| | | Circuit 2 | 13 lbs. 8 oz. | 13 lbs. 8 oz. | 10 lbs. 12 oz. | 10 lbs. 12 oz. |
| | Conventional Fin/Tube with Humiditrol® | Circuit 1 | 17 lbs. 8 oz. | 17 lbs. 8 oz. | 12 lbs. 9 oz. | 12 lbs. 9 oz. |
| | | Circuit 2 | 13 lbs. 8 oz. | 13 lbs. 8 oz. | 12 lbs. 3 oz. | 12 lbs. 3 oz. |
| Gas Heating Options Available - See page 10 | | | Standard (2 Stage), Medium (2 Stage), High (2 Stage) | | | |
| Compressor Type (number) | | | Scroll (2) | Scroll (2) | Scroll (2) | Scroll (2) |
| Outdoor Coils | Net face area (total) - sq. ft. | | 28.0 (29.33) | 28.0 (29.33) | --- (25.9) | --- (25.9) |
| | Environ™ (Fin/Tube) | Number of rows | 1 (3) | 1 (3) | 3 | 3 |
| | | Fins per inch | 20 (20) | 20 (20) | 20 | 20 |
| Outdoor Coil Fans | Motor - (No.) hp | | (2) 1/3 | (2) 1/3 | (2) 1/2 | (2) 1/2 |
| | Motor rpm | | 1075 | 1075 | 1075/600 | 1075/600 |
| | Total Motor watts | | 800 | 800 | 1050 | 1050 |
| | Diameter - (No.) in. | | (2) 24 | (2) 24 | (2) 24 | (2) 24 |
| | Number of blades | | 3 | 3 | 3 | 3 |
| | Total Air volume - cfm | | 8800 | 8800 | 9700 | 9700 |
| | Indoor Coils | Net face area (total) - sq. ft. | | 13.54 | 13.54 | 13.54 |
| Tube diameter - in. | | | 3/8 | 3/8 | 3/8 | 3/8 |
| Number of rows | | | 4 | 4 | 4 | 4 |
| Fins per inch | | | 14 | 14 | 14 | 14 |
| Drain connection - Number and size | | | (1) 1 in. NPT coupling | | | |
| Expansion device type | | | Balance port TXV, removable head | | | |
| ³ Indoor Blower and Drive Selection | Nominal motor output | | 2 hp, 3 hp, 5 hp | | | |
| | Maximum usable motor output (US Only) | | 2.3 hp, 3.45 hp, 5.75 hp | | | |
| | Motor - Drive kit number | | 2 hp Kit 1 590-890 rpm (std. and high efficiency) Kit 2 800-1105 rpm (std. and high efficiency) Kit 3 795-1195 rpm (std. and high efficiency) 3 hp Kit 4 730-970 rpm (std. efficiency) Kit 5 940-1200 rpm (std. efficiency) Kit 6 1015-1300 rpm (std. efficiency) Kit 7 730-970 rpm (high efficiency) Kit 8 940-1200 rpm (high efficiency) Kit 9 1015-1300 rpm (high efficiency) 5 hp Kit 10 900-1135 rpm (std. efficiency) Kit 11 1040-1315 rpm (std. efficiency) Kit 12 1125-1425 rpm (std. efficiency) | | | |
| Blower wheel nominal diameter x width - in. | | | (1) 15 X 15 | (1) 15 X 15 | (1) 15 X 15 | (1) 15 X 15 |
| Filters | Type of filter | | Disposable | | | |
| | Number and size - in. | | (4) 20 x 25 x 2 | | | |
| Electrical characteristics | | | 208/230V, 460V or 575V - 60 hertz - 3 phase | | | |

NOTE - Net capacity includes evaporator blower motor heat deduction. Gross capacity does not include evaporator blower motor heat deduction.

¹ AHRI Certified to AHRI Standard 340/360; 95°F outdoor air temperature and 80°F db/67°F wb entering evaporator air; minimum external duct static pressure.

² Integrated Energy Efficiency Ratio certified and tested according to AHRI Standard 340/360.

³ Using total air volume and system static pressure requirements determine from blower performance tables rpm and motor output required. Maximum usable output of motors furnished are shown. In Canada, nominal motor output is also maximum usable motor output. If motors of comparable output are used, be sure to keep within the service factor limitations outlined on the motor nameplate.

NOTE - Units equipped with MSAV® (Multi-Stage Air Volume) option are limited to a motor service factor of 1.0.

SPECIFICATIONS - GAS HEAT - 092H, 102H, 120H, 150H

| Heat Input Type | | Standard | Medium | High |
|--|-----------------------------|-------------|-------------|--------------|
| Number of Gas Heat Stages | | 2 | 2 | 2 |
| Gas Heating Performance | Input - Btuh | 84,500 | 117,000 | 156,000 |
| | First Stage | 130,000 | 180,000 | 240,000 |
| | Second Stage | 104,000 | 144,000 | 192,000 |
| | Output - Btuh | 15 - 45 | 30 - 60 | 40 - 70 |
| | Temperature Rise Range - °F | 80% | 80% | 80% |
| | Thermal Efficiency | 3/4 in. npt | 3/4 in. npt | 3/4 in. npt. |
| | Gas Supply Connections | 7 in. w.c. | 7 in. w.c. | 7 in. w.c. |
| Recommended Gas Supply Pressure - in. w.g. | Natural | 11 in. w.c. | 11 in. w.c. | 11 in. w.c. |
| | LPG/Propane | | | |

HIGH ALTITUDE DERATE - 092H, 102H, 120H, 150H

Units may be installed at altitudes up to 2000 feet above sea level without any modification.

At altitudes above 2000 feet, units must be derated to match gas manifold pressures shown in table below.

At altitudes above 4500 feet unit must be derated 2% for each 1000 feet above sea level.

NOTE - This is the only permissible derate for these units.

| Gas Heat Type | Altitude Feet | Gas Manifold Pressure in. w.g. | | Input Rate - Btuh (Natural Gas or LPG/Propane) | |
|---------------|---------------|--------------------------------|-----------------|--|--------------|
| | | Natural Gas | LPG/Propane Gas | First Stage | Second Stage |
| Standard | 2001-4500 | 3.4 | 9.6 | 84,500 | 124,000 |
| Medium | 2001-4500 | 3.4 | 9.6 | 117,000 | 172,000 |
| High | 2001-4500 | 3.4 | 9.6 | 156,000 | 230,000 |

SPECIFICATIONS - DIRECT DRIVE MODELS

| General Data | | Nominal Tonnage | 7.5 Ton | 10 Ton | 12.5 Ton |
|--|---|--|------------------------|-------------------|-------------------|
| | Model Number | | LGH094U4E | LGH122U4E | LGH152U4E |
| | Efficiency Type | | Ultra | Ultra | Ultra |
| | Blower Type | | Direct Drive | Direct Drive | Direct Drive |
| Cooling Performance | Gross Cooling Capacity - Btuh | | 93,700 | 119,000 | 141,900 |
| | ¹ Net Cooling Capacity - Btuh | | 92,000 | 116,000 | 138,000 |
| | AHRI Rated Air Flow - cfm | | 2800 | 3600 | 4000 |
| | Total Unit Power - kW | | 6.6 | 8.8 | 11.2 |
| | ¹ EER (Btuh/Watt) | | 13.9 | 13.1 | 12.3 |
| | ² IEER (Btuh/Watt) | | 21.5 | 20.0 | 18.9 |
| | Refrigerant Type | | R-410A | R-410A | R-410A |
| Refrigerant Charge | Circuit 1 | | 29 lbs. 0 oz. | 29 lbs. 0 oz. | 29 lbs. 0 oz. |
| Gas Heating Options Available - | | Standard (2 Stage), Medium (2 Stage), High (2 Stage) | | | |
| Compressor Type (number) | | | Tandem Scroll (2) | Tandem Scroll (2) | Tandem Scroll (2) |
| Outdoor Coils | Net face area (total) - sq. ft. | | 40.8 | 40.8 | 40.8 |
| | Number of rows | | 2 | 2 | 2 |
| | Fins per inch | | 20 | 20 | 20 |
| Outdoor Coil Fans | Motor - (No.) hp | | (3) 1/3 ECM | (3) 1/3 ECM | (3) 1/3 ECM |
| | Motor rpm | | 520 - 900 | 640 - 900 | 640 - 900 |
| | Total Motor watts | | 160 - 650 | 280 - 650 | 280 - 650 |
| | Diameter - (No.) in. | | (3) 24 | (3) 24 | (3) 24 |
| | Number of blades | | 3 | 3 | 3 |
| | Total Air volume - cfm | | 5160 - 10,250 | 7100 - 10,250 | 7100 - 10,250 |
| Indoor Coil | Net face area (total) - sq. ft. | | 13.54 | 13.54 | 13.54 |
| | Tube diameter - in. | | 3/8 | 3/8 | 3/8 |
| | Number of rows | | 4 | 4 | 4 |
| | Fins per inch | | 14 | 14 | 14 |
| | Drain connection - Number and size | | (1) 1 in. NPT coupling | | |
| | Expansion device type | Dual-Flow Thermal Expansion Valve System Dual with Flow Control Balance port, removable head | | | |
| Indoor Blower | Nominal motor output | | 3.75 HP (ECM) | 3.75 HP (ECM) | 3.75 HP (ECM) |
| | Blower wheel nominal diameter x width - in. | | (1) 22 x 9 | (1) 22 x 9 | (1) 22 x 9 |
| Filters | Type of filter | Disposable | | | |
| | Number and size - in. | (4) 20 x 25 x 2 | | | |
| Electrical characteristics | | 208/230V, 460V or 575V - 60 hertz - 3 phase | | | |

NOTE - Net capacity includes evaporator blower motor heat deduction. Gross capacity does not include evaporator blower motor heat deduction.

¹ AHRI Certified to AHRI Standard 340/360; 95°F outdoor air temperature and 80°F db/67°F wb entering evaporator air; minimum external duct static pressure.

² Integrated Energy Efficiency Ratio certified and tested according to AHRI Standard 340/360.

SPECIFICATIONS - BELT DRIVE MODELS - 094U, 122U, 152U

| General Data | | Nominal Tonnage | 7.5 Ton | 10 Ton | 12.5 Ton |
|---|--|------------------|---|-------------------|-------------------|
| | | Model Number | LGH094U4M | LGH122U4M | LGH152U4M |
| | | Efficiency Type | Ultra | Ultra | Ultra |
| | | Blower Type | Belt Drive | Belt Drive | Belt Drive |
| Cooling Performance | Gross Cooling Capacity - Btuh | | 93,700 | 119,000 | 141,900 |
| | ¹ Net Cooling Capacity - Btuh | | 92,000 | 116,000 | 136,000 |
| | AHRI Rated Air Flow - cfm | | 2800 | 3600 | 4000 |
| | Total Unit Power - kW | | 6.9 | 8.8 | 11.5 |
| | ¹ EER (Btuh/Watt) | | 13.4 | 12.6 | 12.0 |
| | ² IEER (Btuh/Watt) | | 20.7 | 19.2 | 18.1 |
| | | Refrigerant Type | R-410A | R-410A | R-410A |
| Refrigerant Charge | | Circuit 1 | 29 lbs. 0 oz. | 29 lbs. 0 oz. | 29 lbs. 0 oz. |
| Gas Heating Options Available - | | | Standard (2 Stage), Medium (2 Stage), High (2 Stage) | | |
| Compressor Type (number) | | | Tandem Scroll (2) | Tandem Scroll (2) | Tandem Scroll (2) |
| Outdoor Coils | Net face area (total) - sq. ft. | | 40.8 | 40.8 | 40.8 |
| | Number of rows | | 2 | 2 | 2 |
| | Fins per inch | | 20 | 20 | 20 |
| Outdoor Coil Fans | Motor - (No.) hp | | (3) 1/3 ECM | (3) 1/3 ECM | (3) 1/3 ECM |
| | Motor rpm | | 520 - 900 | 640 - 900 | 640 - 900 |
| | Total Motor watts | | 160 - 650 | 280 - 650 | 280 - 650 |
| | Diameter - (No.) in. | | (3) 24 | (3) 24 | (3) 24 |
| | Number of blades | | 3 | 3 | 3 |
| | Total Air volume - cfm | | 5160 - 10,250 | 7100 - 10,250 | 7100 - 10,250 |
| Indoor Coil | Net face area (total) - sq. ft. | | 13.54 | 13.54 | 13.54 |
| | Tube diameter - in. | | 3/8 | 3/8 | 3/8 |
| | Number of rows | | 4 | 4 | 4 |
| | Fins per inch | | 14 | 14 | 14 |
| | Drain connection - Number and size | | (1) 1 in. NPT coupling | | |
| Expansion device type | | | Dual-Flow Thermal Expansion Valve System Dual with Flow Control Balance port, removable head | | |
| ³ Indoor Blower and Drive Selection | Nominal motor output | | 2 hp, 3 hp, 5 hp | | |
| | Motor - Drive kit number | | 2 hp Kit 1 590-890 rpm (std. and high efficiency) Kit 2 800-1105 rpm (std. and high efficiency) Kit 3 795-1195 rpm (std. and high efficiency) 3 hp Kit 4 730-970 rpm (std. efficiency) Kit 5 940-1200 rpm (std. efficiency) Kit 6 1015-1300 rpm (std. efficiency) Kit 7 730-970 rpm (high efficiency) Kit 8 940-1200 rpm (high efficiency) Kit 9 1015-1300 rpm (high efficiency) 5 hp Kit 10 900-1135 rpm (std. efficiency) Kit 11 1040-1315 rpm (std. efficiency) Kit 12 1125-1425 rpm (std. efficiency) | | |
| Blower wheel nominal diameter x width - in. | | | (1) 15 X 15 | (1) 15 X 15 | (1) 15 X 15 |
| Filters | Type of filter | | Disposable | | |
| | Number and size - in. | | (4) 20 x 25 x 2 | | |
| Electrical characteristics | | | 208/230V, 460V or 575V - 60 hertz - 3 phase | | |

NOTE - Net capacity includes evaporator blower motor heat deduction. Gross capacity does not include evaporator blower motor heat deduction.

¹ AHRI Certified to AHRI Standard 340/360; 95°F outdoor air temperature and 80°F db/67°F wb entering evaporator air; minimum external duct static pressure.

² Integrated Energy Efficiency Ratio certified and tested according to AHRI Standard 340/360.

³ Using total air volume and system static pressure requirements determine from blower performance tables rpm and motor output required. Maximum usable output of motors furnished are shown. If motors of comparable output are used, be sure to keep within the service factor limitations outlined on the motor nameplate.

SPECIFICATIONS - GAS HEAT - 094U, 122U, 152U

| | | Standard | Medium | High |
|--|-----------------------------|-------------|-------------|--------------|
| Heat Input Type | | | | |
| Number of Gas Heat Stages | | 2 | 2 | 2 |
| Gas Heating Performance | Input - Btuh | | | |
| | First Stage | 84,500 | 117,000 | 156,000 |
| | Second Stage | 130,000 | 180,000 | 240,000 |
| | Output - Btuh | | | |
| | Second Stage | 104,000 | 144,000 | 192,000 |
| | Temperature Rise Range - °F | 15 - 45 | 30 - 60 | 40 - 70 |
| | Thermal Efficiency | 80% | 80% | 80% |
| | Gas Supply Connections | 3/4 in. npt | 3/4 in. npt | 3/4 in. npt. |
| Recommended Gas Supply Pressure - in. w.g. | Natural | 7 in. w.c. | 7 in. w.c. | 7 in. w.c. |
| | LPG/Propane | 11 in. w.c. | 11 in. w.c. | 11 in. w.c. |

BLOWER DATA

092, 094, AND 102 BELT DRIVE BLOWER – BASE UNIT

BLOWER TABLE INCLUDES RESISTANCE FOR BASE UNIT ONLY (NO HEAT SECTION) WITH DRY INDOOR COIL AND AIR FILTERS IN PLACE.

FOR ALL UNITS ADD:

- 1 – Wet indoor coil air resistance of selected unit.
- 2 – Any factory installed options air resistance (heat section, economizer, etc.)
- 3 – Any field installed accessories air resistance (duct resistance, diffuser, etc.)

Then determine from blower table blower motor output required.

See page 16 for blower motors and drives. See page 16 for wet coil and option/accessory air resistance data.

MAXIMUM STATIC PRESSURE WITH GAS HEAT - 2.0 in. w.g.

| Total Air Volume cfm | Total Static Pressure – in. w.g. | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|----------------------------------|------|-----|------|-----|------|-----|------|-----|------|-----|------|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|-----|
| | 0.2 | | 0.4 | | 0.6 | | 0.8 | | 1.0 | | 1.2 | | 1.4 | | 1.6 | | 1.8 | | 2.0 | | 2.2 | | 2.4 | | 2.6 | | |
| | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM |
| 1750 | 481 | 0.21 | 549 | 0.4 | 618 | 0.57 | 688 | 0.7 | 758 | 0.82 | 824 | 0.93 | 885 | 1.08 | 941 | 1.23 | 991 | 1.39 | 1038 | 1.54 | 1082 | 1.68 | 1124 | 1.82 | 1166 | 1.95 | |
| 2000 | 493 | 0.29 | 561 | 0.47 | 629 | 0.64 | 700 | 0.77 | 768 | 0.9 | 832 | 1.02 | 892 | 1.17 | 946 | 1.33 | 995 | 1.49 | 1041 | 1.66 | 1085 | 1.81 | 1126 | 1.97 | 1167 | 2.12 | |
| 2250 | 507 | 0.37 | 574 | 0.56 | 643 | 0.72 | 712 | 0.86 | 779 | 0.99 | 842 | 1.13 | 900 | 1.28 | 953 | 1.44 | 1001 | 1.61 | 1045 | 1.78 | 1088 | 1.95 | 1128 | 2.12 | 1168 | 2.3 | |
| 2500 | 521 | 0.46 | 588 | 0.64 | 657 | 0.81 | 727 | 0.95 | 792 | 1.09 | 853 | 1.24 | 909 | 1.4 | 960 | 1.57 | 1007 | 1.74 | 1050 | 1.93 | 1091 | 2.11 | 1130 | 2.29 | 1170 | 2.48 | |
| 2750 | 537 | 0.56 | 604 | 0.74 | 674 | 0.91 | 743 | 1.06 | 806 | 1.21 | 865 | 1.36 | 920 | 1.53 | 969 | 1.71 | 1014 | 1.89 | 1055 | 2.08 | 1095 | 2.27 | 1133 | 2.47 | 1172 | 2.66 | |
| 3000 | 554 | 0.67 | 622 | 0.86 | 692 | 1.02 | 760 | 1.18 | 822 | 1.34 | 878 | 1.5 | 931 | 1.68 | 979 | 1.86 | 1021 | 2.06 | 1061 | 2.26 | 1099 | 2.46 | 1136 | 2.65 | 1174 | 2.85 | |
| 3250 | 572 | 0.78 | 641 | 0.98 | 712 | 1.15 | 778 | 1.32 | 838 | 1.49 | 892 | 1.66 | 943 | 1.84 | 989 | 2.03 | 1030 | 2.24 | 1068 | 2.45 | 1105 | 2.65 | 1141 | 2.85 | 1178 | 3.06 | |
| 3500 | 592 | 0.9 | 663 | 1.12 | 733 | 1.3 | 798 | 1.47 | 855 | 1.65 | 907 | 1.83 | 956 | 2.02 | 1000 | 2.22 | 1039 | 2.44 | 1076 | 2.65 | 1111 | 2.86 | 1146 | 3.07 | 1183 | 3.27 | |
| 3750 | 614 | 1.04 | 687 | 1.28 | 756 | 1.47 | 818 | 1.65 | 872 | 1.83 | 923 | 2.02 | 970 | 2.22 | 1011 | 2.43 | 1049 | 2.65 | 1084 | 2.87 | 1118 | 3.09 | 1152 | 3.29 | 1189 | 3.51 | |
| 4000 | 639 | 1.22 | 713 | 1.48 | 780 | 1.66 | 838 | 1.83 | 890 | 2.02 | 939 | 2.22 | 984 | 2.44 | 1023 | 2.66 | 1059 | 2.89 | 1093 | 3.11 | 1126 | 3.33 | 1160 | 3.54 | 1197 | 3.77 | |
| 4250 | 667 | 1.43 | 741 | 1.69 | 805 | 1.86 | 859 | 2.02 | 909 | 2.22 | 956 | 2.45 | 998 | 2.68 | 1036 | 2.92 | 1070 | 3.15 | 1103 | 3.37 | 1135 | 3.59 | 1169 | 3.81 | 1207 | 4.05 | |

BLOWER DATA

120, 122, 150 AND 152 BELT DRIVE BLOWER – BASE UNIT

BLOWER TABLE INCLUDES RESISTANCE FOR BASE UNIT ONLY (NO HEAT SECTION) WITH DRY INDOOR COIL AND AIR FILTERS IN PLACE.

FOR ALL UNITS ADD:

- 1 – Wet indoor coil air resistance of selected unit.
 - 2 – Any factory installed options air resistance (heat section, economizer, etc.)
 - 3 – Any field installed accessories air resistance (duct resistance, diffuser, etc.)
- Then determine from blower table blower motor output required.

See page 16 for blower motors and drives. See page 16 for wet coil and option/accessory air resistance data.

MAXIMUM STATIC PRESSURE WITH GAS HEAT - 2.0 in. w.g.

| Total Air Volume cfm | Total Static Pressure – in. w.g. | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|----------------------------------|------|-----|------|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|-----|
| | 0.2 | | 0.4 | | 0.6 | | 0.8 | | 1.0 | | 1.2 | | 1.4 | | 1.6 | | 1.8 | | 2.0 | | 2.2 | | 2.4 | | 2.6 | | |
| | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM | BHP | RPM |
| 2000 | 497 | 0.25 | 558 | 0.44 | 624 | 0.6 | 694 | 0.74 | 764 | 0.85 | 830 | 0.99 | 889 | 1.16 | 943 | 1.34 | 994 | 1.52 | 1045 | 1.71 | 1096 | 1.89 | 1146 | 2.08 | 1197 | 2.27 | |
| 2250 | 511 | 0.34 | 573 | 0.52 | 638 | 0.68 | 708 | 0.82 | 776 | 0.94 | 839 | 1.09 | 896 | 1.26 | 948 | 1.45 | 998 | 1.64 | 1048 | 1.83 | 1098 | 2.01 | 1149 | 2.2 | 1200 | 2.4 | |
| 2500 | 527 | 0.44 | 589 | 0.62 | 654 | 0.78 | 723 | 0.91 | 789 | 1.05 | 850 | 1.21 | 904 | 1.39 | 955 | 1.58 | 1003 | 1.77 | 1052 | 1.96 | 1101 | 2.14 | 1152 | 2.33 | 1203 | 2.53 | |
| 2750 | 545 | 0.55 | 606 | 0.72 | 672 | 0.88 | 740 | 1.03 | 804 | 1.17 | 861 | 1.34 | 914 | 1.53 | 962 | 1.72 | 1010 | 1.92 | 1057 | 2.10 | 1105 | 2.29 | 1154 | 2.47 | 1206 | 2.68 | |
| 3000 | 564 | 0.66 | 626 | 0.84 | 692 | 1.01 | 759 | 1.16 | 819 | 1.32 | 874 | 1.49 | 924 | 1.68 | 971 | 1.88 | 1017 | 2.08 | 1063 | 2.26 | 1110 | 2.44 | 1158 | 2.63 | 1208 | 2.83 | |
| 3250 | 585 | 0.79 | 648 | 0.98 | 714 | 1.14 | 778 | 1.31 | 836 | 1.48 | 887 | 1.66 | 935 | 1.86 | 981 | 2.06 | 1026 | 2.26 | 1071 | 2.45 | 1117 | 2.63 | 1163 | 2.80 | 1213 | 3.00 | |
| 3500 | 607 | 0.93 | 672 | 1.13 | 737 | 1.31 | 798 | 1.48 | 852 | 1.66 | 901 | 1.85 | 948 | 2.05 | 993 | 2.26 | 1037 | 2.46 | 1081 | 2.65 | 1125 | 2.83 | 1171 | 3.01 | 1221 | 3.21 | |
| 3750 | 632 | 1.10 | 698 | 1.31 | 762 | 1.50 | 819 | 1.67 | 869 | 1.86 | 915 | 2.05 | 961 | 2.25 | 1005 | 2.47 | 1049 | 2.68 | 1092 | 2.88 | 1136 | 3.05 | 1181 | 3.24 | 1231 | 3.45 | |
| 4000 | 660 | 1.30 | 726 | 1.52 | 787 | 1.70 | 838 | 1.87 | 885 | 2.06 | 930 | 2.26 | 974 | 2.48 | 1018 | 2.71 | 1062 | 2.93 | 1105 | 3.12 | 1149 | 3.30 | 1194 | 3.49 | 1245 | 3.72 | |
| 4250 | 691 | 1.53 | 755 | 1.75 | 810 | 1.91 | 857 | 2.07 | 901 | 2.27 | 945 | 2.50 | 990 | 2.74 | 1034 | 2.98 | 1077 | 3.20 | 1120 | 3.39 | 1163 | 3.58 | 1210 | 3.79 | 1262 | 4.03 | |
| 4500 | 724 | 1.78 | 783 | 1.98 | 831 | 2.12 | 874 | 2.28 | 917 | 2.50 | 962 | 2.75 | 1006 | 3.02 | 1051 | 3.27 | 1094 | 3.49 | 1137 | 3.70 | 1181 | 3.89 | 1228 | 4.11 | 1281 | 4.38 | |
| 4750 | 757 | 2.05 | 809 | 2.20 | 851 | 2.33 | 891 | 2.51 | 935 | 2.76 | 980 | 3.05 | 1025 | 3.33 | 1070 | 3.59 | 1113 | 3.82 | 1156 | 4.03 | 1201 | 4.24 | 1249 | 4.47 | 1303 | 4.75 | |
| 5000 | 787 | 2.31 | 831 | 2.43 | 870 | 2.57 | 910 | 2.78 | 954 | 3.06 | 1000 | 3.38 | 1046 | 3.68 | 1091 | 3.95 | 1135 | 4.19 | 1178 | 4.40 | 1224 | 4.62 | 1272 | 4.86 | 1325 | 5.13 | |
| 5250 | 814 | 2.55 | 852 | 2.66 | 889 | 2.83 | 930 | 3.09 | 975 | 3.41 | 1023 | 3.76 | 1070 | 4.08 | 1115 | 4.35 | 1159 | 4.59 | 1203 | 4.81 | 1248 | 5.03 | 1297 | 5.27 | 1350 | 5.53 | |
| 5500 | 835 | 2.78 | 871 | 2.91 | 909 | 3.13 | 952 | 3.44 | 999 | 3.81 | 1049 | 4.18 | 1096 | 4.51 | 1142 | 4.79 | 1186 | 5.03 | 1229 | 5.24 | 1275 | 5.46 | 1324 | 5.69 | --- | --- | |
| 5750 | 854 | 3.01 | 890 | 3.19 | 930 | 3.48 | 977 | 3.86 | 1027 | 4.27 | 1078 | 4.66 | 1126 | 4.99 | 1171 | 5.26 | 1214 | 5.49 | 1258 | 5.70 | --- | --- | --- | --- | --- | --- | |
| 6000 | 871 | 3.26 | 910 | 3.53 | 955 | 3.90 | 1006 | 4.34 | 1060 | 4.80 | 1111 | 5.19 | 1158 | 5.51 | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | |
| 6250 | 890 | 3.57 | 934 | 3.94 | 985 | 4.41 | 1041 | 4.91 | 1096 | 5.38 | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | |

BLOWER DATA - 092, 094, 102, 120, 122, 150, 152

FACTORY INSTALLED BELT DRIVE KIT SPECIFICATIONS

| Motor Efficiency | Nominal hp | Maximum hp | Drive Kit Number | RPM Range |
|------------------|------------|------------|------------------|-------------|
| Standard & High | 2 | 2.3 | 1 | 590 - 890 |
| Standard & High | 2 | 2.3 | 2 | 800 - 1105 |
| Standard & High | 2 | 2.3 | 3 | 795 - 1195 |
| Standard | 3 | 3.45 | 4 | 730 - 970 |
| Standard | 3 | 3.45 | 5 | 940 - 1200 |
| Standard | 3 | 3.45 | 6 | 1015 - 1300 |
| High | 3 | 3.45 | 7 | 730 - 970 |
| High | 3 | 3.45 | 8 | 940 - 1200 |
| High | 3 | 3.45 | 9 | 1015 - 1300 |
| Standard | 5 | 5.75 | 10 | 900 - 1135 |
| Standard | 5 | 5.75 | 11 | 1040 - 1315 |
| Standard | 5 | 5.75 | 12 | 1125 - 1425 |

NOTE - Using total air volume and system static pressure requirements determine from blower performance tables rpm and motor output required. Maximum usable output of motors furnished are shown. In Canada, nominal motor output is also maximum usable motor output. If motors of comparable output are used, be sure to keep within the service factor limitations outlined on the motor nameplate.

NOTE - Units equipped with Multi-Stage Air Volume option are limited to a motor service factor of 1.0.

POWER EXHAUST FAN PERFORMANCE

| Return Air System Static Pressure | Air Volume Exhausted |
|-----------------------------------|----------------------|
| in. w.g. | cfm |
| 0 | 3175 |
| 0.05 | 2955 |
| 0.10 | 2685 |
| 0.15 | 2410 |
| 0.20 | 2165 |
| 0.25 | 1920 |
| 0.30 | 1420 |
| 0.35 | 1200 |

FACTORY INSTALLED OPTIONS/FIELD INSTALLED ACCESSORY AIR RESISTANCE - in. w.g.

| Air Volume cfm | Wet Indoor Coil | | Gas Heat Exchanger | | | Economizer | Humiditrol Condenser Reheat Coil | Filters | | Return Air Adaptor Plate |
|----------------|-----------------|----------|--------------------|-------------|-----------|------------|----------------------------------|---------|---------|--------------------------|
| | | | Standard Heat | Medium heat | High Heat | | | MERV 8 | MERV 13 | |
| | 092, 102 | 120, 150 | | | | | | | | |
| 1750 | 0.04 | 0.04 | 0.06 | 0.02 | 0.02 | 0.05 | 0.02 | 0.01 | 0.03 | 0.00 |
| 2000 | 0.05 | 0.05 | 0.07 | 0.05 | 0.06 | 0.06 | 0.02 | 0.01 | 0.03 | 0.00 |
| 2250 | 0.06 | 0.06 | 0.07 | 0.07 | 0.08 | 0.08 | 0.02 | 0.01 | 0.04 | 0.00 |
| 2500 | 0.07 | 0.07 | 0.09 | 0.10 | 0.11 | 0.11 | 0.03 | 0.01 | 0.05 | 0.00 |
| 2750 | 0.08 | 0.08 | 0.09 | 0.11 | 0.12 | 0.12 | 0.03 | 0.02 | 0.05 | 0.00 |
| 3000 | 0.10 | 0.09 | 0.11 | 0.12 | 0.13 | 0.13 | 0.03 | 0.02 | 0.06 | 0.02 |
| 3250 | 0.11 | 0.10 | 0.12 | 0.15 | 0.16 | 0.15 | 0.04 | 0.02 | 0.06 | 0.02 |
| 3500 | 0.12 | 0.11 | 0.12 | 0.16 | 0.17 | 0.15 | 0.04 | 0.03 | 0.07 | 0.04 |
| 3750 | 0.14 | 0.13 | 0.14 | 0.19 | 0.20 | 0.15 | 0.05 | 0.03 | 0.08 | 0.07 |
| 4000 | 0.15 | 0.14 | 0.14 | 0.21 | 0.22 | 0.19 | 0.05 | 0.04 | 0.08 | 0.09 |
| 4250 | 0.17 | 0.15 | 0.14 | 0.24 | 0.28 | 0.19 | 0.06 | 0.04 | 0.09 | 0.11 |
| 4500 | 0.19 | 0.17 | 0.15 | 0.26 | 0.32 | 0.22 | 0.07 | 0.04 | 0.09 | 0.12 |
| 4750 | 0.20 | 0.18 | 0.16 | 0.29 | 0.37 | 0.25 | 0.07 | 0.05 | 0.10 | 0.16 |
| 5000 | 0.22 | 0.20 | 0.16 | 0.34 | 0.43 | 0.29 | 0.08 | 0.06 | 0.10 | 0.18 |
| 5250 | 0.24 | 0.22 | 0.16 | 0.37 | 0.47 | 0.32 | 0.08 | 0.06 | 0.11 | 0.19 |
| 5500 | 0.25 | 0.23 | 0.18 | 0.44 | 0.54 | 0.34 | 0.09 | 0.07 | 0.12 | 0.22 |
| 5750 | 0.27 | 0.25 | 0.19 | 0.49 | 0.59 | 0.45 | 0.10 | 0.07 | 0.12 | 0.25 |
| 6000 | 0.29 | 0.27 | 0.20 | 0.54 | 0.64 | 0.52 | 0.10 | 0.08 | 0.13 | 0.27 |

BLOWER DATA

CEILING DIFFUSERS AIR RESISTANCE - in. w.g.

| Unit Size | RTD11 Step-Down Diffuser | | | FD11 Flush Diffuser | |
|--------------------------|--------------------------|-------------|------------------------|---------------------|--------------------------|
| | Air Volume cfm | 2 Ends Open | 1 Side, 2 Ends Open | | All Ends & Sides Open |
| 092, 094 Models | 2400 | 0.21 | 0.18 | 0.15 | 0.14 |
| | 2600 | 0.24 | 0.21 | 0.18 | 0.17 |
| | 2800 | 0.27 | 0.24 | 0.21 | 0.20 |
| | 3000 | 0.32 | 0.29 | 0.25 | 0.25 |
| | 3200 | 0.41 | 0.37 | 0.32 | 0.31 |
| | 3400 | 0.50 | 0.45 | 0.39 | 0.37 |
| | 3600 | 0.61 | 0.54 | 0.48 | 0.44 |
| 102, 120 & 122 Models | 3800 | 0.73 | 0.63 | 0.57 | 0.51 |
| | 3600 | 0.36 | 0.28 | 0.23 | 0.15 |
| | 3800 | 0.40 | 0.32 | 0.26 | 0.18 |
| | 4000 | 0.44 | 0.36 | 0.29 | 0.21 |
| | 4200 | 0.49 | 0.40 | 0.33 | 0.24 |
| | 4400 | 0.54 | 0.44 | 0.37 | 0.27 |
| | 4600 | 0.60 | 0.49 | 0.42 | 0.31 |
| | 4800 | 0.65 | 0.53 | 0.46 | 0.35 |
| 150, 152 Models | 5000 | 0.69 | 0.58 | 0.50 | 0.39 |
| | 5200 | 0.75 | 0.62 | 0.54 | 0.43 |
| | 4200 | 0.22 | 0.19 | 0.16 | 0.10 |
| | 4400 | 0.28 | 0.24 | 0.20 | 0.12 |
| | 4600 | 0.34 | 0.29 | 0.24 | 0.15 |
| | 4800 | 0.40 | 0.34 | 0.29 | 0.19 |
| | 5000 | 0.46 | 0.39 | 0.34 | 0.23 |
| | 5200 | 0.52 | 0.44 | 0.39 | 0.27 |
| | 5400 | 0.58 | 0.49 | 0.43 | 0.31 |
| 5600 | 0.64 | 0.54 | 0.47 | 0.35 | |
| 5800 | 0.70 | 0.59 | 0.51 | 0.39 | |

CEILING DIFFUSER AIR THROW DATA

| Model No. | Air Volume cfm | ¹ Effective Throw Range | |
|-------------------------|-------------------|------------------------------------|------------|
| | | RTD11 Step-Down | FD11 Flush |
| | | ft. | ft. |
| 092, 094 Models | 2600 | 24 - 29 | 19 - 24 |
| | 2800 | 25 - 30 | 20 - 28 |
| | 3000 | 27 - 33 | 21 - 29 |
| | 3200 | 28 - 35 | 22 - 29 |
| | 3400 | 30 - 37 | 22 - 30 |
| 102, 120, 122 Models | 3600 | 25 - 33 | 22 - 29 |
| | 3800 | 27 - 35 | 22 - 30 |
| | 4000 | 29 - 37 | 24 - 33 |
| | 4200 | 32 - 40 | 26 - 35 |
| | 4400 | 34 - 42 | 28 - 37 |
| 150, 152 Models | 5600 | 39 - 49 | 28 - 37 |
| | 5800 | 42 - 51 | 29 - 38 |
| | 6000 | 44 - 54 | 40 - 50 |
| | 6200 | 45 - 55 | 42 - 51 |
| | 6400 | 46 - 55 | 43 - 52 |
| | 6600 | 47 - 56 | 45 - 56 |

¹ Throw is the horizontal or vertical distance an air stream travels on leaving the outlet or diffuser before the maximum velocity is reduced to 50 ft. per minute. Four sides open.

BLOWER DATA - DIRECT DRIVE - 094U, 122U, 152U

BLOWER TABLE INCLUDES RESISTANCE FOR BASE UNIT ONLY (NO HEAT SECTION) WITH DRY INDOOR COIL AND AIR FILTERS IN PLACE.

FOR ALL UNITS ADD:

- 1 - Wet indoor coil air resistance of selected unit.
- 2 - Any factory installed options air resistance (heat section, economizer, etc.)
- 3 - Any field installed accessories air resistance (duct resistance, diffuser, etc.)

MAXIMUM STATIC PRESSURE WITH GAS HEAT - 2.0 in. w.g.

| Air Volume cfm | Total Static Pressure - in. w.g. | | | | | | | | | | | | | |
|-------------------|---|-------|------|-------|------|-------|------|-------|------|-------|------|-------|------|-------|
| | 0.2 | | 0.4 | | 0.6 | | 0.8 | | 1.0 | | 1.2 | | 1.4 | |
| | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts |
| 1750 | 711 | 188 | 771 | 279 | 836 | 366 | 905 | 453 | 975 | 544 | 1044 | 640 | 1109 | 737 |
| 2000 | 752 | 242 | 812 | 332 | 876 | 420 | 944 | 510 | 1011 | 606 | 1075 | 709 | 1138 | 812 |
| 2250 | 799 | 300 | 860 | 389 | 923 | 479 | 988 | 575 | 1052 | 678 | 1113 | 787 | 1171 | 896 |
| 2500 | 853 | 362 | 914 | 453 | 976 | 548 | 1038 | 650 | 1097 | 761 | 1154 | 877 | 1209 | 990 |
| 2750 | 914 | 434 | 974 | 529 | 1033 | 629 | 1091 | 739 | 1146 | 858 | 1199 | 979 | 1250 | 1098 |
| 3000 | 980 | 513 | 1037 | 614 | 1092 | 720 | 1146 | 837 | 1198 | 961 | 1247 | 1088 | 1295 | 1215 |
| 3250 | 1048 | 598 | 1101 | 705 | 1153 | 819 | 1203 | 941 | 1251 | 1071 | 1298 | 1206 | 1343 | 1343 |
| 3500 | 1116 | 693 | 1166 | 809 | 1214 | 931 | 1261 | 1060 | 1307 | 1198 | 1351 | 1341 | 1395 | 1489 |
| 3750 | 1185 | 806 | 1232 | 931 | 1277 | 1063 | 1322 | 1201 | 1365 | 1348 | 1407 | 1499 | 1448 | 1657 |
| 4000 | 1254 | 937 | 1299 | 1072 | 1341 | 1214 | 1383 | 1363 | 1424 | 1518 | 1464 | 1679 | 1503 | 1844 |
| 4250 | 1324 | 1089 | 1366 | 1234 | 1406 | 1386 | 1445 | 1545 | 1484 | 1708 | 1522 | 1876 | 1559 | 2046 |
| 4500 | 1395 | 1262 | 1433 | 1417 | 1471 | 1579 | 1508 | 1745 | 1544 | 1913 | 1581 | 2084 | 1616 | 2256 |
| 4750 | 1465 | 1455 | 1501 | 1619 | 1536 | 1787 | 1571 | 1957 | 1606 | 2128 | 1641 | 2299 | 1675 | 2470 |
| 5000 | 1534 | 1666 | 1568 | 1834 | 1602 | 2004 | 1635 | 2174 | 1668 | 2345 | 1701 | 2514 | 1735 | 2682 |
| 5250 | 1603 | 1887 | 1635 | 2055 | 1667 | 2224 | 1699 | 2392 | 1731 | 2559 | 1763 | 2724 | --- | --- |
| 5500 | 1671 | 2110 | 1702 | 2275 | 1733 | 2441 | 1764 | 2605 | --- | --- | --- | --- | --- | --- |
| 5750 | 1738 | 2325 | 1768 | 2488 | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- |
| Total | Total Static Pressure - in. w.g. | | | | | | | | | | | | | |

| Air Volume cfm | Total Static Pressure - in. w.g. | | | | | | | | | | | |
|-------------------|----------------------------------|-------|------|-------|------|-------|------|-------|------|-------|------|-------|
| | 1.6 | | 1.8 | | 2.0 | | 2.2 | | 2.4 | | 2.6 | |
| | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts |
| 1750 | 1172 | 833 | 1231 | 932 | 1287 | 1039 | 1340 | 1156 | 1391 | 1283 | 1442 | 1426 |
| 2000 | 1197 | 913 | 1253 | 1019 | 1306 | 1135 | 1357 | 1261 | 1407 | 1398 | 1457 | 1547 |
| 2250 | 1227 | 1003 | 1280 | 1117 | 1330 | 1242 | 1379 | 1378 | 1428 | 1525 | 1477 | 1680 |
| 2500 | 1261 | 1103 | 1311 | 1226 | 1360 | 1361 | 1407 | 1507 | 1454 | 1663 | 1501 | 1826 |
| 2750 | 1299 | 1219 | 1347 | 1350 | 1394 | 1494 | 1440 | 1649 | 1485 | 1813 | 1530 | 1982 |
| 3000 | 1342 | 1346 | 1388 | 1487 | 1432 | 1640 | 1476 | 1803 | 1520 | 1973 | 1563 | 2146 |
| 3250 | 1388 | 1485 | 1432 | 1638 | 1475 | 1800 | 1517 | 1969 | 1558 | 2143 | 1600 | 2319 |
| 3500 | 1437 | 1643 | 1479 | 1805 | 1519 | 1975 | 1560 | 2148 | 1600 | 2325 | 1640 | 2502 |
| 3750 | 1489 | 1821 | 1528 | 1990 | 1567 | 2164 | 1605 | 2340 | 1645 | 2517 | 1685 | 2693 |
| 4000 | 1541 | 2014 | 1579 | 2187 | 1616 | 2364 | 1654 | 2540 | 1693 | 2715 | 1732 | 2887 |
| 4250 | 1596 | 2218 | 1632 | 2393 | 1668 | 2569 | 1705 | 2742 | 1743 | 2913 | --- | --- |
| 4500 | 1652 | 2429 | 1687 | 2603 | 1722 | 2775 | 1759 | 2944 | --- | --- | --- | --- |
| 4750 | 1709 | 2641 | 1743 | 2811 | 1778 | 2979 | --- | --- | --- | --- | --- | --- |
| 5000 | 1768 | 2850 | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- |
| 5250 | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- |
| 5500 | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- |
| 5750 | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- | --- |

ELECTRICAL DATA

7.5 TON HIGH EFFICIENCY (R-410A)

LGH092H4

| ¹ Voltage - 60hz | | 208/230V - 3 Ph | | | 460V - 3 Ph | | | 575V - 3 Ph | | |
|---|--------------------------------|-----------------|------|------|-------------|-----|-----|-------------|-----|-----|
| Compressor 1 | Rated Load Amps | 13.1 | | | 6.1 | | | 4.4 | | |
| | Locked Rotor Amps | 83.1 | | | 41 | | | 33 | | |
| Compressor 2 | Rated Load Amps | 13.1 | | | 6.1 | | | 4.4 | | |
| | Locked Rotor Amps | 83.1 | | | 41 | | | 33 | | |
| Outdoor Fan Motors (2) | Full Load Amps | 2.4 | | | 1.3 | | | 1 | | |
| | (total) | (4.8) | | | (2.6) | | | (2) | | |
| Power Exhaust (1) 0.33 HP | Full Load Amps | 2.4 | | | 1.3 | | | 1 | | |
| Service Outlet 115V GFI (amps) | | 15 | | | 15 | | | 20 | | |
| Indoor Blower Motor | Horsepower | 2 | 3 | 5 | 2 | 3 | 5 | 2 | 3 | 5 |
| | Full Load Amps | 7.5 | 10.6 | 16.7 | 3.4 | 4.8 | 7.6 | 2.7 | 3.9 | 6.1 |
| ² Maximum Overcurrent Protection | Unit Only | 50 | 50 | 60 | 25 | 25 | 30 | 15 | 20 | 20 |
| | With (1) 0.33 HP Power Exhaust | 50 | 60 | 70 | 25 | 25 | 30 | 20 | 20 | 25 |
| ³ Minimum Circuit Ampacity | Unit Only | 42 | 45 | 52 | 20 | 22 | 25 | 15 | 16 | 19 |
| | With (1) 0.33 HP Power Exhaust | 45 | 48 | 55 | 22 | 23 | 26 | 16 | 17 | 20 |

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

¹ Extremes of operating range are plus and minus 10% of line voltage.

² HACR type breaker or fuse.

³ Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.

8.5 TON HIGH EFFICIENCY (R-410A)

LGH102H4

| ¹ Voltage - 60hz | | 208/230V - 3 Ph | | | 460V - 3 Ph | | | 575V - 3 Ph | | |
|---|--------------------------------|-----------------|------|------|-------------|-----|-----|-------------|-----|-----|
| Compressor 1 | Rated Load Amps | 13.7 | | | 6.2 | | | 4.8 | | |
| | Locked Rotor Amps | 83.1 | | | 41 | | | 33 | | |
| Compressor 2 | Rated Load Amps | 13.7 | | | 6.2 | | | 4.8 | | |
| | Locked Rotor Amps | 83.1 | | | 41 | | | 33 | | |
| Outdoor Fan Motors (2) | Full Load Amps | 2.4 | | | 1.3 | | | 1 | | |
| | (total) | (4.8) | | | (2.6) | | | (2) | | |
| Power Exhaust (1) 0.33 HP | Full Load Amps | 2.4 | | | 1.3 | | | 1 | | |
| Service Outlet 115V GFI (amps) | | 15 | | | 15 | | | 20 | | |
| Indoor Blower Motor | Horsepower | 2 | 3 | 5 | 2 | 3 | 5 | 2 | 3 | 5 |
| | Full Load Amps | 7.5 | 10.6 | 16.7 | 3.4 | 4.8 | 7.6 | 2.7 | 3.9 | 6.1 |
| ² Maximum Overcurrent Protection | Unit Only | 50 | 50 | 60 | 25 | 25 | 30 | 20 | 20 | 25 |
| | With (1) 0.33 HP Power Exhaust | 50 | 60 | 70 | 25 | 25 | 30 | 20 | 20 | 25 |
| ³ Minimum Circuit Ampacity | Unit Only | 44 | 47 | 54 | 20 | 22 | 25 | 16 | 17 | 20 |
| | With (1) 0.33 HP Power Exhaust | 46 | 49 | 56 | 22 | 23 | 26 | 17 | 18 | 21 |

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

¹ Extremes of operating range are plus and minus 10% of line voltage.

² HACR type breaker or fuse.

³ Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.

ELECTRICAL DATA

10 TON HIGH EFFICIENCY (R-410A)

LGH120H4

| ¹ Voltage - 60hz | | 208/230V - 3 Ph | | | 460V - 3 Ph | | | 575V - 3 Ph | | |
|---|--------------------------------|-----------------|------|------|-------------|-----|-----|-------------|-----|-----|
| Compressor 1 | Rated Load Amps | 16 | | | 7.8 | | | 5.7 | | |
| | Locked Rotor Amps | 110 | | | 52 | | | 38.9 | | |
| Compressor 2 | Rated Load Amps | 16 | | | 7.8 | | | 5.7 | | |
| | Locked Rotor Amps | 110 | | | 52 | | | 38.9 | | |
| Outdoor Fan Motors (2) | Full Load Amps | 2.4 | | | 1.3 | | | 1 | | |
| | (total) | (4.8) | | | (2.6) | | | (2) | | |
| Power Exhaust (1) 0.33 HP | Full Load Amps | 2.4 | | | 1.3 | | | 1 | | |
| Service Outlet 115V GFI (amps) | | 15 | | | 15 | | | 20 | | |
| Indoor Blower Motor | Horsepower | 2 | 3 | 5 | 2 | 3 | 5 | 2 | 3 | 5 |
| | Full Load Amps | 7.5 | 10.6 | 16.7 | 3.4 | 4.8 | 7.6 | 2.7 | 3.9 | 6.1 |
| ² Maximum Overcurrent Protection | Unit Only | 50 | 50 | 60 | 30 | 30 | 35 | 20 | 20 | 25 |
| | With (1) 0.33 HP Power Exhaust | 50 | 60 | 70 | 30 | 30 | 35 | 20 | 20 | 25 |
| ³ Minimum Circuit Ampacity | Unit Only | 43 | 46 | 53 | 24 | 26 | 29 | 16 | 18 | 20 |
| | With (1) 0.33 HP Power Exhaust | 46 | 49 | 56 | 26 | 27 | 30 | 17 | 19 | 21 |

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

¹ Extremes of operating range are plus and minus 10% of line voltage.

² HACR type breaker or fuse.

³ Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.

12.5 TON HIGH EFFICIENCY (R-410A)

LGH150H4

| ¹ Voltage - 60hz | | 208/230V - 3 Ph | | | 460V - 3 Ph | | | 575V - 3 Ph | | |
|---|--------------------------------|-----------------|------|------|-------------|-----|-----|-------------|-----|-----|
| Compressor 1 | Rated Load Amps | 19.6 | | | 8.2 | | | 6.6 | | |
| | Locked Rotor Amps | 136 | | | 66.1 | | | 55.3 | | |
| Compressor 2 | Rated Load Amps | 22.4 | | | 10.6 | | | 7.7 | | |
| | Locked Rotor Amps | 149 | | | 75 | | | 54 | | |
| Outdoor Fan Motors (2) | Full Load Amps | 3.2 | | | 1.7 | | | 1.5 | | |
| | (total) | (6.4) | | | (3.4) | | | (3) | | |
| Power Exhaust (1) 0.33 HP | Full Load Amps | 2.4 | | | 1.3 | | | 1 | | |
| Service Outlet 115V GFI (amps) | | 15 | | | 15 | | | 20 | | |
| Indoor Blower Motor | Horsepower | 2 | 3 | 5 | 2 | 3 | 5 | 2 | 3 | 5 |
| | Full Load Amps | 7.5 | 10.6 | 16.7 | 3.4 | 4.8 | 7.6 | 2.7 | 3.9 | 6.1 |
| ² Maximum Overcurrent Protection | Unit Only | 80 (70) | 80 | 90 | 35 | 35 | 40 | 25 | 30 | 30 |
| | With (1) 0.33 HP Power Exhaust | 80(70) | 80 | 90 | 35 | 40 | 40 | 30 | 30 | 30 |
| ³ Minimum Circuit Ampacity | Unit Only | 62 (58) | 65 | 71 | 28 | 30 | 33 | 22 | 23 | 25 |
| | With (1) 0.33 HP Power Exhaust | 64 (60) | 67 | 73 | 30 | 31 | 34 | 23 | 24 | 26 |

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

¹ Extremes of operating range are plus and minus 10% of line voltage.

² HACR type breaker or fuse.

³ Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.

ELECTRICAL DATA**7.5 TON****DIRECT DRIVE****LGH094U4E**

| ¹ Voltage - 60hz | | 208/230V - 3 Ph | 460V - 3 Ph | 575V - 3 Ph |
|---|--------------------------------|-----------------|-------------|-------------|
| Compressor 1 | Rated Load Amps | 13.1 | 6.1 | 4.4 |
| | Locked Rotor Amps | 83.1 | 41 | 33 |
| Compressor 2 | Rated Load Amps | 13.1 | 6.1 | 4.4 |
| | Locked Rotor Amps | 83.1 | 41 | 33 |
| Outdoor Fan Motors (3) | Full Load Amps | 2.8 | 1.4 | 1.1 |
| | (total) | (8.4) | (4.2) | (3.3) |
| Power Exhaust (1) 0.33 HP | Full Load Amps | 2.4 | 1.3 | 1 |
| Service Outlet 115V GFI (amps) | | 15 | 15 | 20 |
| Indoor Blower Motor | Horsepower | 3.75 | 3.75 | 3.75 |
| | Full Load Amps | 8.8 | 4.3 | 3.4 |
| ² Maximum Overcurrent Protection | Unit Only | 60 | 30 | 20 |
| | With (1) 0.33 HP Power Exhaust | 60 | 30 | 20 |
| ³ Minimum Circuit Ampacity | Unit Only | 51 | 25 | 19 |
| | With (1) 0.33 HP Power Exhaust | 53 | 26 | 20 |

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

¹ Extremes of operating range are plus and minus 10% of line voltage.² HACR type breaker or fuse.³ Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.**ELECTRICAL DATA****10 TON****DIRECT DRIVE****LGH122U4E**

| ¹ Voltage - 60hz | | 208/230V - 3 Ph | 460V - 3 Ph | 575V - 3 Ph |
|---|--------------------------------|-----------------|-------------|-------------|
| Compressor 1 | Rated Load Amps | 16 | 7.8 | 5.7 |
| | Locked Rotor Amps | 110 | 52 | 38.9 |
| Compressor 2 | Rated Load Amps | 16 | 7.8 | 5.7 |
| | Locked Rotor Amps | 110 | 52 | 38.9 |
| Outdoor Fan Motors (3) | Full Load Amps | 2.8 | 1.4 | 1.1 |
| | (total) | (8.4) | (4.2) | (3.3) |
| Power Exhaust (1) 0.33 HP | Full Load Amps | 2.4 | 1.3 | 1 |
| Service Outlet 115V GFI (amps) | | 15 | 15 | 20 |
| Indoor Blower Motor | Horsepower | 3.75 | 3.75 | 3.75 |
| | Full Load Amps | 8.8 | 4.3 | 3.4 |
| ² Maximum Overcurrent Protection | Unit Only | 70 | 35 | 25 |
| | With (1) 0.33 HP Power Exhaust | 70 | 35 | 25 |
| ³ Minimum Circuit Ampacity | Unit Only | 58 | 29 | 22 |
| | With (1) 0.33 HP Power Exhaust | 60 | 30 | 23 |

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

¹ Extremes of operating range are plus and minus 10% of line voltage.² HACR type breaker or fuse.³ Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.

ELECTRICAL DATA**12.5 TON****DIRECT DRIVE****LGH152U4E**

| ¹ Voltage - 60hz | | 208/230V - 3 Ph | 460V - 3 Ph | 575V - 3 Ph |
|---|--------------------------------|-----------------|-------------|-------------|
| Compressor 1 | Rated Load Amps | 19.6 | 8.2 | 6.6 |
| | Locked Rotor Amps | 136 | 66.1 | 55.3 |
| Compressor 2 | Rated Load Amps | 19.6 | 8.2 | 6.6 |
| | Locked Rotor Amps | 136 | 66.1 | 55.3 |
| Outdoor Fan Motors (3) | Full Load Amps | 2.8 | 1.4 | 1.1 |
| | (total) | (8.4) | (4.2) | (3.3) |
| Power Exhaust (1) 0.33 HP | Full Load Amps | 2.4 | 1.3 | 1 |
| Service Outlet 115V GFI (amps) | | 15 | 15 | 20 |
| Indoor Blower Motor | Horsepower | 3.75 | 3.75 | 3.75 |
| | Full Load Amps | 8.8 | 4.3 | 3.4 |
| ² Maximum Overcurrent Protection | Unit Only | 80 | 35 | 30 |
| | With (1) 0.33 HP Power Exhaust | 80 | 35 | 30 |
| ³ Minimum Circuit Ampacity | Unit Only | 66 | 30 | 24 |
| | With (1) 0.33 HP Power Exhaust | 68 | 31 | 25 |

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

¹ Extremes of operating range are plus and minus 10% of line voltage.² HACR type breaker or fuse.³ Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.

ELECTRICAL DATA**7.5 TON****BELT DRIVE****LGH094U4M**

| ¹ Voltage - 60hz | | 208/230V - 3 Ph | | | 460V - 3 Ph | | | 575V - 3 Ph | | |
|---|--------------------------------|-----------------|------|------|-------------|-----|-----|-------------|-----|-----|
| Compressor 1 | Rated Load Amps | 13.1 | | | 6.1 | | | 4.4 | | |
| | Locked Rotor Amps | 83.1 | | | 41 | | | 33 | | |
| Compressor 2 | Rated Load Amps | 13.1 | | | 6.1 | | | 4.4 | | |
| | Locked Rotor Amps | 83.1 | | | 41 | | | 33 | | |
| Outdoor Fan Motors (3) | Full Load Amps | 2.8 | | | 1.4 | | | 1.1 | | |
| | (total) | (8.4) | | | (4.2) | | | (3.3) | | |
| Power Exhaust (1) 0.33 HP | Full Load Amps | 2.4 | | | 1.3 | | | 1 | | |
| Service Outlet 115V GFI (amps) | | 15 | | | 15 | | | 20 | | |
| Indoor Blower Motor | Horsepower | 2 | 3 | 5 | 2 | 3 | 5 | 2 | 3 | 5 |
| | Full Load Amps | 7.5 | 10.6 | 16.7 | 3.4 | 4.8 | 7.6 | 2.7 | 3.9 | 6.1 |
| ² Maximum Overcurrent Protection | Unit Only | 60 | 60 | 70 | 25 | 30 | 35 | 20 | 20 | 25 |
| | With (1) 0.33 HP Power Exhaust | 60 | 60 | 70 | 30 | 30 | 35 | 20 | 20 | 25 |
| ³ Minimum Circuit Ampacity | Unit Only | 50 | 53 | 60 | 24 | 25 | 28 | 18 | 19 | 22 |
| | With (1) 0.33 HP Power Exhaust | 52 | 55 | 62 | 25 | 27 | 30 | 19 | 20 | 23 |

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

¹ Extremes of operating range are plus and minus 10% of line voltage.² HACR type breaker or fuse.³ Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.⁴ Factory installed circuit breaker not available.**ELECTRICAL DATA****10 TON****BELT DRIVE****LGH122U4M**

| ¹ Voltage - 60hz | | 208/230V - 3 Ph | | | 460V - 3 Ph | | | 575V - 3 Ph | | |
|---|--------------------------------|-----------------|------|------|-------------|-----|-----|-------------|-----|-----|
| Compressor 1 | Rated Load Amps | 16.5 | | | 7.2 | | | 5.5 | | |
| | Locked Rotor Amps | 110 | | | 52 | | | 38.9 | | |
| Compressor 2 | Rated Load Amps | 16 | | | 7.8 | | | 5.7 | | |
| | Locked Rotor Amps | 110 | | | 52 | | | 38.9 | | |
| Outdoor Fan Motors (3) | Full Load Amps | 2.8 | | | 1.4 | | | 1.1 | | |
| | (total) | (8.4) | | | (4.2) | | | (3.3) | | |
| Power Exhaust (1) 0.33 HP | Full Load Amps | 2.4 | | | 1.3 | | | 1 | | |
| Service Outlet 115V GFI (amps) | | 15 | | | 15 | | | 20 | | |
| Indoor Blower Motor | Horsepower | 2 | 3 | 5 | 2 | 3 | 5 | 2 | 3 | 5 |
| | Full Load Amps | 7.5 | 10.6 | 16.7 | 3.4 | 4.8 | 7.6 | 2.7 | 3.9 | 6.1 |
| ² Maximum Overcurrent Protection | Unit Only | 70 | 70 | 80 | 30 | 35 | 35 | 25 | 25 | 25 |
| | With (1) 0.33 HP Power Exhaust | 70 | 70 | 80 | 35 | 35 | 35 | 25 | 25 | 30 |
| ³ Minimum Circuit Ampacity | Unit Only | 57 | 60 | 66 | 27 | 29 | 31 | 21 | 22 | 24 |
| | With (1) 0.33 HP Power Exhaust | 59 | 62 | 69 | 28 | 30 | 33 | 22 | 23 | 25 |

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

¹ Extremes of operating range are plus and minus 10% of line voltage.² HACR type breaker or fuse.³ Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.⁴ Factory installed circuit breaker not available.⁵ Disconnect must be field furnished.

ELECTRICAL DATA**7.5 TON****BELT DRIVE****LGH094U4M**

| ¹ Voltage - 60hz | | 208/230V - 3 Ph | | | 460V - 3 Ph | | | 575V - 3 Ph | | |
|---|--------------------------------|-----------------|------|------|-------------|-----|-----|-------------|-----|-----|
| Compressor 1 | Rated Load Amps | 13.1 | | | 6.1 | | | 4.4 | | |
| | Locked Rotor Amps | 83.1 | | | 41 | | | 33 | | |
| Compressor 2 | Rated Load Amps | 13.1 | | | 6.1 | | | 4.4 | | |
| | Locked Rotor Amps | 83.1 | | | 41 | | | 33 | | |
| Outdoor Fan Motors (3) | Full Load Amps | 2.8 | | | 1.4 | | | 1.1 | | |
| | (total) | (8.4) | | | (4.2) | | | (3.3) | | |
| Power Exhaust (1) 0.33 HP | Full Load Amps | 2.4 | | | 1.3 | | | 1 | | |
| Service Outlet 115V GFI (amps) | | 15 | | | 15 | | | 20 | | |
| Indoor Blower Motor | Horsepower | 2 | 3 | 5 | 2 | 3 | 5 | 2 | 3 | 5 |
| | Full Load Amps | 7.5 | 10.6 | 16.7 | 3.4 | 4.8 | 7.6 | 2.7 | 3.9 | 6.1 |
| ² Maximum Overcurrent Protection | Unit Only | 60 | 60 | 70 | 25 | 30 | 35 | 20 | 20 | 25 |
| | With (1) 0.33 HP Power Exhaust | 60 | 60 | 70 | 30 | 30 | 35 | 20 | 20 | 25 |
| ³ Minimum Circuit Ampacity | Unit Only | 50 | 53 | 60 | 24 | 25 | 28 | 18 | 19 | 22 |
| | With (1) 0.33 HP Power Exhaust | 52 | 55 | 62 | 25 | 27 | 30 | 19 | 20 | 23 |

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

¹ Extremes of operating range are plus and minus 10% of line voltage.² HACR type breaker or fuse.³ Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.⁴ Factory installed circuit breaker not available.**ELECTRICAL DATA****10 TON****BELT DRIVE****LGH122U4M**

| ¹ Voltage - 60hz | | 208/230V - 3 Ph | | | 460V - 3 Ph | | | 575V - 3 Ph | | |
|---|--------------------------------|-----------------|------|------|-------------|-----|-----|-------------|-----|-----|
| Compressor 1 | Rated Load Amps | 16.5 | | | 7.2 | | | 5.5 | | |
| | Locked Rotor Amps | 110 | | | 52 | | | 38.9 | | |
| Compressor 2 | Rated Load Amps | 16 | | | 7.8 | | | 5.7 | | |
| | Locked Rotor Amps | 110 | | | 52 | | | 38.9 | | |
| Outdoor Fan Motors (3) | Full Load Amps | 2.8 | | | 1.4 | | | 1.1 | | |
| | (total) | (8.4) | | | (4.2) | | | (3.3) | | |
| Power Exhaust (1) 0.33 HP | Full Load Amps | 2.4 | | | 1.3 | | | 1 | | |
| Service Outlet 115V GFI (amps) | | 15 | | | 15 | | | 20 | | |
| Indoor Blower Motor | Horsepower | 2 | 3 | 5 | 2 | 3 | 5 | 2 | 3 | 5 |
| | Full Load Amps | 7.5 | 10.6 | 16.7 | 3.4 | 4.8 | 7.6 | 2.7 | 3.9 | 6.1 |
| ² Maximum Overcurrent Protection | Unit Only | 70 | 70 | 80 | 30 | 35 | 35 | 25 | 25 | 25 |
| | With (1) 0.33 HP Power Exhaust | 70 | 70 | 80 | 35 | 35 | 35 | 25 | 25 | 30 |
| ³ Minimum Circuit Ampacity | Unit Only | 57 | 60 | 66 | 27 | 29 | 31 | 21 | 22 | 24 |
| | With (1) 0.33 HP Power Exhaust | 59 | 62 | 69 | 28 | 30 | 33 | 22 | 23 | 25 |

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

¹ Extremes of operating range are plus and minus 10% of line voltage.² HACR type breaker or fuse.³ Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.⁴ Factory installed circuit breaker not available.⁵ Disconnect must be field furnished.

**PARTS ARRANGEMENT - 092H, 102H, 120H, 150S
ALL-ALUMINUM COIL SYSTEM**




FIGURE 1

**PARTS ARRANGEMENT - 092H, 102H, 120H, 150H
FIN/TUBE COIL**




FIGURE 2

**PARTS ARRANGEMENT - 094U, 122U, 152U
FIN/TUBE COIL**




FIGURE 3

**CONTROL BOX PARTS ARRANGEMENT -
STANDARD AND HIGH EFFICIENCY NON-CE UNITS**




FIGURE 4

CONTROL BOX PARTS ARRANGEMENT - ULTRA HIGH EFFICIENCY NON-CE UNITS




FIGURE 5

CONTROL BOX PARTS ARRANGEMENT - CE UNITS




FIGURE 6

I-UNIT COMPONENTS

⚠ WARNING



Electric shock hazard. Can cause injury or death. Before attempting to perform any service or maintenance, turn the electrical power to unit OFF at disconnect switch(es). Unit may have multiple power supplies.

All 7.5 through 12.5 ton (38.1 through 70.3 kW) units are configured to order units (CTO). The LGH unit components are shown in figure 1, 2 or 3. All units come standard with hinged unit panels. All L1, L2 and L3 wiring is color coded; L1 is red, L2 is yellow and L3 is blue.

A-Control Box Components

ELECTROSTATIC DISCHARGE (ESD) Precautions and Procedures

⚠ CAUTION

Electrostatic discharge can affect electronic components. Take precautions during unit installation and service to protect the unit's electronic controls. Precautions will help to avoid control exposure to electrostatic discharge by putting the unit, the control and the technician at the same electrostatic potential. Neutralize electrostatic charge by touching hand and all tools on an unpainted unit surface, such as the gas valve or blower deck, before performing any service procedure.

LGH control box components are shown in figures 4, 5 and 6. The control box is located in the upper portion of the compressor compartment.

1-Disconnect Switch S48 (Optional)

All units may be equipped with an optional disconnect switch S48. Other factory or field installed optional circuit breakers may be used, such as CB10. S48 and CB10 are toggle switches, which can be used by the service technician to disconnect power to the unit.

2-Control Transformer T1

All use a single line voltage to 24VAC transformer mounted in the control box. Transformer supplies power to control circuits in the unit. The transformer is rated at 70VA and is protected by a 3.5 amp circuit breaker (CB8). The 208/230 (Y) voltage transformers use primary voltage taps as shown in figure 7, while 460 (G) and 575 (J) voltage transformers use a single primary voltage tap.

3-Outdoor Fan Relay K10, K68

Outdoor fan relays K10 and K68 are DPDT relays with a 24VAC coil. In standard and high efficiency units, K10 and K68 energize condenser fans B4 and B5. In ultra high efficiency units, K10 and K68 energize compressor 1 and 2 crankcase heaters.

4-Outdoor Fan Capacitors C1, C2 (non-Ultra units)

Fan capacitors C1 and C2 370V / 10 MFD capacitors are used to assist in the start up of condenser fans B4 and B5.




FIGURE 7

5-C. A. I. Transformers T3 all 460V & 575V units

All LGH 460 (G) and 575 (J) voltage units use transformer T3. The auto voltage to 230VAC transformer is mounted in the control box. The transformer has an output rating of 0.5A. T3 transformer supplies 230 VAC power to combustion air blower motor (B6).

6-Compressor Contactor K1, K2

All compressor contactors are three-pole, double-break contactors with 24VAC coils. K1 and K2 (both energized by A55) energize compressors B1 and B2. On CE M-volt units, contactor is CE approved by manufacturer (Siemens). See figure 8.




FIGURE 8

7-Combustion Air Inducer Relay K13

Combustion air inducer relay K13, used in all LGH units, is a DPDT relay with a 24VAC coil. K13 is energized by the A55 Unit Controller. K13 remains energized throughout the heating demand. When energized, K13 N.O. contacts close to energize combustion air blower and begin a heating sequence. Pressure switch S18, located in the compressor compartment, closes as combustion air static pressure falls to "prove" combustion air inducer operation. When S18 closes, the ignition controls and gas valves are energized to begin a heating sequence.

8-Blower Contactor K3

K3 is used in units with a constant blower speed or a staged blower which is not equipped with a bypass option. K3 is a three-pole-double-break contactor with a 24VAC coil used to energize the indoor blower motor B3 in response to blower demand. K3 is energized by A55 Unit Controller. On M-volt CE units, the contactor is CE approved by manufacturer (Siemens). See figure 8.

9-Burner Controls A3

A3 controls gas heat section burner controls. Burner controls are factory set and are not adjustable. The control makes three attempts at ignition and then locks out the system if ignition is not obtained after the third trial. Reset after lockout requires only breaking and remaking thermostat demand. The control shuts off gas flow immediately in the event of a gas or power failure. Upon restoration of gas and power, the control will restart the ignition sequence and continue until flame is established or system locks out. For a more detailed description see the Gas Heat Components section.

10-Power Exhaust Relay K65 (PED units)

Power exhaust relay K65 is a N.O. DPDT relay with a 24VAC coil. K65 is used in all LGH units equipped with the optional power exhaust dampers. K65 is energized by the economizer control panel (A56), after the economizer dampers reach 50% open (adjustable in ECTO). When K65 closes, the exhaust fans B10 and B11 are energized.

11-Blower Motor Overload Relay S42

Two hp high efficiency blower motors and M-volt unit blower motors are equipped with an overload relay. High efficiency blower motors and M-volt unit blower motors manufactured before Dec. 19, 2010, are equipped with the relay. Ultra high efficiency units equipped with a direct drive blower have an internal overload.

The relay (S42) is connected in line with the blower motor to monitor the current flow to the motor. When the relay senses an overload condition, a set of normally closed contacts open to de-energize the blower. Units will be equipped with a relay manufactured by Telemecanique figure 9 or Siemens figure 10.

12-Unit Controller A55

The Unit Controller provides all unit control functions, unit status information, unit diagnostics, programmable parameters and USB verification and profile sharing. Use the Unit Controller keypad and display to navigate through menus. Software is also available to access the Unit Controller. Refer to the Unit Controller guide provided with the unit. Thermostat wires are connected to J297 on the Unit Controller.




FIGURE 9




FIGURE 10

13-Compressor Overload Relays S176, S177 (M-volt CE units)

Relays are wired in series with the appropriate compressor contactor and monitor the current flow to the compressor motor. When the relay senses an overload condition, N.C. contacts open to de-energize the compressor. Relays are manufactured by Siemens; see figure 11.




FIGURE 11

14-Variable Frequency Drive A96 (optional)

Units may be equipped with a VFD which alters the supply power frequency and voltage to the blower motor. Blower speed is staged depending on the compressor stages, heating demand, ventilation demand, or smoke alarm. The amount of airflow for each stage is preset from the factory. Airflow can be adjusted as shown in Belt Drive Supply Air Inverter section. The VFD is located below the Unit Controller.

15-VFD Power To Motor Contactor K202 (optional)

Contactor is used in VFD units equipped with a VFD bypass option. The three-pole contactor with a 24VAC coil is energized by the A55 Unit Controller. K202 allows power from the VFD to the B3 blower motor in response to blower demand.

16-Inverter Start Forward Rotation Relay K203 (optional)

Relay is used in optional VFD units and is a three-pole double-throw relay with a 24VAC coil. K203 is energized by the A55 Unit Controller and provides input to the A96 VFD to start blower forward rotation. K203 also de-energizes K3 allowing A96 to control B3 blower.

17-VFD Controller (GP board) A133 (VFD units)

M2 and earlier versions of Unit Controller only. The GP board A133 controls and monitors the status of the VFD A96. The board sends the signal to start the VFD forward rotation and also sends a 0-10VDC signal to the VFD to control the speed of the blower rotation. A133 also reports VFD malfunctions to the A55.

**PLUMBING, COMPRESSOR AND REFRIGERANT CIRCUITS DETAIL
(HIGH EFFICIENCY ALL-ALUMINUM OUTDOOR COIL)**





FIGURE 12
Page 31

**PLUMBING, COMPRESSOR AND REFRIGERANT CIRCUITS DETAIL
(OPTIONAL STANDARD EFFICIENCY FIN/TUBE COIL)**





FIGURE 13

**PLUMBING, COMPRESSOR AND REFRIGERANT CIRCUITS DETAIL
(OPTIONAL ULTRA HIGH EFFICIENCY UNITS WITH FIN/TUBE COIL)**





FIGURE 14

B-Cooling Components

Standard and high efficiency units use independent cooling circuits consisting of separate compressors, condenser coils and evaporator coils. See figure 12 or 13. Ultra high efficiency units use a common cooling circuit consisting of two compressors in parallel, two condenser coils in parallel, and one evaporator coil. See figure 14. On standard and high efficiency units, two draw-through type condenser fans are used. On ultra high efficiency units, three draw-through type condenser fans are used. Standard and high efficiency units are equipped with belt-drive blowers which draw air across the evaporator during unit operation. Ultra high efficiency units are equipped with either a belt-drive blower or a drive drive blower which draws air across the evaporator during unit operation.

On standard and high efficiency units, the evaporators are slab type and are stacked. Each evaporator uses a thermostatic expansion valve as the primary expansion device. Ultra high efficiency units are equipped with a single slab style evaporator. The evaporator uses two thermostatic expansions valves. Evaporators are equipped with enhanced fins and rifled tubing.

In all units, each compressor is protected by a crankcase heater, high pressure switch and low pressure switch. Additional protection is provided by low ambient switches and freezestats. Ultra high efficiency units are also equipped with a suction line pressure transducer and compressor sump thermistors (temperature sensors) for added compressor reliability.

Cooling may be supplemented by a factory- or field-installed economizer.

1-Compressors B1, B2

Standard and high efficiency units are equipped with two scroll compressors and two independent cooling circuits. Ultra efficiency units are equipped with two scroll compressors and one common cooling circuit. Compressor capacity may vary from stage to stage. In all cases, the capacity of each compressor is added to reach the total capacity of the unit. See "SPECIFICATIONS" and "ELECTRICAL DATA" (table of contents) or compressor nameplate for compressor specifications.

WARNING

Electrical shock hazard. Compressor must be grounded. Do not operate without protective cover over terminals. Disconnect power before removing protective cover. Discharge capacitors before servicing unit. Failure to follow these precautions could cause electrical shock resulting in injury or death.

Each compressor is energized by a corresponding compressor contactor.

NOTE-Refer to the wiring diagram section for specific unit operation.

If Interlink compressor replacement is necessary, call 1-800-453-6669.

IMPORTANT

Some scroll compressors have an internal vacuum protector that will unload scrolls when suction pressure goes below 20 psig. A hissing sound will be heard when the compressor is running unloaded. Protector will reset when low pressure in system rises above 40 psig. DO NOT REPLACE COMPRESSOR.

2-Crankcase Heaters HR1, HR2

All LGH units use insertion type heaters. Heater HR1 is installed around compressor B1 and heater HR2 is installed around compressor B2. Crankcase heater wattage varies by compressor size.

3-High Pressure Switches S4, S7

The high pressure switch is an auto-reset SPST N.C. switch which opens on a pressure rise. All units are equipped with this switch. On fin/tube outdoor coils, the switch is located in the compressor discharge line. On all-aluminum outdoor coils, the switch is located on the liquid line in the blower section. Switches are wired in series with the compressor contactor coil.

On standard and high efficiency units, S4 (first circuit) and S7 (second circuit) are wired in series with the respective compressor contactor coils. On ultra high efficiency units, only S4 is used. S4 is located on the common compressor discharge line and is wired to both compressor contactors via the A55 Unit Controller.

All-Aluminum Coil Units -

When discharge pressure rises to 610 ± 15 psig (4206 ± 103 kPa) (indicating a problem in the system) the switch opens and the respective compressor is de-energized (the economizer can continue to operate). When discharge pressure drops to 475 ± 15 psig (3275 ± 103 kPa) the pressure switch will close.

Fin/Tube Coil Units -

On standard and high efficiency units, when discharge pressure rises to 640 ± 10 psig (4413 ± 69 kPa) (indicating a problem in the system) the switch opens and the respective compressor is de-energized (the economizer can continue to operate). When discharge pressure drops to 475 ± 20 psig (3275 ± 138 kPa) the pressure switch will close.

On ultra high efficiency units, BOTH compressors are de-energized or energized at the pressures listed in the previous paragraph.

The A55 Unit Controller has a three-strike counter before locking out. This means the control allows three high pressure trips per one thermostat demand. The control can be reset by breaking and remaking the thermostat demand or manually resetting the control.

4-Low Ambient Switches S11, S84

The low ambient switch is an auto-reset SPST N.O. pressure switch which allows mechanical cooling operation at low outdoor temperatures. On standard and high efficiency units, the switches are located in each liquid line prior to the indoor coil section. On ultra high efficiency units, S11 (only) is located on the common liquid line prior to the indoor coil section.

On standard and high efficiency units, S11 and S84 are wired to the A55 Unit Controller which cycles outdoor fans via K10 (outdoor fan 1) and K68 (outdoor fan 2). On ultra high efficiency units, S11 is wired to the A55 Unit Controller which cycles outdoor fan 1 (outdoor fans 2 and 3 are de-energized during low ambient operation).

When liquid pressure rises to 450 ± 10 psig (3102 ± 69 kPa), the switch closes and the condenser fan is energized. When discharge pressure in one refrigerant circuit drops to 240 ± 10 psig (1655 ± 69 kPa), the switch opens and the condenser fan in that refrigerant circuit is de-energized. This intermittent fan operation results in higher evaporating temperature allowing the system to operate without icing the evaporator coil and losing capacity.

5-Service Valve (optional)

Non-reheat, fin/tube coil condenser units may be equipped with service valves located in the discharge and liquid lines. The service valves are manually operated valves used for service operation.

6-Filter Drier

LGH units have a filter drier located in the liquid line of each refrigerant circuit. See figure 12, 13, or 14. The drier removes contaminants and moisture from the system.

7-Low Pressure Switches S87, S88

The low pressure switch is an auto-reset SPST N.O. switch (held N.C. by refrigerant pressure) which opens on a pressure drop. All units are equipped with this switch. The switch is located in the compressor suction line.

On standard and high efficiency units, S87 (compressor one) and S88 (compressor two) are wired to A55 Unit Controller. On ultra high efficiency units, S87 (only) is located on the common suction line and is wired to A55 Unit Controller.

A55 governs the low pressure switches by shunting the switches during start up until pressure is stabilized. After the shunt period, the control has a three-strike counter, during first thermostat demand, before the compressor is locked out. The control is reset by breaking and remaking the thermostat demand or manually resetting the control.

When suction pressure drops to 40 ± 5 psig (276 ± 34 kPa), (indicating low pressure), the switch opens and the compressor(s) is(are) de-energized. The switch automatically resets when pressure in the suction line rises to 90 ± 5 psig (620 ± 34 kPa) due to many causes such as refrigerant being added.

8-Condenser Fans B4, B5, B21

See SPECIFICATIONS tables at the front of this manual for specifications of condenser fans used in all units. All condenser fans have single-phase motors. The fan assembly may be removed for servicing and cleaning.

Ultra High Efficiency Units Only

Ultra high efficiency units are equipped with electronically commutated condenser fan motors (ECM). The ECM motors are wired directly to 230VAC power but do not operate until a pulse width modulated (PWM) control signal is sent from the A55 Unit Controller. The PWM signal determines the condenser fan speed. All three fans will operate in low speed with a Y1 demand; all three fans will operate in high speed with a Y2 demand.

Both low and high voltage plugs are located at the top of the blower compartment in the indoor section of the unit. Condenser fan motors B4, B5 and B21 high voltage plugs are J86, J87 and J88 respectively. Low voltage plugs are J336, J337 and J338 respectively. Refer to wiring markings to identify plugs. Use figure 15 to identify fan motors.

If an ECM fan is not operating:

- 1- Check to make sure high voltage is present before checking low voltage.
- 2- Read the voltage at the appropriate high voltage fan motor plug (J86, J87, or J88) using the VAC meter setting.
- 3- If high voltage is present, check the low voltage plug (J336, J337, or J338) for a signal from the Unit Controller. Use either the duty cycle (%) or a VDC meter setting.

Note - The VDC reading may fluctuate and is normal for a PWM signal.




FIGURE 15

9-Freezestats S49 and S50

Standard and high efficiency units are equipped with a low temperature switch (freezestat) located on the return bend of each evaporator coil. S49 (first circuit) and S50 (second circuit) are located on the corresponding evaporator coils. Ultra high efficiency units are equipped with S49 only which is located on the return bend of the common evaporator coil.

Each freezestat is wired to the A55 Unit Controller. Each freezestat is a SPST N.C. auto-reset switch which opens at $29^{\circ}\text{F} \pm 3^{\circ}\text{F}$ ($-1.7^{\circ}\text{C} \pm 1.7^{\circ}\text{C}$) on a temperature drop and closes at $58^{\circ}\text{F} \pm 4^{\circ}\text{F}$ ($14.4^{\circ}\text{C} \pm 2.2^{\circ}\text{C}$) on a temperature rise. To prevent coil icing, freezestats open during compressor operation to temporarily disable the respective compressor until the coil warms sufficiently to melt any accumulated frost.

If the freezestats are tripping frequently due to coil icing, check the unit charge, airflow and filters before allowing unit back in operation. Make sure to eliminate conditions which might promote evaporator ice buildup.

10-Temperature Sensors RT37 and RT38

Ultra high efficiency units are equipped with a temperature sensor (thermistor) located on the back of each compressor underneath the crankcase heater. The A55 Unit Controller uses input from RT37 (compressor 1), RT38 (compressor 2) and A185 pressure transducer to calculate sump superheat for each compressor. The Unit Controller uses this information to optimize system reliability.

Verify the sensor value using the menu path:

MAIN MENU > DATA > IN/OUTPUTS > SENSORS > LOCAL

Sensors should read within +/- 5 degrees of actual compressor sump temperature. Make sure the sensor is making sufficient contact with the compressor shell.

11-Pressure Transducer A185

Ultra high efficiency units are equipped with a pressure transducer located on the common suction line. The Unit Controller uses the input from the transducer, RT37 and RT38 to calculate sump superheat for each compressor. The Unit Controller uses this information to optimize system reliability.

Verify the sensor value using the menu path:

MAIN MENU > DATA > IN/OUTPUTS > SENSORS > LOCAL

A185 should read within +/- 10 psi of actual suction pressure.

TO INCREASE BELT TENSION

STANDARD BLOWER ASSEMBLY

- 1- Loosen four bolts securing motor mounting base to frame.
- 2- Turn adjusting bolt to the right, or clockwise, to move the motor away from the blower housing.

IMPORTANT - Gap between end of frame and motor mounting base should be equal at both ends, i.e. parallel along gap.

- 3- Tighten four bolts securing motor mounting base to frame.
- 4- Relieve tension on two adjusting bolts.





FIGURE 16

TENSIONER BLOWER ASSEMBLY (VIEW SHOWN WITHOUT BELT)




FIGURE 17




FIGURE 18

C-Blower Compartment

The blower compartment is located between the evaporator coil and the condenser coil section. The blower assembly is secured to a sliding frame which allows the blower motor assembly to be pulled out of the unit. See figure 16, 17, or 18.

Belt Drive Blowers

- 1- Loosen the reusable wire tie which secures the blower wiring to the blower motor mounting plate.
- 2- Remove and retain screws on either side of sliding frame. Pull frame toward outside of unit.
- 3- Slide frame back into original position when finished servicing. Reattach the blower wiring in the previous location on the blower motor base using the wire tie.
- 4- Replace retained screws on either side of the sliding frame.

Direct Drive Blowers

- 1- Loosen the reusable wire tie which secures the controls and high voltage blower wiring to the blower housing.
- 2- Remove and retain screws in front and on either side of blower housing. Pull frame toward outside of unit.
- 3- Slide frame back into original position when finished servicing. Reattach the blower wiring in the previous location on the blower housing using the wire tie.
- 4- Replace retained screws in front and on either side of the blower housing.

1-Blower Wheels

Belt drive blowers are equipped with one 15 in. x 15 in. (381 mm x 381 mm) blower wheel. Ultra high efficiency units may be equipped with an optional direct drive blower assembly with a backward inclined blower wheel.

2-Indoor Blower Motor B3

Belt driven blowers use three-phase single-speed blower motors. CFM adjustments are made by adjusting the motor pulley (sheave). Ultra high efficiency units may be equipped with an optional direct drive blower assembly with a three-phase, variable speed, direct drive blower motor.

All motor specifications are listed in the SPECIFICATIONS (table of contents) in the front of this manual. Units may be equipped with motors manufactured by various manufacturers, therefore electrical FLA and LRA specifications will vary. See unit rating plate for information specific to your unit.

OPERATION / ADJUSTMENT

VFD / Direct Drive Units - The blower rotation will always be correct on VFD units. Checking blower rotation is not a valid method of determining voltage phasing for incoming power. To check for proper voltage phasing, measure compressor suction and discharge pressures. Make sure suction pressure decreases and discharge pressure increases on start-up.

VFD / Direct Drive Units and Units Equipped With Optional Factory-Installed Voltage or Phase Detection - The Unit Controller checks the incoming power during start-up (A55 P299-1 and P269-2). If the voltage, phase, or frequency is incorrect, the Unit Controller will display an alarm and the unit will not start. If line voltage is corrected,

the Unit Controller will energize the unit after five (default) minutes. While line voltage is continually checked by the Unit Controller, the voltage phasing is not. If one or more phases is interrupted, power to one or more transformers is interrupted and the unit is shut down by either the Unit Controller or the corresponding transformer.

Note - Optional phase/voltage detection is set at the factory and is enabled by the Unit Controller internal logic. If an after market device is installed, refer to the device manufacturer's literature.

On units equipped with Unit Controller firmware version 7.06 and earlier:

Voltage, phase and frequency are checked on start-up

Blower Operation

NOTE-The following is a generalized procedure and does not apply to all thermostat control systems.

- 1- Blower operation is dependent on the thermostat control system option that has been installed in the units. Refer to operation sequence of the control system installed for detailed descriptions of blower operation.
- 2- Generally, blower operation is set at the thermostat fan switch. With the fan switch in "ON" position and the **OCP** input is "**ON**", the blower operates continuously. With the fan switch in "AUTO" position, the blower cycles with demand.
- 3- In most cases, the blower and entire unit will be off when the system switch is in the "OFF" position. The only exception is immediately after a heating demand when the blower control keeps the blower on until all heat is extracted from the heat exchanger.

Determining Unit Air Volume

IMPORTANT - VFD units are factory-set to run the blower at full speed when there is a blower (G) demand without a heating or cooling demand. Refer to the field-provided, design specified CFM for all modes of operation. Use the following procedure to adjust motor pulley to deliver the highest CFM called for in the design spec. See Supply Air Inverter Start-Up section to set blower CFM for all modes once the motor pulley is set.

IMPORTANT - Direct drive variable blower unit CFM is determined by the Unit Controller. Refer to the Direct Drive Variable Speed Start-Up section.

- 1- The following measurements must be made with a dry indoor coil. Run blower without a cooling demand. Measure the indoor blower shaft RPM. Air filters must be in place when measurements are taken.
- 2- With all access panels in place, measure static pressure external to unit (from supply to return). Blower performance data is based on static pressure readings taken in locations shown in figure 19.

Note - Static pressure readings can vary if not taken where shown.

- 3- Refer to blower tables in BLOWER DATA (table of contents) in the front of this manual. Use static pressure and RPM readings to determine unit air volume. Apply accessory air resistance tables when installing units with any of the optional accessories listed.

4- Standard Blowers -

The blower RPM can be adjusted at the motor pulley. Loosen Allen screw and turn adjustable pulley clockwise to increase CFM. Turn counterclockwise to decrease CFM. See figure 16. Do not exceed minimum and maximum number of pulley turns as shown in table 1.

Tensioner Blowers -

Refer to label on motor base. See figure 17.

**TABLE 1
MINIMUM AND MAXIMUM PULLEY ADJUSTMENT**

| Belt | Minimum Turns Open | Maximum Turns Open |
|-----------|--------------------|--------------------|
| A Section | 0 | 5 |
| B Section | 1* | 6 |

*No minimum turns open when B belt is used on pulleys 6" O.D. or larger.

! IMPORTANT

Three Phase Scroll Compressor Voltage Phasing

Three phase scroll compressors must be phased sequentially to ensure correct compressor and blower* rotation and operation. Compressor and blower are wired in phase at the factory. Power wires are color-coded as follows: line 1-red, line 2-yellow, line 3-blue.

1-Observe suction and discharge pressures and blower* rotation on unit start-up.

2-Suction pressure must drop, discharge pressure must rise and blower* rotation must match rotation marking.

If pressure differential is not observed or blower* rotation is not correct:

3-Disconnect all remote electrical power supplies.

4-Reverse any two field-installed wires connected to the line side of S48 disconnect or TB13 terminal strip. Do not reverse wires at blower contactor.

5-Make sure the connections are tight.

Discharge and suction pressures should operate at their normal start-up ranges.

*Supply air VFD motors should rotate in the correct direction; verify scroll compressor rotation separately. Contact technical support if the VFD blower is rotating incorrectly.




FIGURE 19

Blower Belt Adjustment

Maximum life and wear can be obtained from belts only if proper pulley alignment and belt tension are maintained. Tension new belts after a 24-48 hour period of operation. This will allow belt to stretch and seat in the pulley grooves. Make sure blower and motor pulleys are aligned as shown in figure 20.




FIGURE 20

1- Loosen four bolts securing motor base to mounting frame. See figure 16 or 17.

2- *To increase belt tension* - Turn both adjusting bolts to the right, or clockwise, to move the motor outward and tighten the belt. This increases the distance between the blower motor and the blower housing.

To loosen belt tension - Turn the adjusting bolt to the left, or counterclockwise to loosen belt tension.

IMPORTANT - Align edges of blower motor base and mounting frame base parallel before tightening four bolts on the side of base. Motor shaft and blower shaft must be parallel.

3- Tighten bolts on side of base.

Check Belt Tension

Overtensioning belts shortens belt and bearing life. Check belt tension as follows:

- 1- Measure span length X. See figure 21.
- 2- Apply perpendicular force to center of span (X) with enough pressure to deflect belt 1/64" for every inch of span length or 1.5mm per 100mm of span length.
Example: Deflection distance of a 40" span would be 40/64" or 5/8".
Example: Deflection distance of a 400mm span would be 6mm.
- 3- Measure belt deflection force. For a new 2 and 3hp belt, the deflection force should be 5.0-7.0 lbs. (35-48kPa). For a new 5hp belt, the deflection force should be 7-10lbs. (48-69kPa).

A force below these values indicates an undertensioned belt. A force above these values indicates an overtensioned belt.




FIGURE 21

F-Field-Furnished Blower Drives

For field-furnished blower drives, use the the blower tables in the BLOWER TABLES section of this manual to determine BHP, RPM and drive kit required. Reference table 2 for drive component manufacturer's numbers.

**TABLE 2
MANUFACTURER'S NUMBERS**

| Drive No. | DRIVE COMPONENTS | | | | | |
|--------------------|------------------|--------------|--------------------|--------------|--------------|--------------|
| | Motor Pulley | | Blower Pulley | | Belt | |
| | Supplier No. | OEM Part No. | Supplier No. | OEM Part No. | Supplier No. | OEM Part No. |
| A01 | 1VP34x7/8 | 31K6901 | AK54 x 1 | 100244-19 | A40 | 100245-17 |
| A02 | 1VP34x7/8 | 31K6901 | AK49 x 1 | 100244-18 | A39 | 100245-16 |
| A03 | 1VP34x7/8 | 31K6901 | AK44 x 1 | 100244-16 | A39 | 100245-16 |
| A05 | 1VP34x7/8 | 31K6901 | AK41 x 1 | 100244-15 | A39 | 100245-16 |
| A06 | 1VP44x7/8 | P-8-1488 | AK51 x 1 | 18L2201 | A41 | 100245-18 |
| A07 | 1VP50x7/8 | P-8-2187 | AK54 x 1 | 100244-19 | AX43 | 73K8201 |
| AA01 | 1VP34x7/8 | 31K6901 | AK69 x 1 | 37L4701 | AX51 | 13H0101 |
| AA02 | 1VP40x7/8 | 79J0301 | BK80H ¹ | 100788-03 | A53 | P-8-4951 |
| AA03 | 1VP40x7/8 | 79J0301 | AK59 x 1 | 31K6801 | A50 | 100245-29 |
| AA04 | 1VP44x7/8 | P-8-1488 | AK59 x 1 | 31K6801 | AX51 | 13H0101 |
| A01T ² | 1VP34x7/8 | 31K6901 | AK54 x 1 | 100244-19 | A41 | 100245-18 |
| A02T ² | 1VP34x7/8 | 31K6901 | AK49 x 1 | 100244-18 | A40 | 100245-17 |
| A03T ² | 1VP34x7/8 | 31K6901 | AK44 x 1 | 100244-16 | A40 | 100245-17 |
| A05T ² | 1VP34x7/8 | 31K6901 | AK41 x 1 | 100244-15 | A41 | 100245-18 |
| A06T ² | 1VP44x7/8 | P-8-1488 | AK51 x 1 | 18L2201 | A41 | 100245-18 |
| A07T ² | 1VP50x7/8 | P-8-2187 | AK54 x 1 | 100244-19 | AX43 | 73K8201 |
| AA01T ² | 1VP34x7/8 | 31K6901 | AK69 x 1 | 37L4701 | A50 | 100245-29 |
| AA02T ² | 1VP40x7/8 | 79J0301 | BK80H* | 100788-03 | A52 | 100245-30 |
| AA03T ² | 1VP40x7/8 | 79J0301 | AK59 x 1 | 31K6801 | A49 | 100245-32 |
| AA04T ² | 1VP44x7/8 | P-8-1488 | AK59 x 1 | 31K6801 | A50 | 100245-29 |

NOTES: ¹ Requires split taper bushing, Browning no. H1; OEM no. 100073-04 ² Includes tension assembly, Fenner no. FS0590; OEM no. 101994-02

D-GAS HEAT COMPONENTS

See unit nameplate for all -1 model unit Btuh capacities. See SPECIFICATIONS tables or unit nameplate for Btuh capacities in -2 model units. Flexible pipe will feed supply gas to both sections. If for service the flexible connection must be broken, hand tighten then turn additional 1/4" with a wrench for metal to metal seal (do not overtighten).

NOTE - Do not use thread sealing compound on flex pipe flare connections.

1-Control Box Components A3, A55, T3, K13

⚠ WARNING

Shock hazard. Spark related components contain high voltage which can cause personal injury or death. Disconnect power before servicing. Control is not field repairable. Unsafe operation will result. If control is inoperable, simply replace the entire control.

Burner Ignition Control A3

The ignition control is located in the heat section and is manufactured by Johnson Controls. See table 3 for LED codes.

TABLE 3

| Manufacturer | LED Code | Description |
|--------------|-------------------------|------------------------------|
| Johnson | Steady "ON" | Normal |
| | .5 sec on / 2.5 sec off | Reset Mode |
| | "OFF" | No Power or Detected Failure |

The ignition control provides three main functions: gas valve control, ignition and flame sensing. The unit will usually ignite on the first attempt; however, the ignition attempt sequence provides three trials for ignition before locking out. The lockout time for the Johnson control is 5 minutes. After lockout, the ignition control automatically resets and provides three more attempts at ignition. Manual reset after lockout requires breaking and remaking power to the ignition control. See figure 22 for a normal ignition sequence and figure 23 for the ignition attempt sequence with retrials (nominal timings given for simplicity). Specific timings for the ignition controls are shown in figure 24.




FIGURE 22




FIGURE 23




FIGURE 24

Flame rectification sensing is used on all LGH units. Loss of flame during a heating cycle is indicated by an absence of flame signal (0 microamps). If this happens, the control will immediately restart the ignition sequence and then lock out if ignition is not gained after the third trial. See System Service Checks section for flame current measurement.

The control shuts off gas flow immediately in the event of a power failure. Upon restoration of gas and power, the control will restart the ignition sequence and continue until flame is established or system locks out.

On a heating demand, the ignition control is energized by the A55 Unit Controller. The ignition control then allows 30 to 40 seconds for the combustion air blower to vent exhaust gases from the burners. When the combustion air blower is purging the exhaust gases, the combustion air prove switch is closing proving that the combustion air blower is operating before allowing the ignition control to energize. When the combustion air prove switch is closed and the delay is over, the ignition control activates gas valve, the spark electrode and the flame sensing electrode. Sparking stops immediately after flame is sensed. The combustion air blower continues to operate throughout the heating demand. If the flame fails or if the burners do not ignite, the ignition control will attempt to ignite the burners up to two more times. If ignition cannot be obtained after the third attempt, the control will lock out. The ignition control is not adjustable.

2-Heat Exchanger (Figures 25 and 26)

The LGH units use aluminized steel inshot burners with matching tubular aluminized (stainless steel is an option) steel heat exchangers and two-stage redundant gas valves. Units are equipped with one eleven tube/burner for high heat and one six tube/burner for standard heat. Burners use a burner venturi to mix gas and air for proper combustion. Combustion takes place at each tube entrance. As hot combustion gases are drawn upward through each tube by the combustion air blower, exhaust gases are drawn out the top and fresh air/gas mixture is drawn in at the bottom. Heat is transferred to the air stream from all surfaces of the heat exchanger tubes. The supply air blowers, controlled by the A55 Unit Controller, force air across all surfaces of the tubes to extract the heat of combustion. The shape of the tubes ensures maximum heat exchange.

The gas valves accomplish staging by allowing more or less gas to the burners as called for by heating demand.

3-Gas Heat Exchanger Inserts - Direct Drive Only

Inserts are installed on standard (130,000Btuh) and high (240,000Btuh) heat exchangers. Medium heat exchangers do not require inserts. See figure 27. Inserts are used to maintain even temperature distribution through the heat exchanger. Temperature distribution can vary depending on supply air flow, number of heat exchanger tubes and the blower deck opening.




FIGURE 25




FIGURE 26

4-Burner Assembly (Figure 28)

The burners are controlled by the spark electrode, flame sensing electrode, gas valve and combustion air blower. The spark electrode, flame sensing electrode and gas valve are directly controlled by ignition control. Ignition control and combustion air blower is controlled by A55 Unit Controller.

Burners

All units use inshot burners (see figure 28). Burners are factory set and do not require adjustment. A peep hole with cover is furnished in the heating access panel for flame viewing. Always operate the unit with the access panel in place.

Burners can be removed individually for service. Burner maintenance and service is detailed in the SERVICE CHECKS section of this manual.

INSERT LOCATION - DIRECT DRIVE ONLY

STANDARD HEAT (130,000BTUH)

HIGH HEAT (180,000BTUH)

Note - No inserts on medium heat.





FIGURE 27

5-Primary High Temperature Limits S10

S10 is the primary high temperature limit and is located on the blower deck to the right of the blower housing.

Primary limit S10 is wired to the A55 Unit Controller which energizes burner 1 control (A3). Its N.C. contacts open to de-energize the ignition control when excessive temperature is reached in the blower compartment. At the same time, the N.O. contacts of S10 close energizing the blower relay coil K3 through A55. If the limit trips the blower will be energized. Limit settings are factory set and cannot be adjusted. If limit must be replaced, the same type and set point must be used.

TYPICAL GAS BURNER ASSEMBLY




FIGURE 28


Orifice

Each burner uses an orifice (two types figure 29) which is precisely matched to the burner input. **Install only the orifices with the same threads.** The orifice is threaded into the burner manifold. The burner is supported by the orifice and will easily slide off for service.

NOTE-Do not use thread sealing compound on the orifices. Using thread sealing compound may plug the orifices.


Each orifice and burner are sized specifically to the unit. Refer to ProductZone@www.davenet.com for correct sizing information.

ORIFICE WITH STRAIGHT THREADS



Tighten to 14 ± .5 ft/lbs
Do not over-tighten.

ORIFICE WITH PIPE THREADS



Tighten to 6.25 ± .5 ft.lbs.
Do not over-tighten.

FIGURE 29

6-Flame Roll-out Limit S47

Flame roll-out limit S47 is a SPST N.C. high temperature limit located as shown in figure 30. S47 is wired to the A55 Unit Controller. When S47 senses flame roll-out (indicating a blockage in the combustion air passages), the flame roll-out limit trips and the ignition control immediately closes the gas valve.

Limit S47 in standard heat units is factory preset to open at $250^{\circ}\text{F} \pm 12^{\circ}\text{F}$ ($121.1^{\circ}\text{C} \pm 6.7^{\circ}\text{C}$) on a temperature rise. All flame roll-out limits are manual reset.

7-Combustion Air Prove Switch S18

S18 is a SPST N.O. switch which monitors combustion air inducer operation. See figure 30 for location. Switch S18 is wired to the A55 Unit Controller.

The switch closes on a *negative* pressure fall. This negative pressure fall and switch actuation allows the ignition sequence to continue (proves, by closing, that the combustion air inducer is operating before allowing the gas valve to open.) The combustion air prove switch is factory set and not adjustable. The switch will automatically open on a pressure rise (less negative pressure). S18 closes at 0.25 ± 5 in.w.c. (62.3 ± 12.4 Pa) and opens at 0.10 ± 5 in.w.c. (24.8 ± 12.4 Pa)

8-Combustion Air Inducer B6

The combustion air inducer provides fresh air to the burner while clearing the combustion chamber of exhaust gases. See figure 30 for the inducer location. The inducer is energized by the A55 Unit Controller via K13 relay.

The inducer uses a 208/230V single-phase PSC motor and a

4.81in. x 1.25in. (122mm x 32mm) blower wheel. The motor operates at 3200RPM and is equipped with auto-reset overload protection. Blower is supplied by various manufacturers. Ratings may vary by manufacturer. Specific blower electrical ratings can be found on the unit rating plate.

All combustion air blower motors are sealed and cannot be oiled. The blower cannot be adjusted but can be disassembled for cleaning.

9-Combustion Air Motor Capacitor C3

Combustion air inducer B6 requires a run capacitor rated at 3 MFD and 370VAC.

10-Gas Valves GV1

Gas valve GV1 is a two-stage redundant valve. Units are equipped with valves manufactured by White-Rodgers or Honeywell. On both valves first stage (low fire) is quick opening (on and off in less than 3 seconds). On the White-Rodgers valve second stage is slow opening (on to high fire pressure in 40 seconds and off to low fire pressure in 30 seconds). On the Honeywell second stage is quick opening. On a call for first stage heat (low fire), the valve is energized by the ignition control simultaneously with the spark electrode. On a call for second stage heat (high fire), the second stage operator is energized directly from A55. The White-Rodgers valve is adjustable for high fire only. Low fire is not adjustable. The Honeywell valve is adjustable for both low fire and high fire. A manual shut-off knob is provided on the valve for shut-off. Manual shut-off knob immediately closes both stages without delay. Figure 31 shows gas valve components. Table 4 shows factory gas valve regulation for LGH units.




FIGURE 30

TABLE 4

| GAS VALVE REGULATION FOR LGH UNITS | | | | |
|---|--|--------------------------|---------------------------|------------------------------|
| Maximum Inlet Pressure | Operating Pressure (outlet) Factory Setting | | | |
| | Natural | | L.P | |
| | Low | High | Low | High |
| 13.0"W.C. 3232Pa | 1.6±0.2"W.C. 398±50Pa | 3.7±0.3"W.C. 920±75Pa | 5.5±0.3"W.C. 1368±75Pa | 10.5±0.5"W.C. 2611±7124Pa |




FIGURE 31

11-Spark Electrodes

An electrode assembly is used for ignition spark. Two identical electrodes are used (one for each gas heat section). The electrode is mounted through holes on the left-most end of the burner support. The electrode tip protrudes into the flame envelope of the adjacent burner. The electrode assembly is fastened to burner supports and can be removed for service without removing any part of the burners.

During ignition, spark travels through the spark electrode (figure 32) and ignites the left burner. Flame travels from burner to burner until all are lit.

The spark electrode is connected to the ignition control by a 8 mm silicone-insulated stranded high voltage wire. The wire uses 1/4" (6.35 mm) female quick connect on the electrode end and female spark plug-type terminal on the ignition control end.

NOTE- IN ORDER TO MAXIMIZE SPARK ENERGY TO ELECTRODE, HIGH VOLTAGE WIRE SHOULD TOUCH UNIT CABINET AS LITTLE AS POSSIBLE.




FIGURE 32

12-Flame Sensors

A flame sensor is located on the right side of each burner support. The sensor is mounted through a hole in the burner support and the tip protrudes into the flame envelope of the right most burner. The sensor assembly is fastened to burner supports and can be removed for service without removing any part of the burners.

When flame is sensed by the flame sensor (indicated by microamp signal through the flame) sparking stops immediately. During operation, flame is sensed by current passed along the ground electrode (located on the spark electrode), through the flame and into the sensing electrode. The ignition control allows the gas valve to stay open as long as a flame signal (current passed through the flame) is sensed.




FIGURE 33

II-PLACEMENT AND INSTALLATION

Make sure the unit is installed in accordance with the installation instructions and all applicable codes. See accessories section for conditions requiring use of the optional roof mounting frame (C1CURB10).

III-CHARGING

WARNING

Refrigerant can be harmful if it is inhaled. Refrigerant must be used and recovered responsibly.

Failure to follow this warning may result in personal injury or death.

IMPORTANT

Units equipped with a Hot Gas Reheat system **MUST** be charged in standard cooling mode.

A-Refrigerant Charge and Check - All-Aluminum Coil 092H, 102H, 120H, 150S Units

WARNING-Do not exceed nameplate charge under any condition.

This unit is factory charged and should require no further adjustment. If the system requires additional refrigerant, reclaim the charge, evacuate the system, and add required nameplate charge.

NOTE - System charging is not recommended below 60°F (15°C). In temperatures below 60°F (15°C), the charge must be weighed into the system.

If weighing facilities are not available, or to check the charge, use the following procedure:

IMPORTANT - Charge unit in standard cooling mode.

- 1- Make sure outdoor coil is clean. Attach gauge manifolds and operate unit at full CFM in cooling mode with econo-

mizer disabled until system stabilizes (approximately five minutes). Make sure all outdoor air dampers are closed.

- 2- Check each system separately with all stages operating. Compare the normal operating pressures (see tables 5 - 8) to the pressures obtained from the gauges. Check unit components if there are significant differences.
- 3- Measure the outdoor ambient temperature and the suction pressure. Refer to the appropriate circuit charging curve to determine a target liquid temperature.

Note - Pressures are listed for sea level applications.

- 4- Use the same thermometer to accurately measure the liquid temperature (in the outdoor section).
 - If measured liquid temperature is higher than the target liquid temperature, add refrigerant to the system.
 - If measured liquid temperature is lower than the target liquid temperature, recover some refrigerant from the system.
- 5- Add or remove charge in increments. Allow the system to stabilize each time refrigerant is added or removed.
- 6- Continue the process until measured liquid temperature agrees with the target liquid temperature. Do not go below the target liquid temperature when adjusting charge. Note that suction pressure can change as charge is adjusted.
- 7- Example LGH/LCH092 Circuit 1: At 95°F outdoor ambient and a measured suction pressure of 130psig, the target liquid temperature is 96°F. For a measured liquid temperature of 106°F, add charge in increments until measured liquid temperature agrees with the target liquid temperature.

TABLE 5

| LGH/LCH092H Normal Operating Pressures - All-Aluminum - TXV | | | | | | | | | | | | |
|---|---------------------------------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| | Outdoor Coil Entering Air Temperature | | | | | | | | | | | |
| | 65 °F | | 75 °F | | 85 °F | | 95 °F | | 105 °F | | 115 °F | |
| | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) |
| Circuit 1 | 110 | 234 | 112 | 273 | 115 | 317 | 116 | 367 | 119 | 428 | 121 | 503 |
| | 118 | 236 | 120 | 275 | 123 | 319 | 125 | 369 | 127 | 426 | 130 | 497 |
| | 136 | 240 | 139 | 278 | 142 | 320 | 145 | 369 | 147 | 422 | 150 | 483 |
| | 157 | 248 | 159 | 284 | 163 | 325 | 166 | 373 | 168 | 424 | 171 | 482 |
| Circuit 2 | 112 | 232 | 115 | 269 | 117 | 313 | 118 | 371 | 120 | 441 | 122 | 523 |
| | 119 | 237 | 122 | 273 | 125 | 316 | 128 | 367 | 129 | 431 | 132 | 508 |
| | 134 | 243 | 139 | 279 | 143 | 320 | 146 | 370 | 149 | 424 | 151 | 488 |
| | 155 | 253 | 156 | 287 | 161 | 328 | 165 | 376 | 169 | 427 | 172 | 487 |

TABLE 6



| LGH/LCH102H Normal Operating Pressures - All-Aluminum - TXV | | | | | | | | | | | | |
|--|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| Outdoor Coil Entering Air Temperature | | | | | | | | | | | | |
| | 65 °F | | 75 °F | | 85 °F | | 95 °F | | 105 °F | | 115 °F | |
| | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) |
| Circuit 1 | 111 | 234 | 113 | 273 | 115 | 316 | 117 | 365 | 119 | 419 | 121 | 480 |
| | 120 | 236 | 121 | 275 | 124 | 317 | 126 | 365 | 128 | 417 | 130 | 476 |
| | 139 | 241 | 142 | 279 | 144 | 321 | 147 | 367 | 148 | 420 | 151 | 476 |
| | 156 | 251 | 160 | 287 | 164 | 328 | 168 | 374 | 171 | 424 | 175 | 480 |
| Circuit 2 | 113 | 233 | 116 | 273 | 118 | 317 | 120 | 371 | 122 | 439 | 125 | 530 |
| | 122 | 233 | 124 | 273 | 126 | 317 | 128 | 369 | 131 | 428 | 134 | 502 |
| | 137 | 242 | 142 | 278 | 145 | 320 | 148 | 369 | 150 | 426 | 153 | 489 |
| | 155 | 251 | 159 | 288 | 164 | 328 | 168 | 375 | 171 | 429 | 174 | 488 |

TABLE 7


| LGH/LCH120H All-Aluminum Coil Normal Operating Pressures - TXV | | | | | | | | | | | | |
|---|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| Outdoor Coil Entering Air Temperature | | | | | | | | | | | | |
| | 65 °F | | 75 °F | | 85 °F | | 95 °F | | 105 °F | | 115 °F | |
| | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) |
| Circuit 1 | 113 | 251 | 113 | 290 | 112 | 331 | 116 | 383 | 117 | 439 | 120 | 520 |
| | 120 | 254 | 123 | 293 | 124 | 338 | 126 | 388 | 127 | 441 | 129 | 510 |
| | 139 | 264 | 142 | 303 | 144 | 345 | 147 | 393 | 146 | 445 | 148 | 510 |
| | 155 | 278 | 160 | 314 | 164 | 357 | 167 | 403 | 169 | 456 | 173 | 512 |
| Circuit 2 | 110 | 251 | 111 | 287 | 111 | 329 | 114 | 388 | 117 | 454 | 120 | 538 |
| | 119 | 249 | 120 | 291 | 122 | 336 | 124 | 389 | 126 | 447 | 128 | 520 |
| | 139 | 259 | 142 | 297 | 143 | 337 | 145 | 390 | 144 | 444 | 149 | 514 |
| | 155 | 274 | 160 | 307 | 164 | 349 | 166 | 393 | 169 | 448 | 170 | 510 |

TABLE 8


| LGH/LCH150S All-Aluminum Coil Normal Operating Pressures - TXV | | | | | | | | | | | | |
|---|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| Outdoor Coil Entering Air Temperature | | | | | | | | | | | | |
| | 65 °F | | 75 °F | | 85 °F | | 95 °F | | 105 °F | | 115 °F | |
| | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) |
| Circuit 1 | 111 | 259 | 113 | 301 | 115 | 345 | 114 | 396 | 117 | 456 | 120 | 526 |
| | 121 | 264 | 122 | 303 | 124 | 351 | 125 | 398 | 128 | 455 | 130 | 524 |
| | 140 | 274 | 142 | 313 | 145 | 357 | 146 | 405 | 148 | 460 | 151 | 525 |
| | 159 | 285 | 163 | 327 | 165 | 369 | 166 | 413 | 171 | 471 | 174 | 532 |
| Circuit 2 | 111 | 253 | 113 | 290 | 115 | 334 | 114 | 381 | 117 | 440 | 120 | 523 |
| | 122 | 255 | 122 | 294 | 124 | 336 | 125 | 385 | 127 | 440 | 130 | 520 |
| | 140 | 263 | 142 | 302 | 144 | 345 | 145 | 391 | 147 | 445 | 150 | 510 |
| | 159 | 274 | 163 | 314 | 165 | 355 | 165 | 397 | 170 | 455 | 172 | 513 |



LGH/LCH120H All-Aluminum Coil Charging Curves



LGH/LCH150S All-Aluminum Coil Charging Curves



B-Refrigerant Charge and Check - Fin/Tube Coil - TXV
LGH/LCH092H, 102H, 120H, 150S, 150H

WARNING-Do not exceed nameplate charge under any condition.

This unit is factory charged and should require no further adjustment. If the system requires additional refrigerant, re-claim the charge, evacuate the system, and add required nameplate charge.

NOTE - System charging is not recommended below 60°F (15°C). In temperatures below 60°F (15°C), the charge must be weighed into the system.

If weighing facilities are not available, or to check the charge, use the following procedure:

IMPORTANT - Charge unit in standard cooling mode.

- 1- Attach gauge manifolds and operate unit in cooling mode with economizer disabled until system stabilizes (approximately five minutes). Make sure outdoor air dampers are closed.
- 2- Check each system separately with all stages operating.
- 3- Use a thermometer to accurately measure the outdoor ambient temperature.
- 4- Apply the outdoor temperature to tables 9 through 18 to determine normal operating pressures. Pressures are listed for sea level applications at 80°F dry bulb and 67°F wet bulb return air.
- 5- Compare the normal operating pressures to the pressures obtained from the gauges. Minor variations in these pressures may be expected due to differences in installations. Significant differences could mean that the system is not properly charged or that a problem exists with some component in the system. **Correct any system problems before proceeding.**
- 6- If discharge pressure is high, remove refrigerant from the system. If discharge pressure is low, add refrigerant to the system.
 - Add or remove charge in increments.
 - Allow the system to stabilize each time refrigerant is added or removed.
- 7- Use the following approach method along with the normal operating pressures to confirm readings.

TABLE 9
LGH/LCH092H Fin/Tube Coil - TXV

| Outdoor Coil Entering Air Temp | CIRCUIT 1 | | CIRCUIT 2 | |
|--------------------------------|---------------------|-----------------|---------------------|-----------------|
| | Dis-charge ±10 psig | Suction ±5 psig | Dis-charge ±10 psig | Suction ±5 psig |
| 65°F | 235 | 137 | 262 | 137 |
| 75 °F | 272 | 139 | 298 | 141 |
| 85 °F | 312 | 142 | 338 | 144 |
| 95 °F | 357 | 146 | 380 | 146 |
| 105 °F | 407 | 149 | 428 | 149 |
| 115 °F | 460 | 154 | 477 | 153 |

TABLE 10
LGH/LCH092H Fin/Tube Coil Hot Gas Reheat - TXV

| Outdoor Coil Entering Air Temp | CIRCUIT 1 | | CIRCUIT 2 | |
|--------------------------------|---------------------|-----------------|---------------------|-----------------|
| | Dis-charge ±10 psig | Suction ±5 psig | Dis-charge ±10 psig | Suction ±5 psig |
| 65 °F | 242 | 134 | 262 | 139 |
| 75 °F | 279 | 137 | 297 | 143 |
| 85 °F | 319 | 140 | 338 | 146 |
| 95 °F | 364 | 143 | 379 | 148 |
| 105 °F | 414 | 146 | 427 | 151 |
| 115 °F | 467 | 151 | 476 | 155 |

TABLE 11
LGH/LCH102H Fin/Tube Coil - TXV

| Outdoor Coil Entering Air Temp | CIRCUIT 1 | | CIRCUIT 2 | |
|--------------------------------|---------------------|-----------------|---------------------|-----------------|
| | Dis-charge ±10 psig | Suction ±5 psig | Dis-charge ±10 psig | Suction ±5 psig |
| 65 °F | 241 | 139 | 273 | 141 |
| 75 °F | 277 | 141 | 307 | 144 |
| 85 °F | 318 | 143 | 348 | 147 |
| 95 °F | 362 | 145 | 389 | 149 |
| 105 °F | 411 | 148 | 437 | 151 |
| 115 °F | 464 | 150 | 486 | 152 |

TABLE 12
LGH/LCH102H Fin/Tube Coil Hot Gas Reheat - TXV

| Outdoor Coil Entering Air Temp | CIRCUIT 1 | | CIRCUIT 2 | |
|--------------------------------|---------------------|-----------------|---------------------|-----------------|
| | Dis-charge ±10 psig | Suction ±5 psig | Dis-charge ±10 psig | Suction ±5 psig |
| 65 °F | 249 | 137 | 272 | 142 |
| 75 °F | 285 | 139 | 306 | 145 |
| 85 °F | 327 | 141 | 347 | 148 |
| 95 °F | 370 | 143 | 389 | 150 |
| 105 °F | 420 | 146 | 436 | 152 |
| 115 °F | 473 | 148 | 485 | 154 |

TABLE 13
LGH/LCH120H Fin/Tube Coil - TXV

| Outdoor Coil Entering Air Temp | CIRCUIT 1 | | CIRCUIT 2 | |
|--------------------------------|---------------------|-----------------|---------------------|-----------------|
| | Dis-charge ±10 psig | Suction ±5 psig | Dis-charge ±10 psig | Suction ±5 psig |
| 65° F | 259 | 137 | 283 | 139 |
| 75° F | 297 | 140 | 321 | 142 |
| 85° F | 338 | 143 | 360 | 144 |
| 95° F | 382 | 146 | 406 | 146 |
| 105° F | 431 | 149 | 453 | 148 |
| 115° F | 486 | 151 | 505 | 151 |

TABLE 14
LGH/LCH120H Fin/Tube Coil Hot Gas Reheat - TXV

| Outdoor Coil Entering Air Temp | CIRCUIT 1 | | CIRCUIT 2 | |
|--------------------------------|---------------------|-----------------|---------------------|-----------------|
| | Dis-charge ±10 psig | Suction ±5 psig | Dis-charge ±10 psig | Suction ±5 psig |
| 65° F | 266 | 134 | 281 | 139 |
| 75° F | 303 | 137 | 310 | 141 |
| 85° F | 344 | 140 | 358 | 143 |
| 95° F | 391 | 143 | 403 | 145 |
| 105° F | 443 | 146 | 450 | 146 |
| 115° F | 499 | 149 | 497 | 148 |

TABLE 15
LGH/LCH150S Fin/Tube Coil - TXV

| Outdoor Coil Entering Air Temp | CIRCUIT 1 | | CIRCUIT 2 | |
|--------------------------------|---------------------|-----------------|---------------------|-----------------|
| | Dis-charge ±10 psig | Suction ±5 psig | Dis-charge ±10 psig | Suction ±5 psig |
| 65° F | 275 | 140 | 298 | 139 |
| 75° F | 312 | 142 | 335 | 141 |
| 85° F | 354 | 143 | 374 | 142 |
| 95° F | 398 | 146 | 419 | 146 |
| 105° F | 449 | 149 | 465 | 148 |
| 115° F | 500 | 151 | 514 | 150 |

TABLE 16
LGH/LCH150S Fin/Tube Coil Hot Gas Reheat - TXV

| Outdoor Coil Entering Air Temp | CIRCUIT 1 | | CIRCUIT 2 | |
|--------------------------------|---------------------|-----------------|---------------------|-----------------|
| | Dis-charge ±10 psig | Suction ±5 psig | Dis-charge ±10 psig | Suction ±5 psig |
| 65° F | 280 | 136 | 296 | 136 |
| 75° F | 319 | 141 | 335 | 141 |
| 85° F | 360 | 142 | 376 | 143 |
| 95° F | 407 | 144 | 420 | 144 |
| 105° F | 455 | 147 | 466 | 147 |
| 115° F | 510 | 150 | 518 | 150 |

TABLE 17
LGH/LCH150H Fin/Tube - TXV

| Outdoor Coil Entering Air Temp | CIRCUIT 1 | | CIRCUIT 2 | |
|--------------------------------|---------------------|-----------------|---------------------|-----------------|
| | Dis-charge ±10 psig | Suction ±5 psig | Dis-charge ±10 psig | Suction ±5 psig |
| 65°F | 276 | 131 | 275 | 125 |
| 75°F | 317 | 133 | 314 | 128 |
| 85°F | 357 | 136 | 363 | 131 |
| 95°F | 399 | 139 | 408 | 136 |
| 105°F | 450 | 142 | 457 | 140 |
| 115°F | 502 | 145 | 509 | 142 |

TABLE 18
LGH/LCH150H Fin/Tube Hot Gas Reheat - TXV

| Outdoor Coil Entering Air Temp | CIRCUIT 1 | | CIRCUIT 2 | |
|--------------------------------|---------------------|-----------------|---------------------|-----------------|
| | Dis-charge ±10 psig | Suction ±5 psig | Dis-charge ±10 psig | Suction ±5 psig |
| 65° F | 296 | 135 | 286 | 135 |
| 75° F | 334 | 137 | 318 | 136 |
| 85° F | 378 | 139 | 364 | 138 |
| 95° F | 422 | 142 | 409 | 140 |
| 105° F | 470 | 144 | 458 | 142 |
| 115° F | 520 | 147 | 509 | 146 |

Charge Verification - Approach Method - AHRI Testing (Fin/Tube Coil Continued)

1- Using the same thermometer, compare liquid temperature to outdoor ambient temperature.

Approach Temperature = Liquid temperature (at condenser outlet) minus ambient temperature.

2- Approach temperature should match values in table 19. An approach temperature greater than value shown indicates an undercharge. An approach temperature less than value shown indicates an overcharge.

3- The approach method is not valid for grossly over or undercharged systems. Use tables 9 through 18 as a guide for typical operating pressures.

TABLE 19
APPROACH TEMPERATURE - FIN/TUBE COIL - TXV

| Unit | Liquid Temp. Minus Ambient Temp. | |
|-------------------------------|----------------------------------|------------------------|
| | 1st Stage | 2nd Stage |
| 092 | 6°F ± 1 (3.3°C ± 0.5) | 7°F ± 1 (3.9°C ± 0.5) |
| 102 | 6°F ± 1 (3.3°C ± 0.5) | 9°F ± 1 (5.0°C ± 0.5) |
| 120 & 150S | 6°F ± 1 (3.3°C ± 0.5) | 10°F ± 1 (5.6°C ± 0.5) |
| 150H | 4°F ± 1 (2.2°C ± 0.5) | 6°F ± 1 (3.3°C ± 0.5) |
| 092, 120 & 150 Hot Gas Reheat | 6°F ± 1 (3.3°C ± 0.5) | 8°F ± 1 (4.4°C ± 0.5) |
| 102 Hot Gas Reheat | 6°F ± 1 (3.3°C ± 0.5) | 9°F ± 1 (5.0°C ± 0.5) |

F-Refrigerant Charge and Check - Fin/Tube Coil & RFC LGH/LCH150S

WARNING-Do not exceed nameplate charge under any condition.

This unit is factory charged and should require no further adjustment. If the system requires additional refrigerant, re-claim the charge, evacuate the system, and add required nameplate charge.

NOTE - System charging is not recommended below 60° F (15° C). In temperatures below 60° F (15° C), the charge must be weighed into the system.

If weighing facilities are not available, or to check the charge, use the following procedure:

IMPORTANT - Charge unit in standard cooling mode.

- 1- Make sure outdoor coil is clean. Attach gauge manifolds and operate unit at full CFM in cooling mode with economizer disabled until system stabilizes (approximately five minutes). Make sure all outdoor air dampers are closed.
- 2- Check each system separately with all stages operating. Compare the normal operating pressures (see table 20) to the pressures obtained from the gauges. Check unit components if there are significant differences.
- 3- Measure the outdoor ambient temperature and the suction pressure. Refer to the appropriate circuit charging curve to determine a target liquid temperature.

Note - Pressures are listed for sea level applications.

- 4- Use the same thermometer to accurately measure the liquid temperature (in the outdoor section).
 - If measured liquid temperature is higher than the target liquid temperature, add refrigerant to the system.
 - If measured liquid temperature is lower than the target liquid temperature, recover some refrigerant from the system.
- 5- Add or remove charge in increments. Allow the system to stabilize each time refrigerant is added or removed.
- 6- Continue the process until measured liquid temperature agrees with the target liquid temperature. Do not go below the target liquid temperature when adjusting


charge. Note that suction pressure can change as charge is adjusted.

target liquid temperature is 96°F. For a measured liquid temperature of 106°F, add charge in increments until measured liquid temperature agrees with the target liquid temperature.

7- Example LGH/LCH150 Circuit 1: At 95°F outdoor ambient and a measured suction pressure of 130psig, the

TABLE 20

| LGH/LCH150S Normal Operating Pressures - Fin/Tube - RFC | | | | | | | | | | | | |
|---|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| Outdoor Coil Entering Air Temperature | | | | | | | | | | | | |
| | 65 °F | | 75 °F | | 85 °F | | 95 °F | | 105 °F | | 115 °F | |
| | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) |
| Circuit 1 | 108 | 253 | 112 | 295 | 114 | 338 | 117 | 384 | 119 | 438 | 122 | 501 |
| | 114 | 255 | 119 | 296 | 122 | 342 | 125 | 390 | 127 | 444 | 129 | 501 |
| | 119 | 257 | 129 | 303 | 136 | 348 | 141 | 403 | 145 | 460 | 149 | 522 |
| | 125 | 264 | 136 | 308 | 146 | 358 | 155 | 413 | 161 | 470 | 167 | 530 |
| Circuit 2 | 108 | 273 | 111 | 314 | 114 | 356 | 117 | 400 | 119 | 451 | 121 | 508 |
| | 115 | 277 | 119 | 318 | 122 | 362 | 125 | 409 | 128 | 460 | 129 | 512 |
| | 124 | 284 | 131 | 327 | 137 | 372 | 141 | 422 | 145 | 474 | 147 | 532 |
| | 131 | 289 | 140 | 334 | 148 | 382 | 155 | 434 | 160 | 486 | 163 | 541 |



G-Refrigerant Charge and Check - Fin/Tube Coil & TXV

LGH/LCH094U, 122U, 152U

WARNING-Do not exceed nameplate charge under any condition.

This unit is factory charged and should require no further adjustment. If the system requires additional refrigerant, re-claim the charge, evacuate the system, and add required nameplate charge. This unit is equipped with solenoid valves which do not allow refrigerant flow between the high side and the low side when the unit is de-energized. When reclaiming/evacuating the system, make sure refrigerant/vacuum is pulled from both the suction and discharge lines. When adding nameplate charge, add 1/3 to the suction line and 2/3 to the discharge line.

NOTE - System charging is not recommended below 60°F (15°C). In temperatures below 60°F (15°C), the charge must be weighed into the system.

If weighing facilities are not available, or to check the charge, use the following procedure:

IMPORTANT - Charge unit in standard cooling mode.

- 1- Attach gauge manifolds and operate unit in cooling mode with economizer disabled until system stabilizes (approximately five minutes). Make sure outdoor air dampers are closed.
- 2- Make sure both compressors are operating.
- 3- Use a thermometer to accurately measure the outdoor ambient temperature.
- 4- Apply the outdoor temperature to tables 21 through 23 to determine normal operating pressures. Pressures are listed for sea level applications at 80°F dry bulb and 67°F wet bulb return air.
- 5- Compare the normal operating pressures to the pressures obtained from the gauges. Minor variations in these pressures may be expected due to differences in installations. Significant differences could mean that the system is not properly charged or that a problem exists with some component in the system. **Correct any system problems before proceeding.**
- 6- If discharge pressure is high, remove refrigerant from the system. If discharge pressure is low, add refrigerant to the system.
 - Add or remove charge in increments.
 - Allow the system to stabilize each time refrigerant is added or removed.
- 7- Use the following approach method along with the normal operating pressures to confirm readings.

**TABLE 21
LGH/LCH094U**

| Outdoor Coil Entering Air Temp | Discharge ±10 psig | Suction ±5 psig |
|--------------------------------|--------------------|-----------------|
| 65° F | 238 | 136 |
| 75° F | 273 | 141 |
| 85° F | 313 | 143 |
| 95° F | 361 | 146 |
| 105° F | 396 | 149 |
| 115° F | 448 | 152 |

**TABLE 22
LGH/LCH122U**

| Outdoor Coil Entering Air Temp | Discharge ±10 psig | Suction ±5 psig |
|--------------------------------|--------------------|-----------------|
| 65° F | 250 | 134 |
| 75° F | 288 | 138 |
| 85° F | 331 | 141 |
| 95° F | 378 | 143 |
| 105° F | 412 | 144 |
| 115° F | 463 | 147 |

**TABLE 23
LGH/LCH152U**

| Outdoor Coil Entering Air Temp | Discharge ±10 psig | Suction ±5 psig |
|--------------------------------|--------------------|-----------------|
| 65° F | 266 | 129 |
| 75° F | 305 | 132 |
| 85° F | 346 | 134 |
| 95° F | 391 | 138 |
| 105° F | 443 | 141 |
| 115° F | 498 | 143 |

Charge Verification - Approach Method - AHRI Testing (Fin/Tube Coil Continued)

- 1- Using the same thermometer, compare liquid temperature to outdoor ambient temperature.

Approach Temperature = Liquid temperature (at condenser outlet) minus ambient temperature.
- 2- Approach temperature should match values in table 24. An approach temperature greater than value shown indicates an undercharge. An approach temperature less than value shown indicates an overcharge.
- 3- The approach method is not valid for grossly over or undercharged systems. Use tables 21 through 23 as a guide for typical operating pressures.

**TABLE 24
APPROACH TEMPERATURE - 094, 122, 152**

| Unit | Liquid Temp. Minus Ambient Temp. |
|----------|----------------------------------|
| | Full Load (Both Compressors) |
| 094 | 5°F ± 1 (2.8°C ± 0.5) |
| 122, 152 | 4°F ± 1 (2.2°C ± 0.5) |

IV-START-UP - OPERATION

Refer to start-up directions and to the unit wiring diagram when servicing. See unit nameplate for minimum circuit ampacity and maximum fuse size.

A-Preliminary and Seasonal Checks

- 1- Make sure the unit is installed in accordance with the installation instructions and applicable codes.
- 2- Inspect all electrical wiring, both field and factory installed for loose connections. Tighten as required. Refer to unit diagram located on inside of unit control box cover.
- 3- Check to ensure that refrigerant lines are in good condition and do not rub against the cabinet or other refrigerant lines.
- 4- Check voltage. Voltage must be within the range listed on the nameplate. If not, consult power company and have the voltage corrected before starting the unit.
- 5- Recheck voltage and amp draw with unit running. If voltage is not within range listed on unit nameplate, stop unit and consult power company. Refer to unit nameplate for maximum rated load amps.
- 6- Inspect and adjust blower belt (see section on Blower Compartment - Blower Belt Adjustment).

B-Cooling Start-up See figure 34, 35 or 36 for Circuits

NOTE-Crankcase heaters must be energized 24 hours before attempting to start compressor. Set thermostat so that there is no demand to prevent compressor from cycling. Apply power to unit.




FIGURE 34




FIGURE 35




FIGURE 36

VFD Units - Refer to the Supply Air Inverter Start-Up section.

- 1- Initiate first and second stage cooling demands according to instructions provided with thermostat.
- 2- First-stage thermostat demand will energize compressor 1. Second-stage thermostat demand will energize compressor 2.
- 3- Standard and high efficiency units contain two refrigerant circuits or stages. Ultra high efficiency units have one common (tandem) refrigerant circuit.
- 4- Each refrigerant circuit is separately charged with refrigerant. See unit rating plate for correct amount of charge.

C-Heating Start-up

FOR YOUR SAFETY READ BEFORE LIGHTING

⚠️ WARNING



Danger of explosion. Can cause injury or product or property damage. If overheating occurs or if gas supply fails to shut off, shut off the manual gas valve to the appliance before shutting off electrical supply.

⚠️ WARNING



Electric shock hazard. Can cause injury or death. Before attempting to perform any service or maintenance, turn the electrical power to unit OFF at disconnect switch(es). Unit may have multiple power supplies.

BEFORE LIGHTING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, do not try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.



⚠️ IMPORTANT

Units equipped with a Hot Gas Reheat system MUST be charged in standard cooling mode.


In case of a safety shutdown, move thermostat switch to **OFF** and return the thermostat switch to **HEAT** to reset ignition control.

Placing Furnace In Operation

Gas Valve Operation for White Rodgers 36C and Honeywell VR8205Q/VR8305Q (figure 37)

- 1- Set thermostat to lowest setting.
- 2- Turn off all electrical power to appliance.
- 3- This appliance is equipped with an ignition device which automatically lights the burner. Do **not** try to light the burner by hand.
- 4- Open or remove the heat section access panel.
- 5- Turn the knob on the gas valve clockwise  to "**OFF**". Depress 36C knob slightly. Do not force.
- 6- Wait five (5) minutes to clear out any gas. If you then smell gas, **STOP!** Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions. If you do not smell gas, go to the next step.
- 7- Turn the knob on the gas valve counterclockwise  to "**ON**". Do not force.
- 8- Close or replace the heat section access panel.
- 9- Turn on all electrical power to appliance.
- 10- Set thermostat to desired setting.
- 11- The combustion air inducer will start. The burners will light within 40 seconds.
- 12- If the appliance does not light the first time (gas line not fully purged), it will attempt up to two more ignitions before locking out.
- 13- If lockout occurs, repeat steps 1 through 10.
- 14- If the appliance will not operate, follow the instructions "Turning Off Gas to Appliance" and call your service technician or gas supplier.

Turning Off Gas to Appliance

- 1- If using an electromechanical thermostat, set to the lowest setting.
- 2- Before performing any service, turn off all electrical power to the appliance.
- 3- Open or remove the heat section access panel.
- 4- Turn the knob on the gas valve clockwise  to "**OFF**". Depress 36C knob slightly. Do not force.

D-Safety or Emergency Shutdown

Turn off power to the unit. Close manual and main gas valves.




FIGURE 37

V- SYSTEMS SERVICE CHECKS

A-Heating System Service Checks

All LGH units are ETL/CSA design certified without modification.

Before checking piping, check with gas company or authorities having jurisdiction for local code requirements. Refer to the LGH installation instruction for more information.

1-Gas Piping

Gas supply piping must not allow more than 0.5"W.C. (124.3 Pa) drop in pressure between the gas meter and the unit. Supply gas pipe must not be smaller than the unit gas connection. Refer to installation instructions for details.

2-Testing Gas Piping

NOTE-In case emergency shutdown is required, turn off the main manual shut-off valve and disconnect the main power to the unit. These controls should be properly labeled by the installer.

When pressure testing gas lines, the gas valve must be disconnected and isolated. **Gas valves can be damaged if subjected to more than 0.5 psig [14"W.C. (3481 Pa)].** See figure 38.




FIGURE 38

When checking piping connection for gas leaks, use the preferred means. Common kitchen detergents can cause harmful corrosion on various metals used in gas piping. The use of specialty Gas Leak Detector is strongly recommended.

Do not use matches, candles, flame or any other source of ignition to check for gas leaks.

3-Testing Gas Supply Pressure

When testing gas supply pressure, connect test gauge to the inlet pressure tap located on unit gas valve GV1 and or GV3. Test supply gas pressure with unit firing at maximum rate (both stages energized). Make sure the reading falls within the range of the following values. Low pressure may result in erratic operation or "underfire." High pressure can

result in permanent damage to the gas valve or "overfire." For natural gas units, operating pressure at the unit gas connection must be between 4.7"W.C. and 10.5"W.C. (1168 Pa and 2610 Pa). For L.P. gas units, operating pressure at the unit gas connection must be between 10.8"W.C. and 13.5"W.C. (2685.3 Pa and 3356.7 Pa).

On multiple unit installations, each unit should be checked separately while operating at maximum rate, beginning with the one closest to the supply gas main and progressing to the one furthest from the main. Multiple units should also be tested with and without the other units operating. Supply pressure must fall within the range listed in the previous paragraph.

4-Check and Adjust Manifold Pressure

After line pressure has been checked and adjusted, check manifold pressure. Move test gauge to the outlet pressure tap located on unit gas valve GV1 and or GV3. See figure 37 for location of pressure tap on the gas valve.

The manifold pressure is factory set and should not require adjustment. If manifold pressure is incorrect and no other source of improper manifold pressure can be found, the valve must be replaced. See figure 37 for location of gas valve (manifold pressure) adjustment screw.

All gas valves are factory regulated. The gas valve should completely and immediately cycle off in the event of gas or power failure. The manual shut-off knob can be used to immediately shut off gas supply.

CAUTION

For safety, connect a shut-off valve between the manometer and the gas tap to permit shut off of gas pressure to the manometer.

Manifold Adjustment Procedure

- 1- Connect test gauge to the outlet pressure tap on the gas valve. Start the unit (call for second stage heat) and allow five minutes for the unit to reach steady state.
- 2- While waiting for the unit to stabilize, notice the flame. The flame should be stable without flashback and should not lift from the burner heads. Natural gas should burn basically blue with some clear streaks. L.P. gas should burn mostly blue with some clear yellow streaks.
- 3- After allowing the unit to stabilize for five minutes, record the manifold pressure and compare to the values given in table 4.

CAUTION

Disconnect heating demand as soon as an accurate reading has been obtained.

5-Proper Gas Flow

To check for proper gas flow to burners, determine Btuh input from unit rating plate or the gas heating capacity in the SPECIFICATIONS tables. Divide this input rating by the Btuh per cubic foot of available gas. Result is the number of cubic feet per hour required. Determine the flow of gas through gas meter for two minutes and multiply by 30 to get hourly flow of gas to the burners.

NOTE - To obtain accurate reading, shut off all other gas appliances connected to meter.

6-Inshot Burner

Burners are factory set for maximum air and cannot be adjusted. Always operate unit with access panel in place. A peep hole is furnished in the heating access panel for flame viewing. Natural gas should burn basically blue with some clear streaks. L.P. gas should burn mostly blue with some clear yellow streaks.

Figure 39 shows how to remove burner assembly.

- 1- Turn off power to unit and shut off gas supply.
- 2- Remove screws holding the burner support cap.
- 3- Slide each burner off its orifice.
- 4- Clean and reassemble (reverse steps 1-3).
- 5- Be sure to secure all wires and check plumbing.
- 6- Turn on power to unit. Follow lighting instructions attached to unit and operate unit in heating mode. Check burner flames. They should be blue with yellow streaks.




FIGURE 39

7-Spark Electrode Gap

The spark electrode assembly can be removed for inspection by removing two screws securing the electrode assembly and sliding it out of unit.

For proper unit operation, electrodes must be positioned and the spark gap set correctly.

Spark gap may be checked with appropriately sized twist drills or feeler gauges. Disconnect power to the unit and remove electrode assembly. The gap should be between 0.125" \pm 0.015" (3.2 mm \pm .4 mm). See figure 32.

8-Heat Exchanger

To Access or Remove Heat Exchanger From Unit:

- 1- Turn off gas and electric power.
- 2- Remove access panel(s) and unit center mullion.
- 3- Remove gas valve, manifold assembly and burners.
- 4- Remove combustion air inducer and flue box. Pay careful attention to the order in which gaskets and orifice are removed.
- 5- Support heat exchanger (to prevent it from falling when final screws are removed.)
- 6- Remove screws supporting heat exchanger.
- 7- To install heat exchanger, reverse procedure. Be sure to secure all wires and check plumbing and burner plate for airtight seal. Screws must be torqued to 35 in.-lbs. to ensure proper operation.

9-Flame Sensing

Flame current is an electrical current which passes from the ignition control through the sensor electrode during unit operation. The current passes from the sensor through the flame to the ground electrode (located on the flame electrode) to complete a safety circuit. The electrodes should be located so the tips are at least 1/2" (12.7 mm) inside the flame envelope. Do not bend electrodes. To measure flame current, follow the procedure on the following page:

NOTE-Electrodes are not field adjustable. Any alterations to the electrode may create a hazardous condition that can cause property or personal injury.

- 1- Disconnect power to unit.
- 2- Remove lead from sensing electrode and install a 0-50DC microamp meter in series between the sensing electrode and the sensing lead.
- 3- Reconnect power and adjust thermostat for heating demand.
- 4- When flame is established, compare reading to table 25. Do not bend electrodes.
- 5- Disconnect power to unit before disconnecting meter. Make sure sensor wire is securely reconnected before reconnecting power to unit.

TABLE 25

| Manufacturer | Nominal Signal Microamps | Drop Out |
|--------------|--------------------------|----------|
| JOHNSON | 0.5 - 1.0 | .09 |

NOTE-If the meter scale reads 0, the leads are reversed. Disconnect power and reconnect leads for proper polarity.

10-Combustion Air Inducer

The combustion air inducer is factory set and is not field adjustable. However, operation should be monitored to ensure proper operation. The combustion air inducer is used to draw fresh air into the combustion chamber while simultaneously expelling exhaust gases. The inducer operates throughout the heating cycle.

On a heating demand, the ignition control is energized by the A55 Unit Controller. The ignition control then allows 30 to 40 seconds for the combustion air inducer to vent exhaust gases from the burners. When the combustion air inducer is purging the exhaust gases, the combustion air prove switch is closing proving that the combustion air inducer is operating before allowing the ignition control to energize. When the combustion air prove switch is closed and the delay is over, the ignition control activates the first stage operator of the gas valve (low fire), the spark and the flame sensing electrode. Sparking stops immediately after flame is sensed.

11-High Altitude

Units may be installed at altitudes up to 2000 feet (610 m) above sea level without any modification. At altitudes above 2000 feet (610 m), units must be derated to match gas manifold pressures shown in table below.

NOTE — This is the only permissible derate for these units.

| Altitude - ft. (m) | Natural Gas | | LPG/Propane | |
|---------------------------|-------------|------|-------------|------|
| | in. w.g. | kPa | in. w.g. | kPa |
| 2001 - 3000 (610 - 915) | 3.6 | 0.90 | 10.2 | 2.54 |
| 3001 - 4000 (915 - 1220) | 3.5 | 0.87 | 9.9 | 2.46 |
| 4001 - 5000 (1220 - 1525) | 3.4 | 0.85 | 9.6 | 2.39 |
| 5001 - 6000 (1525 - 1830) | 3.3 | 0.82 | 9.4 | 2.34 |
| 6001 - 7000 (1830 - 2135) | 3.2 | 0.80 | 9.1 | 2.26 |

B-Cooling System Service Checks

LGH units are factory charged and require no further adjustment; however, charge should be checked periodically. See section III- CHARGING.

VI-MAINTENANCE

A-Filters

LGH units use four 20 x 25 x 2" pleated throw-away type filters. Filters may be accessed through the economizer / filter access door. Filters should be checked monthly (or more frequently in severe use) and cleaned or replaced regularly. Take note of the "AIR FLOW DIRECTION" marking on the filter frame when re-installing.

NOTE-Filters must be U.L.C. certified or equivalent for use in Canada.

B-Lubrication

All motors and blower wheels used in LGH units are pre-lubricated; no further lubrication is required.

C-Supply Air Blower Wheel

Annually inspect supply air blower wheel for accumulated dirt or dust. Turn off power before attempting to remove access panel or to clean blower wheel.

! WARNING



Electric shock hazard. Can cause injury or death. Before attempting to perform any service or maintenance, turn the electrical power to unit OFF at disconnect switch(es). Unit may have multiple power supplies.

D-Evaporator Coil

Inspect and clean coil at beginning of each season. Clean using mild detergent or commercial coil cleanser. Check condensate drain pan and line, if necessary. Flush coil and condensate drain with water taking care not to get insulation, filters and return air ducts wet. Check connecting lines and coil for evidence of oil and refrigerant leaks.

E-Condenser Coil

Formed Coils -

Clean condenser coil annually with water and inspect monthly during the cooling season.

Clean the all-aluminum coil by spraying the coil steadily and uniformly from top to bottom. Do not exceed 900 psi or a 45° angle; nozzle must be at least 12 inches from the coil face. Take care not to fracture the braze between the fins and refrigerant tubes. Reduce pressure and work cautiously to prevent damage.

Slab Coils -

Clean condenser coil annually with detergent or commercial coil cleaner and inspect monthly during the cooling season. Check connecting lines and coil for evidence of oil and refrigerant leaks.

NOTE-If owner complains of insufficient cooling, the unit should be gauged and refrigerant charge checked. Refer to Gauge Manifold Attachment and Charging sections in this manual.

F-Electrical

- 1- Check all wiring for loose connections.
- 2- Check for correct voltage at unit (unit operating).
- 3- Check amp-draw on both condenser fan motor and blower motor.
Fan Motor Rating Plate ____ Actual _____
Indoor Blower Motor Rating Plate ____ Actual _____
- 4- Check crankcase heater temperatures to ensure they are operating.
- 5- Check compressor sump thermistors to ensure they are making contact with compressor shell (ultra high efficiency units only).

VII-ACCESSORIES

The accessories section describes the application of most of the optional accessories which can be factory or field installed to the LGH units.

A-Mounting Frames

When installing units on a combustible surface for downflow discharge applications, a C1CURB roof mounting frame is used. The roof mounting frames are recommended in all other applications but not required. If the LGH units are not mounted on a flat (roof) surface, they MUST be supported under all edges and under the middle of the unit to prevent sagging. The units MUST be mounted level within 1/16" per linear foot or 5mm per meter in any direction.

The assembled C1CURB mounting frame is shown in figure 40. Refer to the roof mounting frame installation instructions for details of proper assembly and mounting. The roof mounting frame MUST be squared to the roof and level before mounting. Plenum system MUST be installed before the unit is set on the mounting frame. Typical roof curbing and flashing is shown in figure 41. Refer to the roof mounting frame installation instructions for proper plenum construction and attachment.




FIGURE 40

B-LP / Propane Kit

Natural to LP /propane kit includes a spring kit and three stickers. In addition, the LP kit contains either six, nine, or eleven burner orifices. For more detail refer to the natural to LP gas changeover kit installation instructions.

C-Dirty Filter Switch S27

The dirty filter switch senses static pressure increase indicating a dirty filter condition. The switch is N.O. and closes at 1" W.C. (248.6 Pa) The switch is mounted on the top filter channel corner. Wiring for the dirty filter switch is shown on the temperature control section (C2) wiring diagram in back of this manual.




FIGURE 41

D-Transitions

Optional supply/return transitions LASRT08/10 is available for use with the LGH 7.5 ton units and LASRT10/12 is available for the 8.5 and 10 ton units, utilizing optional C1CURB roof mounting frames. LGH 12.5 ton units will use LASRT15 with C1CURB roof mounting frame. Transition must be installed in the C1CURB mounting frame before mounting the unit to the frame. Refer to the manufacturer's instructions included with the transition for detailed installation procedures.

E-LAOD(M) Outdoor Air Dampers (all units)

LAOD(M) consists of a set of dampers which may be manually or motor (M) operated to allow up to 25 percent outside air into the system at all times (see figure 42 or 43). Either air damper can be installed in LGH units. Washable filter supplied with the outdoor air dampers can be cleaned with water and a mild detergent. It should be sprayed with Filter Handicoater when dry prior to re-installation.

F-Supply and Return Diffusers (all units)

Optional flush mount diffuser/return FD11 and extended mount diffuser/return RTD11 are available for use with all LGH units. Refer to manufacturer's instructions included with transition for detailed installation procedures.

G-Blower Proving Switch S52

The blower proving switch monitors blower operation and locks out the unit in case of blower failure. The switch is N.O. and closes at .14" W.C. (34.9 Pa) The switch is mounted on the upper left hand corner of the blower deck. Wiring for the blower proving switch is shown on the temperature control section (C2) wiring diagram in back of this manual.

LAOAD(M) MOTORIZED OUTDOOR AIR DAMPER




FIGURE 42

MANUAL OUTDOOR AIR DAMPER




FIGURE 43




FIGURE 44

**H-Economizer (all units)
(Field or Factory Installed)**

The optional E1ECON15 economizer can be used with downflow and horizontal air discharge applications. See figure 44. The economizer uses outdoor air for free cooling when outdoor temperature and/or humidity is suitable. The economizer is controlled by the A55 Unit Controller.

Free Cooling Mode

The Unit Controller will allow free cooling in one of five modes. Each mode uses different combinations of sensors to determine outdoor air suitability. See table 26 for modes. See figure 45 for factory-installed sensors. Temperature offset is the default free cooling mode.

NOTE - All free cooling modes of operation will modulate dampers to 55°F (13°C) supply / discharge air.

Unit Controller Settings

On early versions, switches are located on the Unit Controller to adjust settings. On newer versions, the display and keypad on the Unit Controller are used to navigate through menus to adjust settings. Some versions require a configuration ID be entered to enable the economizer. Refer to economizer installation instructions and Unit Controller installation and application manuals.

**TABLE 26
ECONOMIZER MODES AND SETPOINT**

| Free Cooling Mode | Free Cooling Setpoint | Field-Provided Sensors | Dampers will modulate to 55°F (default, parameter 159) discharge air (RT6) when outdoor air is suitable: | Input Ranges |
|-------------------|-----------------------|----------------------------|--|--------------|
| TEMP | OFFSET | None Needed | Outdoor air temperature (RT17) is less than return air temperature (RT16) by at least the OFFSET value (10°F default; parameter 161). | 0-40°F |
| TEMP | OAT STPT | None Needed | Outdoor air temperature (RT17) is less than the OAT STPT value (75°F default; parameter 160). | 41-75°F |
| Remote | Remote | Energy Management System** | Either of the TEMP modes can be used when a network OAS signal is provided by an energy management or building control system, via BACnet, LonTalk, or L Connection. The network can command OAS, NOT OAS, or AUTO. AUTO returns to local control of OAS, which is the selected TEMP mode. | NA |
| ENTH | DIFF OFFSET | (Two) C7400 | Outdoor air enthalpy* (A7) is less than return air enthalpy (A62) by at least the OFFSET value (1mA = 2°F default; parameter 163). | 0mA-4mA |
| ENTH | ODE STPT | C7400 | Outdoor air enthalpy (A7) is less than free cooling setpoint (12mA = 75°F default, parameter 162). | 12-19mA |
| GLOBAL | GLOBAL | 24VAC Input Signal | Global input is energized by (P297-9). This setting is also used for outdoor air damper applications. Global input also brings on the blower. (This mode is NOT used when OAS signal is provided via network connection. GLO is only used when a 24VAC signal is used to energize the P297-9 GLO input.) | NA |

*Enthalpy includes effects of both temperature and humidity.

**Energy management systems may require additional field-provided sensors; refer to manufacturer's instructions.




FIGURE 45

I-Gravity Exhaust Dampers

LAGEDH03/15 dampers (figure 46) are used in downflow and horizontal air discharge applications. Horizontal gravity exhaust dampers are installed in the return air plenum. The dampers must be used any time an economizer or power exhaust fans are applied to LGH units.

Gravity exhaust dampers allow exhaust air to be discharged from the system when an economizer and/or power exhaust is operating. Gravity exhaust dampers also prevent outdoor air infiltration during unit off cycle. See installation instructions for more detail.




FIGURE 46

J-LAPEF Power Exhaust Fans

Power exhaust fans are used in downflow applications only. Fan requires optional down flow gravity exhaust dampers and LAREMD economizer. Power exhaust fans provide exhaust air pressure relief and also run when return air dampers are closed and supply air blowers are operating. Figure 47 shows the location of the LAPEF. See installation instructions for more detail.




FIGURE 47

K-Optional Cold Weather Kit (Canada only)

Electric heater is available to automatically control the minimum temperature in the gas burner compartment. Heater is C.G.A. certified to allow cold weather operation of unit down to -60° F (-50° C).

The kit includes the following parts:

- 1- A heater assembly is installed on the vestibule of the heating compartment. Included in the box are the following:
 - a - Electric strip heat (HR6).
 - b - Thermostat switch (S59) is an auto-reset SPST N.C. switch which opens on a temperature drop. The switch is wired in series with 24v power and the combustion air blower switch. When the temperature drops below -30° F (-35° C) the switch opens and the gas heat section is de-energized. The switch automatically resets when the heating compartment temperature reaches -10° F (-12° C).
 - c - Thermostat switch (S60) is an auto-reset SPST N.C. switch which opens on a temperature rise. The switch is wired in series with HR6. When the temperature rises above 20° F (-7° C) the switch opens and the electric heater is de-energized. The switch automatically resets when the heating compartment temperature reaches -10° F (23.3° C).
 - d -Thermostat switch (S61) is an auto-reset SPST N.O. switch which closes on a temperature drop. The switch is wired in series with HR6. When temperature drops below 20° F (-7° C) the switch closes and electric heater is energized. The switch automatically opens when heating compartment temperature reaches 76° F (24° C).
- 2- K125 heat shutoff relay de-energizes HR6 heaters when S60 or S61 thermostat switches open. K125 must be installed in the control section.
- 3- Wire harness is routed between the heat section components and the unit control box. Follow instructions provided with kit for wire connections.

L-Control Systems

The A55 Unit Controller provides all control function for the rooftop unit. Default operation requires a standard room thermostat or direct digital controller (DDC). The A55 can also control the unit from a zone temperature sensor. The A55 Unit Controller is a network controller when daisy-chained to the L Connection® Network Control System. For ease of configuration, the A55 can be connected to a PC with Unit Controller PC software installed.

M-Indoor Air Quality (CO₂) Sensor A63

The indoor air quality sensor monitors CO₂ levels and reports the levels to the A55 Unit Controller. The board adjusts the economizer dampers according to the CO₂ levels. The sensor is mounted next to the indoor thermostat or in the return air duct. Refer to the indoor air quality sensor installation instructions for proper adjustment. Wiring for the indoor air quality switch is shown on the temperature control section (C2) wiring diagram in back of this manual.

N-Drain Pan Overflow Switch S149 (optional)

The overflow switch is used to interrupt cooling operation when excessive condensate collects in the drain pan.

The N.C. overflow switch is connected to the M2 Unit Controller (A55) through DI-3. When the switch opens, the Unit Controller will shut off the unit. After a five-minute time out, the Unit Controller will verify the overflow switch position and restart the unit (if the switch has closed). The Unit Controller has a three-strike counter before the unit locks out. This means the Unit Controller will allow the overflow switch to open three times per thermostat demand. If the unit locks out, a reset of the Unit Controller is required after the switch has closed to restore unit operation.

O-Smoke Detectors A17 and A64

Photoelectric smoke detectors are a factory installed option. The smoke detectors can be installed in the supply air section (A64), return air section (A17), or in both the supply and return air section. Wiring for the smoke detectors are shown on the temperature control section (C2) wiring diagram in back of this manual.

P-Factory Installed-Hot Gas Reheat (optional)

General

Hot Gas Reheat units provide a dehumidifying mode of operation. These units contain a reheat coil adjacent to and downstream of the evaporator coil. Reheat coil solenoid

valve, L14, routes hot discharge gas from the compressor to the reheat coil. Return air pulled across the evaporator coil is cooled and dehumidified; the reheat coil adds heat to supply air. See figure 48 for reheat refrigerant routing and figure 49 for standard cooling refrigerant routing.




FIGURE 48




FIGURE 49

L14 Reheat Coil Solenoid Valve

When Unit Controller input (Unit Controller J298-5 or J299-8) indicates room conditions require dehumidification, L14 reheat valve is energized (Unit Controller P269-3) and refrigerant is routed to the reheat coil.

Reheat Setpoint

Reheat is factory-set to energize when indoor relative humidity rises above 60% (default). The reheat setpoint can be adjusted by changing Unit Controller *Settings - Control* menu. A setting of 100% will operate reheat from an energy management system digital output. The reheat setpoint can also be adjusted using an optional Network Control Panel (NCP).

Reheat will terminate when the indoor relative humidity falls 3% (57% default) or the digital output de-energizes. The reheat deadband can be adjusted at *Settings - Control* menu.

Check-Out

Test Hot Gas Reheat operation using the following procedure.

- 1- Make sure reheat is wired as shown in wiring section.
- 2- Make sure unit is in local thermostat mode.
- 3- Select Unit Controller *Service - Test*.

The blower and compressor 1 (reheat) should be operating. Reheat mode will be appear on the Unit Controller display.

- 4- Deselect Unit Controller *Service - Test*.

Compressor 1 (reheat) and blower should de-energize.

Default Reheat Operation

TABLE 27

Reheat Operation - Two Cooling Stages - Default

| T'stat and Humidity Demands | Operation |
|-----------------------------|---|
| Reheat Only | Compressor 1 Reheat |
| Reheat & Y1 | Compressor 1 Reheat & Compressor 2 Cooling* |
| Reheat & Y1 & Y2 | Compressor 1 Cooling & Compressor 2 Cooling** |

*If there is no reheat demand and outdoor air is suitable, free cooling will operate.

**If there is no reheat demand and outdoor air is suitable, free cooling and compressor 1 will operate.

VIII-Belt Drive Supply Air Inverter

NOTE - Units equipped a Variable Frequency Drive (VFD) are designed to operate on balanced, three-phase power. Operating units on unbalanced three-phase power will reduce the reliability of all electrical components in the unit. Unbalanced power is a result of the power delivery system supplied by the local utility company. Factory-installed inverters are sized to drive blower motors with an equivalent current rating using balanced three-phase power. If unbalanced three-phase power is supplied; the installer must replace the existing factory-installed inverter with an inverter that has a higher current rating to allow for the imbalance. Refer to the installation instructions for additional information and available replacements.

The supply air inverter or variable frequency drive (VFD), is located in the compressor compartment. The VFD stages the amount of supply airflow according to the number of compressors operating.

The amount of airflow for each stage is set in the Unit Controller when the unit is initially commissioned. Each value is recorded on a label on the inside of the compressor access panel. Settings can also be read on the Unit Controller display. Use one of the following menus.

M2 Unit Controllers:

Data > Status > Blower

M3 Unit Controllers:

DATA > ADVANCED STATUS > BLOWER > BLOWER STATUS

Use figure 50 to determine whether the VFD should be providing a staged output to the blower motor.

⚠ WARNING

ELECTRICAL SHOCK HAZARD.

Failure to follow instructions exactly could result in serious injury or death.

VFD HOLDS A POTENTIALLY LETHAL CHARGE UP TO 10 MINUTES AFTER POWER HAS BEEN DISCONNECTED. Do not open VFD cover until 10 minutes AFTER power source has been disconnected and power lamp has turned off.

Read manual provided by VFD manufacturer. Carefully review and follow all safety warnings in that manual also.




FIGURE 50

ADJUST CFM

If a test and balance contractor has not commissioned the unit, use this section to set supply air CFM.

A-Design Specifications

Use table 28 to fill in field-provided, design specified blower CFM.

B-Set Maximum CFM

Use table 28 to determine highest blower CFM for appropriate unit. Adjust the blower pulley to deliver that amount of CFM with only the blower operating. See section 1-UNIT COMPONENTS; C-Blower Compartment; *Determining Unit CFM*.

TABLE 28
Blower CFM Design Specifications

| Blower Speed | Design Specified CFM |
|--------------|----------------------|
| Heating | |
| Cooling High | |
| Cooling Low | |
| Ventilation | |

C-Enter Design Specifications Into Controller

Use the following menu to enter the blower design specified CFM into the Unit Controller. Make sure blower CFM is within limitations shown in table 29. Refer to the Unit Controller manual provided with unit.

M2 Unit Controller -

Settings > Control > Guided Setup > Advanced Guided Setup > Setup Equipment > Change MSAV™ Settings? > Yes

M3 Unit Controller -

SETUP > TEST & BALANCE > BLOWER >

D-Set Damper Minimum Position

To maintain required minimum ventilation air volumes when the unit is in the occupied mode, two minimum damper positions must be set. The Unit Controller will open the dampers to “Min OCP Blwr Low” when blower CFM is BELOW a “midpoint” CFM. The Unit Controller will open the damper to “Min OCP Blwr High” when blower CFM is at or ABOVE the “midpoint” CFM.

The Unit Controller will calculate the “midpoint” CFM.

Set Minimum Position 1

Use the following menu in the Unit Controller to set “Min OCP Blwr Low” for the blower CFM below the “midpoint” CFM. When navigating into this menu, the Unit Controller will bring on the corresponding blower speed and allow damper position adjustment.

M2 Unit Controller -

Settings > Control > MSAV > Damper > Low Speed

M3 Unit Controller -

SETTINGS > RTU Options > EDIT PARAMETER > ENTER DATA ID - 9 > MIN DAMPER LOW BLOWER = X.X %

Measure the intake air CFM. If the CFM is lower than the design specified CFM for ventilation air, use the Unit Controller to increase the damper percent open. If the CFM is higher than specified, decrease the damper percent open.

Note - Intake air CFM can also be determined using the outdoor air temperature, return air temperature and mixed air temperature. Refer to the economizer or outdoor air damper installation instructions.

Set Minimum Position 2

Use the same menu in the Unit Controller to set “Min OCP Blwr High” for the blower CFM above the “midpoint” CFM. When navigating into this menu, the Unit Controller will bring on the corresponding blower speed and allow damper position adjustment.

M2 Unit Controller -

Settings > Control > MSAV > Damper > High Speed

M3 Unit Controller -

SETTINGS > RTU OPTIONS > DAMPER > MIN DAMPER POSITION BLOWER ON HIGH = X.X %

Measure the intake air CFM. If the CFM is lower than the design specified CFM for ventilation air, use the Unit Controller to increase the damper percent open. If the CFM is higher than specified, decrease the damper percent open.

Note - Intake air CFM can also be determined using the outdoor air temperature, return air temperature and mixed air temperature. Refer to the economizer or outdoor air damper installation instructions.

E-VFD Bypass Option

The supply air VFD is factory-set to by-pass the VFD manually. To by-pass the VFD and operate the blower in the constant air volume mode, use the following Unit Controller menu and set to “engaged”:

M2 Unit Controller -

Settings > Control > MSAV > VFD Bypass >

M3 Unit Controller -

SETTINGS>RTU OPTIONS>BLOWER>VFD BYPASS

To configure the unit to by-pass the VFD automatically, use the following Unit Controller menu and set to “automatic”:

M2 Unit Controller -

Settings > Install > New M2 > MSAV VFD Bypass >

M3 Unit Controller -

SETUP > INSTALL > PRESS SAVE UNTIL THE MENU READS CONFIGURATION ID 1 > CHANGE CHARACTER POSITION 6TH TO “A” FOR AUTOMATIC BYPASS OPTION AND SAVE

Caution - Units not equipped with a VFD will be set to Settings > Control > MSAV VFD Bypass > None. The blower motor could be damaged and/or result in product or property damage if the setting is changed to automatic or manual.

**TABLE 29
MINIMUM AND MAXIMUM CFM
092H, 102H, 120H, 150H**

| Gas Heat Minimum CFM | | |
|--|-----------------------|-------------|
| Unit | Gas Heat Size | Airflow CFM |
| LGH092-150 | Std. , Med. | 2225 |
| LGH092-150 | High | 2550 |
| Electric Heat Minimum CFM | | |
| Unit | Heat Size (kW) | Airflow CFM |
| LCH092-102 | 0 | 2800 |
| LCH092-150 | 7.5, 15, 22.5, 30, 45 | 2800 |
| LCH120-150 | 0, 60 | 4000 |
| Cooling Minimum CFM - 220* CFM/ton | | |
| Unit | Blower Speed | Airflow CFM |
| LGH/LCH092 | Low | 1650 |
| LGH/LCH102 | Low | 1870 |
| LGH/LCH120 | Low | 2200 |
| LGH/LCH150 | Low | 2750 |
| Cooling Minimum CFM - 280* CFM/ton | | |
| Unit | Blower Speed | Airflow CFM |
| LGH/LCH092 | High | 2100 |
| LGH/LCH102 | High | 2380 |
| LGH/LCH120 | High | 2800 |
| LGH/LCH150 | High | 3500 |
| Smoke and Ventilation Minimum CFM - 150 CFM/ton | | |
| Unit | Not Applicable | Airflow CFM |
| LGH/LCH092 | NA | 1125 |
| LGH/LCH102 | NA | 1275 |
| LGH/LCH120 | NA | 1500 |
| LGH/LCH150 | NA | 1875 |
| Heating and Cooling Maximum CFM - 480 CFM/ton | | |
| Unit | Blower Speed | Airflow CFM |
| LGH/LCH092 | High | 3600 |
| LGH/LCH102 | High | 4080 |
| LGH/LCH120 | High | 4800 |
| LGH/LCH150 | High | 6000 |

**Refer to table 31 for ultra high efficiency unit minimum CFM / ton. Ultra high efficiency units are equipped with tandem compressors which allow lower minimum airflow.*

IX-Direct Drive Supply Air Inverter

If a test and balance contractor has not commissioned the unit, use this section to set supply air CFM.

A-Set Blower Speed

- 1- Use table 30 to fill in field-provided, design specified blower CFM.

TABLE 30
Blower CFM Design Specifications

| Blower Speed | Design Specified CFM |
|--------------|----------------------|
| Heating | |
| Cooling High | |
| Cooling Low | |
| Ventilation | |

- 2- Use the following menu to enter the blower design specified CFM into the Unit Controller. **Don't press "SAVE" until all CFM are entered.** Make sure blower CFM is within limitations shown in table 31. Refer to the Unit Controller manual provided with unit.

SETUP > TEST & BALANCE > BLOWER

- 3- Once all four speeds are entered, the target (highest of the heating and cooling settings) CFM and default RPM will be displayed.

Note - When units are not equipped with heat, the Blower Heat speed will not be displayed. Blower Cooling High will be the first blower speed to appear.

- 4- Measure the static pressure as shown in the *Blower Start-Up* section. Use the static pressure, target CFM and blower tables to determine the RPM needed. Values in the blower table reflect the static pressures taken in locations shown in figure 19.
- 5- Enter the RPM and repeat the previous step until the design CFM is reached.
- 6- Press SAVE followed by MAIN MENU.

Note - Once the CFM settings are saved, the Unit Controller will set all other blower CFM.

B-Set Damper Minimum Position

To maintain required minimum ventilation air volumes when the unit is in the occupied mode, two minimum damper positions must be set. The Unit Controller will open the dampers to "Min OCP Blwr Low" when blower CFM is BELOW a "midpoint" CFM. The Unit Controller will open the damper to "Min OCP Blwr High" when blower CFM is at or ABOVE the "midpoint" CFM.

The Unit Controller will calculate the "midpoint" CFM.

Set Minimum Position 1

Use the following menu in the Unit Controller to set "Min OCP Blwr Low" for the blower CFM below the "midpoint" CFM. When navigating into this menu, the Unit Controller will bring on the corresponding blower speed and allow damper position adjustment.

SETTINGS > RTU Options > EDIT PARAMETER > ENTER
DATA ID - 9 > MIN DAMPER LOW BLOWER = X.X %

Measure the intake air CFM. If the CFM is lower than the design specified CFM for ventilation air, use the Unit Controller to increase the damper percent open. If the CFM is higher than specified, decrease the damper percent open.

Note - Intake air CFM can also be determined using the outdoor air temperature, return air temperature and mixed air temperature. Refer to the economizer or outdoor air damper installation instructions.

Set Minimum Position 2

Use the same menu in the Unit Controller to set "Min OCP Blwr High" for the blower CFM above the "midpoint" CFM. When navigating into this menu, the Unit Controller will bring on the corresponding blower speed and allow damper position adjustment.

SETTINGS > RTU OPTIONS > DAMPER > MIN
DAMPER POSITION BLOWER ON HIGH = X.X %

Measure the intake air CFM. If the CFM is lower than the design specified CFM for ventilation air, use the Unit Controller to increase the damper percent open. If the CFM is higher than specified, decrease the damper percent open.

Note - Intake air CFM can also be determined using the outdoor air temperature, return air temperature and mixed air temperature. Refer to the economizer or outdoor air damper installation instructions.

**TABLE 31
MINIMUM AND MAXIMUM CFM
094U4E, 122U4E, 152U4E**

| Gas Heat Minimum CFM | | |
|--|---------------------|--------------|
| Unit | Gas Heat Size | Airflow CFM* |
| LGH094-152 | Std. , Med. | 2225 |
| LGH094-152 | High | 2550 |
| Electric Heat Minimum CFM | | |
| Unit | Heat Size (kW) | Airflow CFM |
| LCH094 | 7.5 | 1750 |
| LCH094 | 0, 15, 22.5, 30, 45 | 2750 |
| LCH122, 152 | 15, 22.5, 30, 45 | 2750 |
| LCH122, 152 | 0, 60 | 3500 |
| Cooling Low Minimum CFM - 160 CFM/ton | | |
| Unit | Blower Speed | Airflow CFM |
| LGH/LCH094 | Low | 1200 |
| LGH/LCH122 | Low | 1600 |
| LGH/LCH152 | Low | 2000 |
| Cooling High Minimum CFM - 220 CFM/ton | | |
| Unit | Blower Speed | Airflow CFM |
| LGH/LCH094 | High | 1650 |
| LGH/LCH122 | High | 2200 |
| LGH/LCH152 | High | 2750 |
| Smoke and Ventilation Minimum CFM - 150 CFM/ton | | |
| Unit | Not Applicable | Airflow CFM |
| LGH/LCH094 | NA | 1125 |
| LGH/LCH122 | NA | 1500 |
| LGH/LCH152 | NA | 1875 |
| Heating and Cooling Maximum CFM - 480 CFM/ton | | |
| Unit | Blower Speed | Airflow CFM |
| LGH/LCH094 | High | 3600 |
| LGH/LCH122 | High | 4800 |
| LGH/LCH152 | High | 6000 |

*Rounded to nearest 25 CFM.

X-Staged Supply Air Operation

This is a summary of cooling operation for both belt and direct drive blowers.

Note - During a dehumidification demand the blower operates at the highest speed. Free cooling is locked-out during reheat operation. Refer to Hot Gas Reheat start-up and operation section for details.

A-Two-Stage Thermostat

1-Economizer With Outdoor Air Suitable

Y1 Demand -

Compressors Off
Blower Cooling Low
Dampers modulate

Y2 Demand -

Compressors Off
Blower Cooling High
Dampers Modulate

Note - If dampers are at maximum open for three minutes, compressor 1 is energized and blower stays on cooling high.

2-No Economizer or Outdoor Air Not Suitable

Y1 Demand -

Compressor 1 On (on ultra high efficiency units, one compressor will operate)
Blower Cooling Low
Dampers Minimum Position

Y2 Demand -

Compressor 1 and 2 On
Blower Cooling High
Dampers Minimum Position

B-Three-Stage Thermostat OR Zone Sensor

1-Economizer With Outdoor Air Suitable

Y1 Demand -

Compressors Off
Blower Cooling Low
Dampers modulate

Y2 Demand -


Compressors Off
Blower Cooling High
Dampers Modulate

Note - If dampers are at maximum open for three minutes, compressor 1 is energized and blower stays on cooling high.

Y3 Demand -

Compressors 1 and 2 On
Blower Cooling High
Dampers Maximum Open

LGH092/102/120H - CONSTANT SUPPLY AIR, BELT DRIVE BLOWER



NOTE - IF ANY WIRE IN THIS APPLIANCE IS REPLACED IT MUST BE REPLACED WITH WIRE OF LIKE SIZE, RATING, TERMINATION AND INSULATION THICKNESS.
DISCONNECT ALL POWER BEFORE SERVICING !


| KEY | COMPONENT |
|----------|---|
| A55 | PANEL, MAIN |
| B1 | COMPRESSOR 1 |
| B2 | COMPRESSOR 2 |
| B3 | MOTOR, BLOWER |
| B4 | MOTOR, OUTDOOR FAN 1 |
| B5 | MOTOR, OUTDOOR FAN 2 |
| B10 | MOTOR, EXHAUST FAN |
| C1 | CAPACITOR, OUTDOOR FAN 1 |
| C2 | CAPACITOR, OUTDOOR FAN 2 |
| C6 | CAPACITOR, EXHAUST FAN |
| CB8 | CIRCUIT BREAKER, TRANSFORMER T1 |
| CB10 | CIRCUIT BREAKER, UNIT MAIN DISCONNECT |
| CB31 | CIRCUIT BREAKER, TRANSFORMER T43 |
| F4 | FUSE, UNIT |
| F10 | FUSE, OUTDOOR FAN MOTOR |
| F61 | FUSE, UNIT SCOR OPTION |
| HR1 | HEATER, COMPRESSOR 1 |
| HR2 | HEATER, COMPRESSOR 2 |
| J11 | JACK, GFI RECEPTICLE |
| K1-1 | CONTACTOR, COMPRESSOR 1 |
| K2-1 | CONTACTOR, COMPRESSOR 2 |
| K3, -1 | CONTACTOR, BLOWER |
| K10,-1,2 | RELAY, OUTDOOR FAN 1 |
| K65-1,2 | RELAY, EXHAUST FAN |
| K68,-1,2 | RELAY, OUTDOOR FAN 2 |
| L14 | VALVE, SOLENOID REHEAT COIL 1 |
| RT17 | SENSOR, OUTSIDE AIR TEMPERATURE |
| S4 | SWITCH, LIMIT HI PRESS COMP 1 |
| S5 | SWITCH, LIMIT HI TEMP COMPRESSOR 1 |
| S7 | SWITCH, LIMIT HI PRESS COMPRESS 2 |
| S8 | SWITCH, LIMIT HI TEMP COMPRESSOR 2 |
| S8 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMP 1 |
| S42 | SWITCH, OVERLOAD RELAY BLOWER MOTOR |
| S48 | SWITCH, DISCONNECT |
| S49 | SWITCH, FREEZE/STAT COMP 1 |
| S50 | SWITCH, FREEZE/STAT COMP 2 |
| S84 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMP 2 |
| S87 | SWITCH, LOW PRESS, COMPRESSOR 1 |
| S88 | SWITCH, LOW PRESS, COMPRESSOR 2 |
| T1 | TRANSFORMER, CONTROL |
| T43 | TRANSFORMER, HUMIDITROL |
| TB2 | TERMINAL STRIP, UNIT |

120 V FIELD PROVIDED POWER SUPPLY IS REQUIRED


- ⚠ S42 USED ON "M" VOLTAGE UNITS AND UNITS WITH HIGH EFFICIENCY MOTORS
- ⚠ ONLY IN UNITS WITH HUMIDITROL OR PHASE AND VOLTAGE DETECTION OPTION
- ⚠ EXTERNAL HUMIDITROL CONTACTS
- ⚠ S49 AND S50 ARE PART OF 5VDC CIRCUIT
- ⚠ J268-1,-3 AND J268-2,-4 ARE CONNECTED ON UNITS WITHOUT HUMIDITROL OR PHASE DETECTION OPTIONS
- ⚠ B10 IS NOT USED ON UNITS WITH ERV
- ⚠ USED ON UNITS WITH ERV SINGLE POINT POWER. SEE ERV DIAGRAM
- ⚠ USED ON LCH AND UNITS WITH ERV SINGLE POINT POWER ONLY
- ⚠ NOTE: FOR USE WITH COPPER CONDUCTORS ONLY. REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE.
- ⚠ F61 AND F10 USED ON LGH UNITS WITH SCOR OPTION
- ⚠ MOVE WIRE FROM 240 TO 208 TAP ON TRANSFORMER FOR 208 VOLT APPLICATIONS
- ⚠ CB10 NOT AVAILABLE ON UNITS WITH SCOR OPTION

| J/P | JACK/PLUG DESCRIPTION |
|-----|--------------------------------|
| 18 | EXHAUST FAN |
| 86 | OUTDOOR FAN INTERFACE |
| 132 | EXHAUST FAN MOTOR |
| 263 | HIGH AND LOW PRESSURE SWITCHES |
| 264 | BLOWER DECK |
| 265 | CONTACTORS AND RELAYS |
| 267 | OUTDOOR FAN AREA |
| 268 | TRANSFORMER T1 POWER |
| 269 | HUMIDITROL CONTROL |
| 299 | HUMIDITROL SAFETY INTERFACE |

← DENOTES OPTIONAL COMPONENTS
— LINE VOLTAGE FIELD INSTALLED

| | | | |
|---|--|----------------|-------|
| 2018/07 |  | WIRING DIAGRAM | 07/18 |
| | | 537625-03 | |
| COOLING | | | |
| LCH/LGH - 092H, 102H, 120H - G, J, M, Y | | | |
| SECTION B | | | REV 0 |
| Supersedes | | New Form No. | |
| 537625-02 | | 537625-03 | |

LGH150H - Y - CONSTANT SUPPLY AIR, BELT DRIVE BLOWER



- ⚠️ 42 USED ON "M" VOLTAGE UNITS AND UNITS WITH HIGH EFFICIENCY MOTORS
- ⚠️ ONLY IN UNITS WITH HUMIDITROL OR PHASE AND VOLTAGE DETECTION OPTION
- ⚠️ EXTERNAL HUMIDITROL CONTACTS
- ⚠️ 49 AND S50 ARE PART OF 5VDC CIRCUIT
- ⚠️ 268-1,-3 AND J268-2,-4 ARE CONNECTED ON UNITS WITHOUT HUMIDITROL OR PHASE DETECTION OPTIONS
- ⚠️ 10 IS NOT USED ON UNITS WITH ERV
- ⚠️ USED ON UNITS WITH ERV SINGLE POINT POWER. SEE ERV DIAGRAM
- ⚠️ USED ON LCH AND UNITS WITH ERV SINGLE POINT POWER ONLY
- ⚠️ NOTE: FOR USE WITH COPPER CONDUCTORS ONLY. REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE.
- ⚠️ F61 & F10 USED ON LGH UNITS WITH SCCR OPTION
- ⚠️ MOVE WIRE FROM 240 TO 208 TAP ON TRANSFORMER FOR 208 VOLT APPLICATIONS
- ⚠️ CB10 NOT AVAILABLE ON UNITS WITH SCCR OPTION


| J/P | JACK/PLUG DESCRIPTION |
|-----|--------------------------------|
| 18 | EXHAUST FAN |
| 86 | OUTDOOR FAN 1 |
| 87 | OUTDOOR FAN 2 |
| 132 | EXHAUST FAN MOTOR |
| 263 | HIGH AND LOW PRESSURE SWITCHES |
| 264 | BLOWER DECK |
| 265 | CONTACTORS AND RELAYS |
| 267 | OUTDOOR FAN AREA |
| 268 | TRANSFORMER T1 POWER |
| 269 | HUMIDITROL CONTROL |
| 299 | HUMIDITROL SAFETY INTERFACE |

DENOTES OPTIONAL COMPONENTS
 LINE VOLTAGE FIELD INSTALLED

| | | |
|-----------------------------|--|---------------------------|
| 2018/07 | | WIRING DIAGRAM 07/18 |
| 537897-02 | | |
| COOLING LCH/LGH 150H - Y | | |
| SECTION B | | REV 0 |
| Supersedes 537897-01 | | New Form No. 537897-02 |

LGH150H - G, J, M - CONSTANT SUPPLY AIR, BELT DRIVE BLOWER

24 VAC POWER




NOTE - IF ANY WIRE IN THIS APPLIANCE IS REPLACED IT MUST BE REPLACED WITH WIRE OF LIKE SIZE, RATING, TERMINATION AND INSULATION THICKNESS.
DISCONNECT ALL POWER BEFORE SERVICING !

| KEY | COMPONENT |
|-----------|---|
| A55 | PANEL, MAIN |
| B1 | COMPRESSOR 1 |
| B2 | COMPRESSOR 2 |
| B3 | MOTOR, BLOWER |
| B4 | MOTOR, OUTDOOR FAN 1 |
| B5 | MOTOR, OUTDOOR FAN 2 |
| B10 | MOTOR, EXHAUST FAN |
| C1 | CAPACITOR, OUTDOOR FAN 1 |
| C2 | CAPACITOR, OUTDOOR FAN 2 |
| C6 | CAPACITOR, EXHAUST FAN |
| CB8 | CIRCUIT BREAKER, TRANSFORMER T1 |
| CB10 | CIRCUIT BREAKER, UNIT MAIN DISCONNECT |
| CB31 | CIRCUIT BREAKER, TRANSFORMER T43 |
| F4 | FUSE, UNIT |
| F10 | FUSE, OUTDOOR FAN MOTOR |
| F61 | FUSE, SCOR OPTION UNIT |
| HR1 | HEATER, COMPRESSOR 1 |
| HR2 | HEATER, COMPRESSOR 2 |
| J11 | JACK, GFI RECEPTICLE |
| K1,-1 | CONTACTOR, COMPRESSOR 1 |
| K2,-1 | CONTACTOR, COMPRESSOR 2 |
| K3,-1 | CONTACTOR, BLOWER |
| K10,-1,2 | RELAY, OUTDOOR FAN 1 |
| K65,-1,2 | RELAY, EXHAUST FAN |
| K68,-1,2 | RELAY, OUTDOOR FAN 2 |
| K251,-1,2 | RELAY, 2SPEED MOTOR HIGH |
| K252,-1,2 | RELAY, 2SPEED MOTOR LOW |
| L30 | VALVE, SOLENOID REHEAT COIL 2 |
| RT17 | SENSOR, OUTSIDE AIR TEMPERATURE |
| S4 | SWITCH, LIMIT HI PRESS COMP 1 |
| S5 | SWITCH, LIMIT HI TEMP COMPRESSOR 1 |
| S7 | SWITCH, LIMIT HI PRESS COMPRESS 2 |
| S8 | SWITCH, LIMIT HI TEMP COMPRESSOR 2 |
| S11 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMP 1 |
| S42 | SWITCH, OVERLOAD RELAY BLOWER MOTOR |
| S48 | SWITCH, DISCONNECT |
| S49 | SWITCH, FREEZESTAT COMP 1 |
| S50 | SWITCH, FREEZESTAT COMP 2 |
| S84 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMP 2 |
| S87 | SWITCH, LOW PRESS, COMPRESSOR 1 |
| S88 | SWITCH, LOW PRESS, COMPRESSOR 2 |
| T1 | TRANSFORMER, CONTROL |
| T43 | TRANSFORMER, HUMIDITROL |
| TB2 | TERMINAL STRIP, UNIT |

- ⚠️ 42 USED ON "M" VOLTAGE UNITS AND UNITS WITH HIGH EFFICIENCY MOTORS
- ⚠️ ONLY IN UNITS WITH HUMIDITROL OR PHASE AND VOLTAGE DETECTION OPTION
- ⚠️ EXTERNAL HUMIDITROL CONTACTS
- ⚠️ 49 AND S50 ARE PART OF 5VDC CIRCUIT
- ⚠️ 268-1,-3 AND J268-2,-4 ARE CONNECTED ON UNITS WITHOUT HUMIDITROL OR PHASE DETECTION OPTIONS
- ⚠️ 810 IS NOT USED ON UNITS WITH ERV
- ⚠️ USED ON UNITS WITH ERV SINGLE POINT POWER. SEE ERV DIAGRAM
- ⚠️ USED ON LCH AND UNITS WITH ERV SINGLE POINT POWER ONLY
- ⚠️ NOTE: FOR USE WITH COPPER CONDUCTORS ONLY. REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE.
- ⚠️ F61 & F10 USED ON LGH UNITS WITH SCCR OPTION
- ⚠️ MOVE WIRE FROM 240 TO 208 TAP ON TRANSFORMER FOR 208 VOLT APPLICATIONS
- ⚠️ CB10 NOT AVAILABLE ON UNITS WITH SCCR OPTION

| J/P | JACK/PLUG DESCRIPTION |
|-----|--------------------------------|
| 18 | EXHAUST FAN |
| 86 | OUTDOOR FAN 1 |
| 87 | OUTDOOR FAN2 |
| 132 | EXHAUST FAN MOTOR |
| 263 | HIGH AND LOW PRESSURE SWITCHES |
| 284 | BLOWER DECK |
| 285 | CONTACTORS AND RELAYS |
| 287 | OUTDOOR FAN AREA |
| 268 | TRANSFORMER T1 POWER |
| 269 | HUMIDITROL CONTROL |
| 299 | HUMIDITROL SAFETY INTERFACE |

← DENOTES OPTIONAL COMPONENTS
— LINE VOLTAGE FIELD INSTALLED

| | | | |
|-------------------------|--|---------------------------|-------|
| 2018/07 |  | WIRING DIAGRAM | 07/18 |
| | | 537898-02 | |
| COOLING | | | |
| LCH/LGH 150H - G, J, M | | | |
| SECTION B | | | REV 0 |
| Supersedes 537898-01 | | New Form No. 537898-02 | |

LGH092/150 SEQUENCE OF OPERATION

Power:

- 1- Line voltage through the S48 unit disconnect, TB2 terminal block, or CB10 circuit breaker energizes the T1 transformer. T1 provides 24VAC power to A55 Unit Controller which provides 24VAC to the unit cooling, heating and blower controls.
- 2- Line voltage is also routed to compressor crankcase heaters, compressor contactors, the blower motor contactor, condenser fan relays and exhaust fan relays.

Blower Operation:

- 3- The A55 Unit Controller module receives a demand from thermostat terminal G. A55 energizes blower contactor K3 with 24VAC.
- 4- N.O. K3-1 closes, energizing blower B3.

Economizer Operation:

- 5- A55 receives a demand and energizes exhaust fan relay K65 with 24VAC at 50% outside air damper open (adjustable).
- 6- N.O. K65-1 and N.O. K65-2 both close, energizing exhaust fan motor B10.


1st Stage Cooling (compressor B1)

- 7- A55 receives a Y1 thermostat demand.
- 8- After A55 proves N.C. low pressure switch S87, N.C. freezestat S49 and N.C. high pressure switch S4, compressor contactor K1 is energized.
- 9- N.O. contacts K1-1 close energizing compressor B1.
- 10- At the same time, A55 energizes condenser fan relays K10 (when N.O. low ambient switches S11 and S84 close) and K68.
- 11- N.O. contacts K10-1 close energizing condenser fan B4 and N.C. contacts K10-2 open, de-energizing compressor crankcase heaters HR1 and HR2. N.O. contacts K68-1 close energizing condenser fan B5.

2nd Stage Cooling (compressor B2 is energized)

- 12- A55 receives a Y2 thermostat demand.
- 13- After A55 proves N.C. low pressure switch S88, N.C. freezestat S50 and N.C. high pressure switch S7, compressor contactor K2 is energized.
- 14- N.O. contacts K2-1 close energizing compressor B2.

LGH092/152U STAGED SUPPLY AIR, NO BYPASS, BELT DRIVE BLOWER



| KEY | COMPONENT |
|---------|---|
| A1 | PANEL, AUTOMATED LOGIC CONTROL (ALC) |
| A55 | PANEL, MAIN |
| A96 | CONTROL INVERTER |
| B1 | COMPRESSOR 1 |
| B2 | COMPRESSOR 2 |
| B3 | MOTOR, BLOWER |
| B4 | MOTOR, OUTDOOR FAN 1 |
| B5 | MOTOR, OUTDOOR FAN 2 |
| B10 | MOTOR, EXHAUST FAN |
| B21 | MOTOR, OUTDOOR FAN 3 |
| C6 | CAPACITOR, EXHAUST FAN |
| CB8 | CIRCUIT BREAKER, T1 |
| CB10 | CIRCUIT BREAKER, MAIN DISCONNECT, UNIT |
| CB31 | CIRCUIT BREAKER, TRANSFORMER T43 |
| F4 | FUSE, UNIT |
| F10 | FUSE, OUTDOOR FAN MOTOR |
| F57 | FUSE, T5 TRANSFORMER PRIMARY |
| F61 | FUSE, UNIT SCCR OPTION |
| HR1 | HEATER, COMPRESSOR 1 |
| HR2 | HEATER, COMPRESSOR 2 |
| J11 | JACK, GFI RECEPTACLE |
| K1-1 | CONTACTOR, COMPRESSOR 1 |
| K2-1 | CONTACTOR, COMPRESSOR 2 |
| K191-1 | RELAY, CRANKCASE HEATER 1 |
| K65-1,2 | RELAY, EXHAUST FAN |
| K194-1 | RELAY, CRANKCASE HEATER 2 |
| K203-2 | RELAY, INVERTER START/RUN |
| L41 | VALVE SOLENOID, |
| L42 | VALVE SOLENOID, |
| R55 | RESISTOR, VFD LOADING, A96 |
| RT17 | SENSOR, OUTSIDE AIR TEMPERATURE |
| S4 | SWITCH, LIMIT HI PRESS COMP 1 |
| S5 | SWITCH, LIMIT HI TEMP COMPRESSOR 1 |
| S8 | SWITCH, LIMIT HI TEMP COMPRESSOR 2 |
| S11 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMP 1 |
| S48 | SWITCH, DISCONNECT |
| S49 | SWITCH, FREEZESTAT COMP 1 |
| S50 | SWITCH, FREEZESTAT COMP 2 |
| S87 | SWITCH, LOW PRESS, COMPRESSOR 1 |
| T1 | TRANSFORMER, CONTROL |
| T5 | TRANSFORMER, |
| T43 | TRANSFORMER, REHEAT |
| TB2 | TERMINAL STRIP, UNIT |
| TB13 | TERMINAL STRIP, POWER DISTRIBUTION |

⚠ T5 USED ON G AND J VOLTAGE ONLY

⚠ USED ON 094U, 122U, 152U UNITS ONLY

⚠ S49 IS PART OF 5VDC CIRCUIT

⚠ OPTIONAL

⚠ K65 CONTROLLED BY A1, IN TARGET ALC APPLICATIONS ONLY

⚠ DO7 USED ON UNITS WITH HUMIDITROL TO POWER EXHAUST FANS, DO6 PROVIDES POWER TO K65 ON UNITS WITH NO HUMIDITROL

⚠ NOTE: FOR USE WITH COPPER CONDUCTORS ONLY. REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE.

⚠ F10 USED ON UNITS WITH SCCR OPTION, F61 USED ON LGH UNITS WITH SCCR OPTION

⚠ MOVE WIRE FROM 240 TO 208 TAP ON TRANSFORMER FOR 208 VOLT APPLICATIONS

⚠ CB10 NOT AVAILABLE ON UNITS WITH SCCR OPTION

| J/P | JACK/PLUG DESCRIPTION |
|-----|----------------------------------|
| 18 | POWER, EXHAUST FAN |
| 48 | POWER TO INDOOR BLOWER |
| 86 | POWER, OUTDOOR FAN INTERFACE B4 |
| 87 | POWER, OUTDOOR FAN INTERFACE B5 |
| 88 | POWER, OUTDOOR FAN INTERFACE B21 |
| 132 | POWER, EXHAUST FAN MOTOR |
| 246 | POWER TO VFD |
| 247 | POWER, VFD TO MOTOR |
| 248 | VFD CONTROL |
| 263 | HIGH AND LOW PRESSURE SWITCHES |
| 264 | BLOWER DECK |
| 265 | CONTACTORS AND RELAYS |
| 267 | OUTDOOR FAN AREA |
| 268 | TRANSFORMER T1 POWER |
| 269 | TRANSFORMER T43 POWER |
| 298 | IAQ INTERFACE |

⚡ DENOTES OPTIONAL COMPONENTS
 — LINE VOLTAGE FIELD INSTALLED

2018/07
WIRING DIAGRAM
07/18

537616-04

COOLING -MSAV NO BYPASS

(ULTRA) LCH/LGH - 092U, 094U, 120U, 122U, 152U - Y, G, J, M

Supersedes
537616-03
SECTION B
New Form No.
537616-04
REV 0

LGH092/152U M3 SEQUENCE OF OPERATION

Power:

- 1- Line voltage through the S48 unit disconnect, TB2 terminal block, or CB10 circuit breaker energizes the T1 transformer. T1 provides 24VAC power to A55 Unit Controller which provides 24VAC to the unit cooling, heating and blower controls.
- 2- Line voltage is also routed to compressor crankcase heaters, compressor contactors, supply air inverter control, condenser fan relays and exhaust fan relays.

Blower Operation:

Supply Air Inverter: Refer to Supply Air Inverter or Direct Drive blower diagram and sequence of operation.

Economizer Operation:

- 3- A55 receives a demand and energizes exhaust fan relay K65 with 24VAC at 50% outside air damper open (adjustable).
- 4- N.O. K65-1 and N.O. K65-2 both close, energizing exhaust fan motor B10.

1st Stage Cooling (compressor B1 or B2)

- 5- A55 receives a Y1 thermostat demand.
- 6- After A55 proves N.C. low pressure switch S87, N.C. freezestat S49 and N.C. high pressure switch S4, compressor contactor K1 or K2 are energized. *Note - A55 logic (using input from RT37 and RT38 temperature sensors and A185 pressure transducer) determines which contactor is energized.*
- 7- N.O. contacts K1-1 or K2-1 close energizing compressor B1 or B2.

At the same time A55 energizes:

All three condenser fans, B4, B5 & B21, on **LOW** speed.

K191 compressor 1 crankcase heater relay when K1 is energized or K194 compressor 2 crankcase heater relay when K2 is energized (after A55 proves N.O. low ambient switch S11 is closed).

- 8- N.C. K191-1 compressor 1 crankcase heater contacts or N.C. K194-1 compressor 2 crankcase heater contacts open and de-energize compressor crankcase heater HR1 or HR2.

2nd Stage Cooling (compressor B1 and B2 are energized)

- 9- A55 receives a Y2 thermostat demand.
- 10-The K1 or K2 compressor contactor which was not energized will close.
- 11-N.O. K1-1 or K2-1 relay contacts which were not energized will close. The corresponding B1 or B2 compressor will operate in tandem with the other compressor.



At the same time A55 energizes:

All three condenser fans, B4, B5 & B21, on **HIGH** speed.

The K191 or K194 crankcase heater relay which was not energized will close. N.C. K191-1 or K194-1 relay contacts open and de-energize the corresponding crankcase heater HR1 or HR2.

GAS HEAT FOR LGH092/150 UNITS

| KEY | DESCRIPTION |
|---------|-------------------------------------|
| A3 | CONTROL, BURNER 1 |
| A55 | CONTROL, MAIN BOARD LENNOX |
| B6 | MOTOR COMBUSTION AIR BLOWER |
| C3 | CAPACITOR, COMB AIR BLOWER 1 |
| E1 | SPARK |
| F10 | FUSE, OUTDOOR FAN MOTOR |
| FS1 | SENSOR FLAME |
| GV1 | VALVE GAS 1 |
| HR6 | HEATER, -50C LOW AMBIENT KIT |
| J15 | JACK, BURNER 1 |
| J19 | JACK, COMBUSTION AIR BLOWER 1 |
| J135 | JACK, PRIMARY LIMIT |
| J228 | JACK, VESTIBULE HEATER |
| J229 | JACK, VESTIBULE HEATER CONTROL 1 |
| J265C | JACK, CONTACTOR RELAY |
| J266A | JACK, HEATING CONTROL STG 1 |
| J271A,B | JACK, HEATING SENSORS STG 1 |
| K13,-1 | RELAY, COMBUSTION AIR BLOWER |
| K123,-1 | RELAY, SINGLE THROW LIMIT |
| K125,-1 | RELAY, HEAT SHUT OFF |
| P15 | PLUG, BURNER 1 |
| P19 | PLUG, COMBUSTION AIR BLOWER 1 |
| P135 | PLUG, PRIMARY LIMIT |
| P228 | PLUG, VESTIBULE HEATER |
| P229 | PLUG, VESTIBULE HEATER CONTROL 1 |
| P265 | PLUG, CONTACTOR RELAY |
| P266 | PLUG, HEATING CONTROL |
| P271 | PLUG, HEATING SENSORS STG 1 |
| S10 | SWITCH, LIMIT PRIMARY GAS |
| S18 | SWITCH, COMBUSTION AIR BLOWER PROOF |
| S47 | SWITCH FLAME ROLLOUT BURNER |
| S59 | TSTAT, OPEN -20F, CLOSE 10F |
| S60 | TSTAT, OPEN 20F, CLOSE -10F |
| S61 | TSTAT, OPEN 50F, CLOSE 20F |
| T3 | TRANSFORMER COMB AIR BWR 1 |



- ⚠ CSA (-50C) LOW AMBIENT KIT (OPTIONAL)
 - ⚠ T3 USED ON 575 V UNITS ONLY
 - ⚠ GROUND WIRE CE ONLY
 - ⚠ F10 USED ON UNITS WITH SCCR OPTION
 - ⚠ T3 NOT CONNECTED TO F10 ON 575V SCCR UNITS
- ← DENOTES OPTIONAL COMPONENTS

| | | | |
|----------------------------|-----------|---------------------------|--------|
| 2018/07 | | WIRING DIAGRAM | 07/18 |
| | 537705-04 | | |
| HEATING | | | |
| GAS HEAT, 130, 180 AND 240 | | | |
| SECTION A | | | REV. 0 |
| Supersedes 537705-03 | | New Form No. 537705-04 | |

GAS HEAT SEQUENCE OF OPERATION LGH092/150

First Stage Heat:

- 1- Heating demand initiates at W1 in the thermostat.
- 2- 24VAC is routed through TB34 to the A55 Unit Controller. After A55 proves N.C. primary limit S21, the combustion air blower relay K13 is energized.
- 3- N.O. K13-1 contacts close allowing line voltage to energize combustion air blower B6.
- 4- After the combustion air blower B6 has reached full speed, the combustion air proving switch S18 contacts close. The A55 routes 24VAC through N.C. burner flame roll-out switch S47 and the closed contacts of combustion air proving switch S18 to energize the ignition module A3.
- 5- After a 30 second delay A3 energizes the ignitor and LO terminal (low fire) of gas valve GV1.

Second Stage Heat:

- 6- With first stage heat operating, an additional heating demand initiates W2 in the thermostat.
- 7- A second stage heating demand is received by A55 Unit Controller.
- 8- A55 energizes HI terminal (high fire) of gas valve GV1.

End of Second Stage Heat:

- 9- Heating demand is satisfied. Terminal W2 (high fire) is de-energized.
- 10- Terminal HI of GV1 is de-energized by A55 control module.

End of First Stage Heat:


- 11- Heating demand is satisfied. Terminal W1 (low fire) is de-energized.
- 12- Ignition A3 is de-energized by control module A55 in turn de-energizing terminal LO of GV1. Combustion air blower relay K13 is also de-energized.

Optional Low Ambient Kit:

(C.G.A. -50° C Low Ambient Kit)

- 13- Line voltage (or transformer T20 in 460V and 575V only) is routed through the low ambient kit fuses F20 and N.C. low ambient kit thermostats S60 and S61, to energize low ambient kit heater HR6.

ELECTRONIC OR ELECTROMECHANICAL THERMOSTAT



24 V COMMON

| KEY | DESCRIPTION | COMPONENT |
|----------|---------------------------------------|-----------|
| A2 | SENSOR, ELECTRONIC THERMOSTAT | P253 |
| A24 | CONTROL, OUTDOOR AIR CFM FLOW | P255 |
| A34 | DIFFERENTIAL PRESSURE TRANSDUCER | P264 |
| A55 | CONTROLBOARD, MAIN | |
| A63 | SENSOR, CO2 (IAQ) OPTIONAL | P297 |
| A91 | SENSOR, HUMIDITY | P298 |
| A171 | SENSOR ONE, SMOKE, RETURN AIR | P299 |
| A172 | SENSOR TWO, SMOKE, SUPPLY AIR | P304 |
| A173 | MODULE, CONTROL SMOKE DETECTION | RT6 |
| J26 | JACK, AIR FLOW CONTROL | RT16 |
| J99 | JACK, RT16 RETURN AIR SENSOR | S27 |
| J100 | JACK, RT6 SUPPLY AIR SENSOR | S52 |
| J250 | JACK, SMOKE DETECTOR ONE | S42 |
| J251 | JACK, SMOKE DETECTOR ONE | S96 |
| J252 | JACK, SMOKE DETECTOR TWO | S135 |
| J253 | JACK, SMOKE DETECTOR TWO | S149 |
| J255 | JACK, MODULE, CONTROL SMOKE DETECTION | S179 |
| J261 | JACK, SUPPLY SMOKE DETECTOR JUMPER | T8 |
| J262 | JACK, ECONOMIZER | |
| J264 | JACK, BLOWER DECK | |
| J297 | JACK, THERMOSTAT - DDC INTERFACE | |
| J298 | JACK, IAQ INTERFACE | |
| J299 | JACK, SAFETY INTERFACE | |
| K27, - | RELAY, TRANSFER | |
| K55, -1 | RELAY, BLOWER | |
| K222, -1 | RELAY, COMPRESSOR LOCKOUT | |
| P26 | PLUG, AIR FLOW CONTROL | |
| P99 | PLUG, RT16 RETURN AIR SENSOR | |
| P100 | PLUG, RT6 SUPPLY AIR SENSOR | |
| P250 | PLUG, SMOKE DETECTOR ONE | |
| P251 | PLUG, SMOKE DETECTOR ONE | |
| P252 | PLUG, SMOKE DETECTOR TWO | |


- ▲ FOR MOTORS WITH S42 EXTERNAL OVERLOAD LESS INVERTER, SEE INVERTER WITH BY PASS FOR S42 HOOK UP
- ▲ USE S86 DEHUMIDISTAT AND K55 FOR OPTIONAL SUPERMARKET REHEAT SCHEME, PRODIGY PARAMETERS NEED TO BE MODIFIED UNDER THE SETTINGS MENU OR VIA UC SOFTWARE FOR SIMULTANEOUS HEATING AND COOLING.
- ▲ REMOTE LOCATION OF RT6
- ▲ P298-8 (DO-1) IS SERVICE RELAY OUTPUT (24VAC) IF USED CONNECT TO AN INDICATOR LIGHT
- ▲ THERMOSTAT HOOKUP FOR PROGRAMMABLE CONFIGURATION OF THE BOARD (A55).
- ▲ PRODIGY SETTINGS MUST BE MODIFIED WHEN K222, S42, S52, S149 OR S179 ARE INSTALLED
- ▲ CONNECT A172 SENSOR TO J261 ON SUPPLY AIR SMOKE DETECTOR ONLY
- ▲ S179, OVERFLOW SWITCH USED ON LGH/LCH 420-600 UNITS ONLY
- ▲ A63, A34 & A24 ARE MUTUALLY EXCLUSIVE
- ▲ FACTORY INSTALLED OPTION FOR LGH/LCH 242-600 UNITS ONLY

--- DESIGNATES OPTIONAL WIRING
 - - - - - CLASS II FIELD WIRING

| | | | |
|---|--|----------------|--------|
| 08/17 | | WIRING DIAGRAM | 08/17 |
| 537108-03 | | | |
| ACCESSORIES | | | |
| ELECTRONIC OR ELECTROMECHANICAL THERMOSTAT FOR ENERGECE | | | |
| SECTION C | | | REV. 3 |
| Supersedes | | New Form No. | |
| | | 537108-03 | |


- 1- The A55 Unit Controller energizes the thermostat components with 24VAC via J/P297-1.
- 2- The A55 Unit Controller proves the optional N.O. filter switch S27 (indicates dirty filter when closed) and optional N.O. air flow switch S52 (indicates no air [i.e. broken belt] system shuts down).
- 3- The A55 Unit Controller receives data from the supply and return smoke detectors A171 and A172, blower motor overload relay S42, discharge sensor RT6 and return air sensor RT16.
- 4- The A55 Unit Controller receives data from the electronic thermostat A2 (Y1, Y2, W1, W2, G, OCP) and the CO₂ sensor A63 (if economizer is used). A55 energizes the appropriate components.

ECONOMIZER



| KEY | DESCRIPTION |
|-------|----------------------------------|
| A7 | SENSOR, SOLID STATE ENTHALPY |
| A130 | CONTROL, ERS |
| A55 | CONTROL, MAIN PANEL LENNOX |
| A62 | SENSOR, ENTHALPY INDOOR |
| A72 | CONTROL, REMOTE MIN POS (OPT) |
| B7 | MOTOR, DAMPER ECONOMIZER |
| B43 | MOTOR, EXHAUST DAMPER |
| J3 | JACK, UNIT ECONOMIZER |
| J104 | JACK, SENSOR OUTDOOR ENTHALPY |
| J105 | JACK, SENSOR RETURN AIR ENTHALPY |
| J153 | JACK, ENTHALPY / DAMPER MOTOR |
| J193 | JACK, ENTHALPY SENSOR |
| J298A | JACK, IAQ INTERFACE |
| J262A | JACK, DAMPER MOTOR |
| J262B | JACK, ENTHALPY SENSORS |
| P3 | PLUG, ECONOMIZER BYPASS |
| P153 | PLUG, ENTHALPY / DAMPER MOTOR |
| P193 | PLUG, ENTHALPY SENSOR |
| P262 | PLUG, ECONOMIZER OUTPUT |
| S118 | THERMOSTAT, DESICANT DEFROST |
| S174 | SWITCH, EXHAUST DAMPER |

- ⚠ DELETE A7 AND A62 (IF USED) FOR EITHER GLOBAL ENTHALPY OR SENSIBLE TEMPERATURE CONTROL
- ⚠ FOR UNIT DIFFERENTIAL ENTHALPY CONTROL, ADD A62 RETURN AIR ENTHALPY SENSOR
- ⚠ OPTIONAL EXHAUST DAMPER ACTUATOR TO HOLD EXHAUST DAMPER CLOSED WHEN OUTSIDE AIR DAMPER IS CLOSED



- ENERGY RECOVERY WHEEL HOOK UP
NOTE - THIS DIAGRAM USED ONLY WHEN ECONOMIZER OR MOTORIZED OUTDOOR AIR DAMPERS ARE INSTALLED.
- ⚠ S118 USED ON 35 TO 50 TON ENERGENCE UNITS WITH ENERGY RECOVERY WHEEL (ERW)
 - ⚠ REPOSITION A7 ENTHALPY SENSOR FROM ROOFTOP UNIT ECONOMIZER INTO INTAKE HOOD OF THE ERW ROOFTOP UNIT
 - ⚠ REMOVE JUMPER WHEN INSTALLING OPTIONAL LOW AMBIENT SWITCH

— — — — — DESIGNATES OPTIONAL WIRING
- - - - - CLASS II FIELD WIRING

| | | |
|--|--|---------------------------|
| WIRING DIAGRAM | | 04/18 |
| ACCESSORIES | | |
| ENERGENCE/STRATEGOS SERIES ECONOMIZER AND MOTORIZED OAD PIVOTING WHEEL ENERGY RECOVERY SYSTEM OPTION | | |
| SECTION D | | REV 3 |
| Supersedes | | New Form No. 537189-01 |

POWER:


- 1- A55 Unit Controller energizes the economizer components with 24VAC.

OPERATION:

- 2- The A55 Unit Controller along with outdoor enthalpy sensor A7 and indoor enthalpy sensor A62 (if differential enthalpy is used) powers the damper motor B7.
- 3- A55 supplies B7 with 0 - 10 VDC to control the positioning of economizer.
- 4- The damper actuator provides 2 to 10 VDC position feedback.

LGH092/102/120H STAGED SUPPLY AIR, NO BYPASS, BELT DRIVE BLOWER

NOTE - IF ANY WIRE IN THIS APPLIANCE IS REPLACED IT MUST BE REPLACED WITH WIRE OF LIKE SIZE, RATING, TERMINATION AND INSULATION THICKNESS.
DISCONNECT ALL POWER BEFORE SERVICING!



| KEY | COMPONENT |
|----------|---|
| A1 | PANEL, AUTOMATED LOGIC CONTROL (ALC) |
| A55 | PANEL, MAIN |
| A96 | CONTROL INVERTER |
| B1 | COMPRESSOR 1 |
| B2 | COMPRESSOR 2 |
| B3 | MOTOR, BLOWER |
| B4 | MOTOR, OUTDOOR FAN 1 |
| B5 | MOTOR, OUTDOOR FAN 2 |
| B10 | MOTOR, EXHAUST FAN |
| C1 | CAPACITOR, OUTDOOR FAN 1 |
| C2 | CAPACITOR, OUTDOOR FAN 2 |
| C6 | CAPACITOR, EXHAUST FAN |
| CB8 | CIRCUIT BREAKER, T1 |
| CB10 | CIRCUIT BREAKER, MAIN DISCONNECT, UNIT |
| CB31 | CIRCUIT BREAKER, TRANSFORMER T43 |
| F4 | FUSE, UNIT |
| F10 | FUSE, OUTDOOR FAN MOTOR |
| F61 | FUSE, SCCR OPTION UNIT |
| HR1 | HEATER, COMPRESSOR 1 |
| HR2 | HEATER, COMPRESSOR 2 |
| J11 | JACK, GFI RECEIPTICLE |
| K1,-1 | CONTACTOR, COMPRESSOR 1 |
| K2,-1 | CONTACTOR, COMPRESSOR 2 |
| K3,-1 | CONTACTOR, BLOWER |
| K10,-1,2 | RELAY, OUTDOOR FAN 1 |
| K65,-1,2 | RELAY, EXHAUST FAN |
| K68,-1,2 | RELAY, OUTDOOR FAN 2 |
| K203,-2 | RELAY, INVERTER START/RUN |
| L14 | VALVE SOLENOID, REHEAT COIL 1 |
| R55 | RESISTOR, VFD LOADING, A96 |
| RT17 | SENSOR, OUTSIDE AIR TEMPERATURE |
| S4 | SWITCH, LIMIT HI PRESS COMP 1 |
| S5 | SWITCH, LIMIT HI TEMP COMPRESSOR 1 |
| S7 | SWITCH, LIMIT HI PRESS COMPRESSOR 2 |
| S8 | SWITCH, LIMIT HI TEMP COMPRESSOR 2 |
| S11 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMF |
| S48 | SWITCH, DISCONNECT |
| S49 | SWITCH, FREEZESTAT COMP 1 |
| S50 | SWITCH, FREEZESTAT COMP 2 |
| S84 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMF |
| S87 | SWITCH, LOW PRESS, COMPRESSOR 1 |
| S88 | SWITCH, LOW PRESS, COMPRESSOR 2 |
| T1 | TRANSFORMER, CONTROL |
| T43 | TRANSFORMER, REHEAT |
| TB2 | TERMINAL STRIP, UNIT |
| TB13 | TERMINAL STRIP, POWER DISTRIBUTION |

| J/P | JACK/PLUG DESCRIPTION |
|-----|--------------------------------|
| 18 | POWER, EXHAUST FAN |
| 86 | POWER, OUTDOOR FAN INTERFACE |
| 132 | POWER, EXHAUST FAN MOTOR |
| 194 | GP CONTROL INPUT/OUTPUT |
| 246 | POWER TO VFD |
| 247 | POWER, VFD TO MOTOR |
| 248 | VFD CONTROL |
| 263 | HIGH AND LOW PRESSURE SWITCHES |
| 264 | BLOWER DECK |
| 265 | CONTACTORS AND RELAYS |
| 267 | OUTDOOR FAN AREA |
| 268 | TRANSFORMER T1 POWER |
| 269 | TRANSFORMER T43 POWER |
| 298 | IAQ INTERFACE |
| 299 | HUMIDITROL, SAFETY |

▲ ONLY IN UNITS WITH HUMIDITROL OR PHASE AND VOLTAGE DETECTION OPTION
 ▲ EXTERNAL HUMIDITROL CONTACTS
 ▲ S49 AND S50 ARE PART OF 5VDC CIRCUIT


▲ J268-1,-3 AND J268-2,-4 ARE CONNECTED ON UNITS WITHOUT HUMIDITROL OR PHASE DETECTION OPTIONS
 ▲ B10 IS NOT USED ON UNITS WITH ERV
 ▲ USED ON UNITS WITH ERV SINGLE POINT POWER. SEE ERV DIAGRAM
 ▲ K65 IS CONTROLLED BY A1 ONLY IN TARGET ALC APPLICATIONS
 ▲ USED ON LCH AND UNITS WITH ERV SINGLE POINT POWER ONLY

▲ DO7 USED ON UNITS WITH HUMIDITROL TO POWER EXHAUST FANS. DO6 PROVIDES POWER TO K65 ON UNITS WITH NO HUMIDITROL
 ▲ NOTE: FOR USE WITH COPPER CONDUCTORS ONLY. REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE.
 ▲ F61 AND F10 USED ONLGH UNITS WITH SCCR OPTION
 ▲ MOVE WIRE FROM 240 TO 208 TAP ON TRANSFORMER FOR 208 VOLT APPLICATIONS
 ▲ CB10 NOT AVAILABLE ON UNITS WITH SCCR OPTION

— DENOTES OPTIONAL COMPONENTS
 — LINE VOLTAGE FIELD INSTALLED

| | | |
|----------------------|------------------------------------|------------------------|
| 2018/07 | WIRING DIAGRAM | 07/18 |
| | 537626-04 | |
| | COOLING -MSAV NO BYPASS | |
| | LCH/LGH - 092H,102H,120H - G,J,M,Y | |
| SECTION B | | REV 0 |
| Supersedes 537626-03 | | New Form No. 537626-04 |

LGH150H - Y - STAGED SUPPLY AIR, NO BYPASS, BELT DRIVE BLOWER



| KEY | COMPONENT |
|-----------|---|
| A1 | PANEL, AUTOMATED LOGIC CONTROL (ALC) |
| A55 | PANEL, MAIN |
| A96 | CONTROL INVERTER |
| B1 | COMPRESSOR 1 |
| B2 | COMPRESSOR 2 |
| B3 | MOTOR, BLOWER |
| B4 | MOTOR, OUTDOOR FAN 1 |
| B5 | MOTOR, OUTDOOR FAN 2 |
| B10 | MOTOR, EXHAUST FAN |
| C1 | CAPACITOR, OUTDOOR FAN 1 |
| C2 | CAPACITOR, OUTDOOR FAN 2 |
| C6 | CAPACITOR, EXHAUST FAN |
| CB8 | CIRCUIT BREAKER, T1 |
| CB10 | CIRCUIT BREAKER, MAIN DISCONNECT, UNIT |
| CB31 | CIRCUIT BREAKER, TRANSFORMER T43 |
| F4 | FUSE, UNIT |
| F10 | FUSE, OUTDOOR FAN MOTOR |
| F61 | FUSE, SCCR OPTION UNIT |
| HR1 | HEATER, COMPRESSOR 1 |
| HR2 | HEATER, COMPRESSOR 2 |
| J11 | JACK, GFI RECEPTICLE |
| K1,-1 | CONTACTOR, COMPRESSOR 1 |
| K2,-1 | CONTACTOR, COMPRESSOR 2 |
| K3,-1 | CONTACTOR, BLOWER |
| K10,-1,2 | RELAY, OUTDOOR FAN 1 |
| K65,-1,2 | RELAY, EXHAUST FAN |
| K68,-1,2 | RELAY, OUTDOOR FAN 2 |
| K203,-2 | RELAY, INVERTER START/RUN |
| K251,-1,2 | RELAY, 2 SPEED MOTOR |
| L14 | VALVE SOLENOID, REHEAT COIL 1 |
| R55 | RESISTOR, VFD LOADING, A96 |
| RT17 | SENSOR, OUTSIDE AIR TEMPERATURE |
| S4 | SWITCH, LIMIT HI PRESS COMP 1 |
| S5 | SWITCH, LIMIT HI TEMP COMPRESSOR 1 |
| S7 | SWITCH, LIMIT HI PRESS COMPRESSOR 2 |
| S8 | SWITCH, LIMIT HI TEMP COMPRESSOR 2 |
| S11 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMP |
| S48 | SWITCH, DISCONNECT |
| S49 | SWITCH, FREEZESTAT COMP 1 |
| S50 | SWITCH, FREEZESTAT COMP 2 |
| S84 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMP |
| S87 | SWITCH, LOW PRESS, COMPRESSOR 1 |
| S88 | SWITCH, LOW PRESS, COMPRESSOR 2 |
| T1 | TRANSFORMER, CONTROL |
| T43 | TRANSFORMER, REHEAT |
| TB2 | TERMINAL STRIP, UNIT |
| TB13 | TERMINAL STRIP, POWER DISTRIBUTION |

- ⚠ ONLY IN UNITS WITH HUMIDITROL OR PHASE AND VOLTAGE DETECTION OPTION
- ⚠ EXTERNAL HUMIDITROL CONTACTS
- ⚠ S49 AND S50 ARE PART OF 5VDC CIRCUIT
- ⚠ J268-1,-3 AND J268-2,-4 ARE CONNECTED ON UNITS WITHOUT HUMIDITROL OR PHASE DETECTION OPTIONS
- ⚠ B10 IS NOT USED ON UNITS WITH ERV
- ⚠ USED ON UNITS WITH ERV SINGLE POINT POWER. SEE ERV DIAGRAM
- ⚠ K65 IS CONTROLLED BY A1 ONLY IN TARGET ALC APPLICATIONS
- ⚠ USED ON LCH AND UNITS WITH ERV SINGLE POINT POWER ONLY
- ⚠ DO7 USED ON UNITS WITH HUMIDITROL TO POWER EXHAUST FANS. DO6 PROVIDES POWER TO K65 ON UNITS WITH NO HUMIDITROL
- ⚠ NOTE: FOR USE WITH COPPER CONDUCTORS ONLY. REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE.
- ⚠ F61 AND F10 USED ON LGH UNITS WITH SCCR OPTION
- ⚠ MOVE WIRE FROM 240 TO 208 TAP ON TRANSFORMER FOR 208 VOLT APPLICATIONS
- ⚠ CB10 NOT AVAILABLE ON UNITS WITH SCCR OPTION

| J/P | JACK/PLUG DESCRIPTION |
|-----|--------------------------------|
| 18 | POWER, EXHAUST FAN |
| 86 | POWER, OUTDOOR FAN 1 |
| 87 | POWER, OUTDOOR FAN 2 |
| 132 | POWER, EXHAUST FAN MOTOR |
| 194 | GP CONTROL INPUT/OUTPUT |
| 246 | POWER TO VFD |
| 247 | POWER, VFD TO MOTOR |
| 248 | VFD CONTROL |
| 263 | HIGH AND LOW PRESSURE SWITCHES |
| 264 | BLOWER DECK |
| 265 | CONTACTORS AND RELAYS |
| 267 | OUTDOOR FAN AREA |
| 268 | TRANSFORMER T1 POWER |
| 269 | TRANSFORMER T43 POWER |
| 298 | IAQ INTERFACE |
| 299 | HUMIDITROL, SAFETY |

⚡ DENOTES OPTIONAL COMPONENTS
 — LINE VOLTAGE FIELD INSTALLED

2018/07
WIRING DIAGRAM
07/18

537907-02


COOLING - MSAV NO BYPASS

LCH/LGH - 150H - Y

SECTION B
REV 0

Supersedes
537907-01
New Form No.
537907-02

LGH150H G, J, M - STAGED SUPPLY AIR, NO BYPASS, BELT DRIVE BLOWER



| KEY | COMPONENT |
|-----------|---|
| A1 | PANEL, AUTOMATED LOGIC CONTROL (ALC) |
| A55 | PANEL, MAIN |
| A96 | CONTROL INVERTER |
| B1 | COMPRESSOR 1 |
| B2 | COMPRESSOR 2 |
| B3 | MOTOR, BLOWER |
| B4 | MOTOR, OUTDOOR FAN 1 |
| B5 | MOTOR, OUTDOOR FAN 2 |
| B10 | MOTOR, EXHAUST FAN |
| C1 | CAPACITOR, OUTDOOR FAN 1 |
| C2 | CAPACITOR, OUTDOOR FAN 2 |
| C6 | CAPACITOR, EXHAUST FAN |
| CB8 | CIRCUIT BREAKER, T1 |
| CB10 | CIRCUIT BREAKER, MAIN DISCONNECT, UNIT |
| CB31 | CIRCUIT BREAKER, TRANSFORMER T43 |
| F4 | FUSE, UNIT |
| F10 | FUSE, OUTDOOR FAN MOTOR |
| F61 | FUSE, SCCR OPTION UNIT |
| HR1 | HEATER, COMPRESSOR 1 |
| HR2 | HEATER, COMPRESSOR 2 |
| J11 | JACK, GFI RECEPTACLE |
| K1,-1 | CONTACTOR, COMPRESSOR 1 |
| K2,-1 | CONTACTOR, COMPRESSOR 2 |
| K3,-1 | CONTACTOR, BLOWER |
| K10,-1,2 | RELAY, OUTDOOR FAN 1 |
| K65,-1,2 | RELAY, EXHAUST FAN |
| K68,-1,2 | RELAY, OUTDOOR FAN 2 |
| K203,-2 | RELAY, INVERTER START/RUN |
| K251,-1,2 | RELAY, 2 SPEED MOTOR HIGH |
| K252,-1,2 | RELAY, 2 SPEED MOTOR LOW |
| L14 | VALVE SOLENOID, REHEAT COIL 1 |
| R55 | RESISTOR, VFD LOADING, A96 |
| RT17 | SENSOR, OUTSIDE AIR TEMPERATURE |
| S4 | SWITCH, LIMIT HI PRESS COMP 1 |
| S5 | SWITCH, LIMIT HI TEMP COMPRESSOR 1 |
| S7 | SWITCH, LIMIT HI PRESS COMPRESS 2 |
| S8 | SWITCH, LIMIT HI TEMP COMPRESSOR 2 |
| S11 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMP |
| S48 | SWITCH, DISCONNECT |
| S49 | SWITCH, FREEZESTAT COMP 1 |
| S50 | SWITCH, FREEZESTAT COMP 2 |
| S84 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMP |
| S87 | SWITCH, LOW PRESS, COMPRESSOR 1 |
| S88 | SWITCH, LOW PRESS, COMPRESSOR 2 |
| T1 | TRANSFORMER, CONTROL |
| T43 | TRANSFORMER, REHEAT |
| TB2 | TERMINAL STRIP, UNIT |
| TB13 | TERMINAL STRIP, POWER DISTRIBUTION |


| J/P | JACK/PLUG DESCRIPTION |
|-----|--------------------------------|
| 18 | POWER, EXHAUST FAN |
| 86 | POWER, OUTDOOR FAN 1 |
| 87 | POWER, OUTDOOR FAN 2 |
| 132 | POWER, EXHAUST FAN MOTOR |
| 194 | GP CONTROL INPUT/OUTPUT |
| 246 | POWER TO VFD |
| 247 | POWER, VFD TO MOTOR |
| 248 | VFD CONTROL |
| 263 | HIGH AND LOW PRESSURE SWITCHES |
| 264 | BLOWER DECK |
| 265 | CONTACTORS AND RELAYS |
| 267 | OUTDOOR FAN AREA |
| 268 | TRANSFORMER T1 POWER |
| 269 | TRANSFORMER T43 POWER |
| 298 | IAQ INTERFACE |
| 299 | HUMIDITROL, SAFETY |

- ▲ ONLY IN UNITS WITH HUMIDITROL OR PHASE AND VOLTAGE DETECTION OPTION
- ▲ EXTERNAL HUMIDITROL CONTACTS
- ▲ S49 AND S50 ARE PART OF 5VDC CIRCUIT
- ▲ J268-1,-3 AND J268-2,-4 ARE CONNECTED ON UNITS WITHOUT HUMIDITROL OR PHASE DETECTION OPTIONS
- ▲ B10 IS NOT USED ON UNITS WITH ERV
- ▲ USED ON UNITS WITH ERV SINGLE POINT POWER. SEE ERV DIAGRAM
- ▲ K65 IS CONTROLLED BY A1 ONLY IN TARGET ALC APPLICATIONS
- ▲ USED ON LCH AND UNITS WITH ERV SINGLE POINT POWER ONLY
- ▲ DO7 USED ON UNITS WITH HUMIDITROL TO POWER EXHAUST FANS. DO6 PROVIDES POWER TO K65 ON UNITS WITH NO HUMIDITROL
- ▲ NOTE: FOR USE WITH COPPER CONDUCTORS ONLY. REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE.
- ▲ F61 AND F10 USED ON LGH UNITS WITH SCCR OPTION
- ▲ MOVE WIRE FROM 240 TO 208 TAP ON TRANSFORMER FOR 208 VOLT APPLICATIONS
- ▲ CB10 NOT AVAILABLE ON UNITS WITH SCCR OPTION

— DENOTES OPTIONAL COMPONENTS
 — LINE VOLTAGE FIELD INSTALLED

| | | |
|-------------------------|----------------|-------|
| 2018/07 | WIRING DIAGRAM | 07/18 |
| | 537908-02 | |
| COOLING -MSAV NO BYPASS | | |
| LCH/LGH -150H - G,J,M | | |
| SECTION B | | REV 0 |
| Supersedes | New Form No. | |
| 537908-01 | 537908-02 | |

LGH092/102/120H STAGED SUPPLY AIR, WITH BYPASS, BELT DRIVE BLOWER




- ▲ ONLY IN UNITS WITH HUMIDITROL OR PHASE AND VOLTAGE DETECTION OPTION
- ▲ EXTERNAL HUMIDITROL CONTACTS
- ▲ S49 AND S50 ARE PART OF 5VDC CIRCUIT
- ▲ J268-1,-3 AND J268-2,-4 ARE CONNECTED ON UNITS WITHOUT HUMIDITROL OR PHASE DETECTION OPTIONS
- ▲ B10 IS NOT USED ON UNITS WITH ERV
- ▲ USED ON UNITS WITH ERV SINGLE POINT POWER. SEE ERV DIAGRAM
- ▲ A65 IS CONTROLLED BY A1 ONLY IN TARGET ALC APPLICATIONS
- ▲ USED ON LCH AND UNITS WITH ERV SINGLE POINT POWER ONLY
- ▲ DO7 USED ON UNITS WITH HUMIDITROL TO POWER EXHAUST FANS. DO6 PROVIDES POWER TO K65 ON UNITS WITH NO HUMIDITROL
- ▲ NOTE: FOR USE WITH COPPER CONDUCTORS ONLY. REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE.
- ▲ F61 AND F10 USED ON LGH UNITS WITH SCOR OPTION
- ▲ MOVE WIRE FROM 240 TO 208 TAP ON TRANSFORMER FOR 208 VOLT APPLICATIONS
- ▲ CB10 NOT AVAILABLE ON UNITS WITH SCOR OPTION

| J/P | JACK/PLUG DESCRIPTION |
|-----|--------------------------------|
| 18 | POWER, EXHAUST FAN |
| 86 | POWER, OUTDOOR FAN INTERFACE |
| 132 | POWER, EXHAUST FAN MOTOR |
| 194 | GP CONTROL INPUT/OUTPUT |
| 246 | POWER TO VFD |
| 247 | POWER, VFD TO MOTOR |
| 248 | VFD CONTROL |
| 249 | POWER, CONTACTOR BYPASS |
| 283 | HIGH AND LOW PRESSURE SWITCHES |
| 284 | BLOWER DECK |
| 285 | CONTACTORS AND RELAYS |
| 287 | OUTDOOR FAN AREA |
| 288 | TRANSFORMERS T1 POWER |
| 289 | TRANSFORMER T43 POWER |
| 298 | IAQ INTERFACE |
| 299 | HUMIDITROL, SAFETY |

— DENOTES OPTIONAL COMPONENTS
 — LINE VOLTAGE FIELD INSTALLED

| | | |
|------------------------------------|----------------|-------|
| 2018/07 | WIRING DIAGRAM | 07/18 |
| | 537627-04 | |
| COOLING -MSAV WITH BYPASS | | |
| LCH/LGH - 092H,102H,120H - G,J,M,Y | | |
| SECTION B | | REV 0 |
| Supersedes | New Form No. | |
| 537627-03 | 537627-04 | |

LGH150H - Y - STAGED SUPPLY AIR, WITH BYPASS, BELT DRIVE BLOWER



NOTE - IF ANY WIRE IN THIS APPLIANCE IS REPLACED IT MUST BE REPLACED WITH WIRE OF LIKE SIZE, RATING, TERMINATION AND INSULATION THICKNESS.

DISCONNECT ALL POWER BEFORE SERVICING!


| KEY | COMPONENT |
|-----------|---|
| A1 | PANEL, AUTOMATED LOGIC CONTROL (ALC) |
| A55 | PANEL, MAIN |
| A96 | CONTROL INVERTER |
| B1 | COMPRESSOR 1 |
| B2 | COMPRESSOR 2 |
| B3 | MOTOR, BLOWER |
| B4 | MOTOR, OUTDOOR FAN 1 |
| B5 | MOTOR, OUTDOOR FAN 2 |
| B10 | MOTOR, EXHAUST FAN |
| C1 | CAPACITOR, OUTDOOR FAN 1 |
| C2 | CAPACITOR, OUTDOOR FAN 2 |
| C6 | CAPACITOR, EXHAUST FAN |
| CB8 | CIRCUIT BREAKER, T1 |
| CB10 | CIRCUIT BREAKER, MAIN DISCONNECT, UNIT |
| CB31 | CIRCUIT BREAKER, TRANSFORMER T43 |
| F4 | FUSE, UNIT |
| F10 | FUSE, OUTDOOR FAN MOTOR |
| F61 | FUSE, SCCR OPTION UNIT |
| HR1 | HEATER, COMPRESSOR 1 |
| HR2 | HEATER, COMPRESSOR 2 |
| J11 | JACK, GFI RECEPTICLE |
| K1,-1 | CONTACTOR, COMPRESSOR 1 |
| K2,-1 | CONTACTOR, COMPRESSOR 2 |
| K3,-1 | CONTACTOR, BLOWER |
| K10,-1,2 | RELAY, OUTDOOR FAN 1 |
| K65,-1,2 | RELAY, EXHAUST FAN |
| K68,-1,2 | RELAY, OUTDOOR FAN 2 |
| K202,-1 | CONTACTOR, POWER TO MOTOR |
| K203,-2 | RELAY, INVERTER START/RUN |
| K251,-1,2 | RELAY, 2 SPEED MOTOR |
| L14 | VALVE SOLENOID, REHEAT COIL 1 |
| R55 | RESISTOR, VFD LOADING, A96 |
| RT17 | SENSOR, OUTSIDE AIR TEMPERATURE |
| S4 | SWITCH, LIMIT HI PRESS COMP 1 |
| S5 | SWITCH, LIMIT HI TEMP COMPRESSOR 1 |
| S7 | SWITCH, LIMIT HI PRESS COMPRESSOR 2 |
| S8 | SWITCH, LIMIT HI TEMP COMPRESSOR 2 |
| S11 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMP |
| S48 | SWITCH, DISCONNECT |
| S49 | SWITCH, FREEZESTAT COMP 1 |
| S50 | SWITCH, FREEZESTAT COMP 2 |
| S84 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMP |
| S87 | SWITCH, LOW PRESS, COMPRESSOR 1 |
| S88 | SWITCH, LOW PRESS, COMPRESSOR 2 |
| T1 | TRANSFORMER, CONTROL |
| T43 | TRANSFORMER, REHEAT |
| TB2 | TERMINAL STRIP, UNIT |

120 V FIELD PROVIDED POWER SUPPLY IS REQUIRED


| J/P | JACK/PLUG DESCRIPTION |
|-----|--------------------------------|
| 18 | POWER, EXHAUST FAN |
| 86 | POWER, OUTDOOR FAN 1 |
| 87 | POWER, OUTDOOR FAN 2 |
| 132 | POWER, EXHAUST FAN MOTOR |
| 194 | GP CONTROL INPUT/OUTPUT |
| 246 | POWER TO VFD |
| 247 | POWER, VFD TO MOTOR |
| 248 | VFD CONTROL |
| 249 | POWER, CONTACTOR BYPASS |
| 263 | HIGH AND LOW PRESSURE SWITCHES |
| 264 | BLOWER DECK |
| 265 | CONTACTORS AND RELAYS |
| 267 | OUTDOOR FAN AREA |
| 268 | TRANSFORMERS T1 POWER |
| 269 | TRANSFORMER T43 POWER |
| 298 | IAQ INTERFACE |
| 2 | HUMIDITROL, SAFETY |

- ▲ ONLY IN UNITS WITH HUMIDITROL OR PHASE AND VOLTAGE DETECTION OPTION
- ▲ EXTERNAL HUMIDITROL CONTACTS
- ▲ S49 AND S50 ARE PART OF 5VDC CIRCUIT
- ▲ J268-1,-3 AND J268-2,-4 ARE CONNECTED ON UNITS WITHOUT HUMIDITROL OR PHASE DETECTION OPTIONS
- ▲ F10 IS NOT USED ON UNITS WITH ERV
- ▲ USED ON UNITS WITH ERV SINGLE POINT POWER. SEE ERV DIAGRAM
- ▲ S5 IS CONTROLLED BY A1 ONLY IN TARGET ALC APPLICATIONS
- ▲ USED ON LCH AND UNITS WITH ERV SINGLE POINT POWER ONLY
- ▲ DO7 USED ON UNITS WITH HUMIDITROL TO POWER EXHAUST FANS. DO6 PROVIDES POWER TO K65 ON UNITS WITH NO HUMIDITROL
- ▲ NOTE: FOR USE WITH COPPER CONDUCTORS ONLY. REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE.
- ▲ F61 AND F10 USED ON LGH UNITS WITH SCCR OPTION
- ▲ MOVE WIRE FROM 240 TO 208 TAP ON TRANSFORMER FOR 208 VOLT APPLICATIONS
- ▲ CB10 NOT AVAILABLE ON UNITS WITH SCCR OPTION

← DENOTES OPTIONAL COMPONENTS
 — LINE VOLTAGE FIELD INSTALLED

| | | | | |
|--------------------------------|--|---------------------------|-------|--|
| 2018/07 |  | WIRING DIAGRAM | 07/18 | |
| | 537909-02 | | | |
| | COOLING -MSAV WITH BYPASS | | | |
| | LCH/LGH - 150H - Y | | | |
| Supersedes 537909-01 | | SECTION B New Form No. | REV 0 | |
| 537909-01 | | 537909-02 | | |

LGH150H - G, J, M - STAGED SUPPLY AIR, WITH BYPASS, BELT DRIVE BLOWER



| KEY | COMPONENT |
|-----------|---|
| A1 | PANEL, AUTOMATED LOGIC CONTROL (ALC) |
| A55 | PANEL, MAIN |
| A96 | CONTROL INVERTER |
| B1 | COMPRESSOR 1 |
| B2 | COMPRESSOR 2 |
| B3 | MOTOR, BLOWER |
| B4 | MOTOR, OUTDOOR FAN 1 |
| B5 | MOTOR, OUTDOOR FAN 2 |
| B10 | MOTOR, EXHAUST FAN |
| C1 | CAPACITOR, OUTDOOR FAN 1 |
| C2 | CAPACITOR, OUTDOOR FAN 2 |
| C6 | CAPACITOR, EXHAUST FAN |
| CB8 | CIRCUIT BREAKER, T1 |
| CB10 | CIRCUIT BREAKER, MAIN DISCONNECT, UNIT |
| CB31 | CIRCUIT BREAKER, TRANSFORMER T43 |
| F4 | FUSE, UNIT |
| F10 | FUSE, OUTDOOR FAN MOTOR |
| F61 | FUSE, SCCR OPTION UNIT |
| HR1 | HEATER, COMPRESSOR 1 |
| HR2 | HEATER, COMPRESSOR 2 |
| J11 | JACK, GFI RECEPTACLE |
| K1,-1 | CONTACTOR, COMPRESSOR 1 |
| K2,-1 | CONTACTOR, COMPRESSOR 2 |
| K3,-1 | CONTACTOR, BLOWER |
| K10,-1,2 | RELAY, OUTDOOR FAN 1 |
| K65,-1,2 | RELAY, EXHAUST FAN |
| K68,-1,2 | RELAY, OUTDOOR FAN 2 |
| K202,-1 | CONTACTOR, POWER TO MOTOR |
| K203,-2 | RELAY, INVERTER START/RUN |
| K251,-1,2 | RELAY, 2 SPEED MOTOR HIGH |
| K252,-1,2 | RELAY, 2 SPEED MOTOR LOW |
| L14 | VALVE SOLENOID, REHEAT COIL 1 |
| R55 | RESISTOR, VFD LOADING, A96 |
| RT17 | SENSOR, OUTSIDE AIR TEMPERATURE |
| S4 | SWITCH, LIMIT HI PRESS COMP 1 |
| S5 | SWITCH, LIMIT HI TEMP COMPRESSOR 1 |
| S7 | SWITCH, LIMIT HI PRESS COMPRESSOR 2 |
| S8 | SWITCH, LIMIT HI TEMP COMPRESSOR 2 |
| S11 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMP |
| S48 | SWITCH, DISCONNECT |
| S49 | SWITCH, FREEZESTAT COMP 1 |
| S50 | SWITCH, FREEZESTAT COMP 2 |
| S84 | SWITCH, LOW PRESS, LOW AMBIENT KIT COMP |
| S87 | SWITCH, LOW PRESS, COMPRESSOR 1 |
| S88 | SWITCH, LOW PRESS, COMPRESSOR 2 |
| T1 | TRANSFORMER, CONTROL |
| T43 | TRANSFORMER, REHEAT |
| TB2 | TERMINAL STRIP, UNIT |

120 V FIELD PROVIDED POWER SUPPLY IS REQUIRED


| J/P | JACK/PLUG DESCRIPTION |
|-----|--------------------------------|
| 18 | POWER, EXHAUST FAN |
| 86 | POWER, OUTDOOR FAN 1 |
| 87 | POWER, OUTDOOR FAN 2 |
| 132 | POWER, EXHAUST FAN MOTOR |
| 194 | GP CONTROL INPUT/OUTPUT |
| 246 | POWER TO VFD |
| 247 | POWER, VFD TO MOTOR |
| 248 | VFD CONTROL |
| 249 | POWER, CONTACTOR BYPASS |
| 263 | HIGH AND LOW PRESSURE SWITCHES |
| 264 | BLOWER DECK |
| 265 | CONTACTORS AND RELAYS |
| 267 | OUTDOOR FAN AREA |
| 268 | TRANSFORMERS T1 POWER |
| 269 | TRANSFORMER T43 POWER |
| 298 | IAQ INTERFACE |
| 299 | HUMIDITROL, SAFETY |

- ⚠️ ONLY IN UNITS WITH HUMIDITROL OR PHASE AND VOLTAGE DETECTION OPTION
- ⚠️ EXTERNAL HUMIDITROL CONTACTS
- ⚠️ S49 AND S50 ARE PART OF 5VDC CIRCUIT
- ⚠️ J268-1,-3 AND J268-2,-4 ARE CONNECTED ON UNITS WITHOUT HUMIDITROL OR PHASE DETECTION OPTIONS
- ⚠️ S10 IS NOT USED ON UNITS WITH ERV
- ⚠️ USED ON UNITS WITH ERV SINGLE POINT POWER. SEE ERV DIAGRAM
- ⚠️ S5 IS CONTROLLED BY A1 ONLY IN TARGET ALC APPLICATIONS
- ⚠️ USED ON LCH AND UNITS WITH ERV SINGLE POINT POWER ONLY
- ⚠️ DO7 USED ON UNITS WITH HUMIDITROL TO POWER EXHAUST FANS. DO6 PROVIDES POWER TO K65 ON UNITS WITH NO HUMIDITROL
- ⚠️ NOTE: FOR USE WITH COPPER CONDUCTORS ONLY. REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE.
- ⚠️ F61 & F10 USED ON LGH UNITS WITH SCCR OPTION
- ⚠️ MOVE WIRE FROM 240 TO 208 TAP ON TRANSFORMER FOR 208 VOLT APPLICATIONS
- ⚠️ CB10 NOT AVAILABLE ON UNITS WITH SCCR OPTION

— DENOTES OPTIONAL COMPONENTS
 — LINE VOLTAGE FIELD INSTALLED

| | | |
|---------------------------|---------------------------|-------|
| 2018/07 | WIRING DIAGRAM | 07/18 |
| 537910-02 | | |
| COOLING -MSAV WITH BYPASS | | |
| LCH/LGH - 150H - G,J,M | | |
| SECTION B | | REV 0 |
| Supersedes 537910-01 | New Form No. 537910-02 | |

LGH092-152U STAGED SUPPLY AIR, WITH BYPASS, BELT DRIVE BLOWER



| KEY | COMPONENT |
|----------|--|
| A1 | PANEL, AUTOMATED LOGIC CONTROL (ALC) |
| A55 | PANEL, MAIN |
| A96 | CONTROL INVERTER |
| B1 | COMPRESSOR 1 |
| B2 | COMPRESSOR 2 |
| B3 | MOTOR, BLOWER |
| B4 | MOTOR, OUTDOOR FAN 1 |
| B5 | MOTOR, OUTDOOR FAN 2 |
| B10 | MOTOR, EXHAUST FAN |
| B21 | MOTOR, OUTDOOR FAN 3 |
| C6 | CAPACITOR, EXHAUST FAN |
| CB8 | CIRCUIT, BREAKER |
| CB10 | CIRCUIT BREAKER, MAIN DISCONNECT, UNIT |
| CB31 | CIRCUIT BREAKER, TRANSFORMER T43 |
| F4 | FUSE, UNIT |
| F10 | FUSE, OUTDOOR FAN MOTOR |
| F57 | FUSE, T5 TRANSFORMER PRIMARY |
| F61 | FUSE, UNIT SCCR OPTION |
| HR1 | HEATER, COMPRESSOR 1 |
| HR2 | HEATER, COMPRESSOR 2 |
| J11 | JACK, GFI RECEPTICLE |
| K1-1 | CONTACTOR, COMPRESSOR 1 |
| K2-1 | CONTACTOR, COMPRESSOR 2 |
| K3-1 | CONTACTOR, BLOWER |
| K191-1 | RELAY, OUTDOOR FAN 1 |
| K65-1,2 | RELAY, EXHAUST FAN |
| K194-1 | RELAY, OUTDOOR FAN 2 |
| K202-1 | CONTACTOR, POWER TO MOTOR |
| K203-1,2 | RELAY, INVERTER START/RUN |
| L41 | TXV VALVE SOLENOID, |
| L42 | TXV VALVE SOLENOID, |
| R55 | RESISTOR, VFD LOADING, A96 |
| RT17 | SENSOR, OUTSIDE AIR TEMPERATURE |
| S4 | SWITCH, LIMIT HI PRESS, COMP 1 |
| S5 | SWITCH, LIMIT HI TEMP COMPRESSOR 1 |
| S8 | SWITCH, LIMIT HI TEMP COMPRESSOR 2 |
| S11 | SWITCH, LOW PRESS, LOW AMBIENT KIT COM |
| S48 | SWITCH, DISCONNECT |
| S49 | SWITCH, FREEZESTAT COMP 1 |
| S50 | SWITCH, FREEZESTAT COMP 2 |
| S87 | SWITCH, LOW PRESS, COMPRESSOR 1 |
| T1 | TRANSFORMER, CONTROL |
| T5 | TRANSFORMER, |
| T43 | TRANSFORMER, REHEAT |
| TB2 | TERMINAL STRIP, UNIT |
| TB13 | TERMINAL STRIP, POWER DISTRIBUTION |

| J/P | JACK-PLUG DESCRIPTION |
|-----|----------------------------------|
| 18 | POWER, EXHAUST FAN |
| 86 | POWER, OUTDOOR FAN INTERFACE B4 |
| 87 | POWER, OUTDOOR FAN INTERFACE B5 |
| 88 | POWER, OUTDOOR FAN INTERFACE B21 |
| 132 | POWER, EXHAUST FAN MOTOR |
| 246 | POWER TO VFD |
| 247 | POWER, VFD TO MOTOR |
| 248 | VFD CONTROL |
| 249 | POWER, CONTACTOR BYPASS |
| 259 | BLOWER CONTROL HARNESS |
| 263 | HIGH AND LOW PRESSURE SWITCHES |
| 264 | BLOWER DECK |
| 265 | CONTACTORS AND RELAYS |
| 267 | OUTDOOR FAN AREA |
| 268 | TRANSFORMERS T1 POWER |
| 269 | TRANSFORMER T43 POWER |
| 298 | IAQ INTERFACE |

- ⚠ F5 USED ON G & J VOLTAGE ONLY
- ⚠ USED ON 094U, 122U, 152U UNITS ONLY
- ⚠ S49 AND S50 ARE PART OF 5VDC CIRCUIT
- ⚠ OPTIONAL
- ⚠ K65 CONTROLLED BY A1, IN TARGET ALC APPLICATIONS ONLY
- ⚠ DO7 USED ON UNITS WITH HUMIDITROL TO POWER EXHAUST FANS. DO6 PROVIDES POWER TO K65 ON UNITS WITH NO HUMIDITROL
- ⚠ NOTE: FOR USE WITH COPPER CONDUCTORS ONLY. REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT
- ⚠ F10 USED ON UNITS WITH SCCR OPTION. F61 USED ON LGH UNITS WITH SCCR OPTION
- ⚠ MOVE WIRE FROM 240 TO 208 TAP ON TRANSFORMER FOR 208 VOLT APPLICATIONS
- ⚠ CB10 NOT AVAILABLE ON UNITS WITH SCCR OPTION

— DENOTES OPTIONAL COMPONENTS
 — LINE VOLTAGE FIELD INSTALLED

| | | |
|---|----------------|-------|
| 2019/02 | WIRING DIAGRAM | 02/19 |
| | 537617-04 | |
| COOLING -MSAV WITH BYPASS | | |
| (ULTRA) LCH/LGH - 092U, 094U, 120U, 122U, 152U - Y, G, J, M | | |
| SECTION B | | REV 1 |
| Supersedes | New Form No. | |
| 537617-03 | 537617-04 | |

SUPPLY AIR INVERTER - NO BYPASS SEQUENCE OF OPERATION

OPERATION:

- 1- A55 energizes the K203 relay coil.
- 2- K203-2 N.O. contacts close to start A96 forward rotation signal STF.
- 3- Blower B3 speed is controlled by a 0-10VDC signal from A55 to A96 terminal 2. VFD output voltage can be checked between A96 terminals 2 and 5.

A96 FAULT SEQUENCE:

A96 will interrupt the 0-10VDC signal at terminal 2 on an internal failure. A96 will retry three times before terminals B-C open. In addition, A55 will recognize A96 B-C contacts are open and A55 will de-energize the K203 coil.

Optional S52 Blower Proving Switch Installed - Refer to Blower Fault Sequence below.

SUPPLY AIR INVERTER - WITH OPTIONAL FACTORY-INSTALLED BYPASS SEQUENCE OF OPERATION

OPERATION:

- 1- A55 energizes K202 and K203 relay coils.
- 2- K203-1 N.C. contacts open to de-energize K3 relay coil. K3-1 N.O. relay contacts open to interrupt power to B3 blower motor through K3 N.O. relay contacts.
- 3- K202 contacts close to allow power to B3 blower motor from A96.
- 4- K203-2 N.O. contacts close to start A96 forward rotation signal STF.
- 5- Blower B3 speed is controlled by a 0-10VDC signal from A55 PWM1/VO) to A96 terminal 2. VFD output voltage can be checked between A96 terminals 2 and 5.

A96 FAULT SEQUENCE:

The same sequence as shown above. Note that the same alarms will be displayed whether there is an A96 internal fault, a blower component failure, or a control failure.

BLOWER FAULT SEQUENCE:

- 1- The control system initiates a blower demand.
- 2- After 16 seconds, if S52 remains open, A55 will shut the blower down for 5 minutes.
- 3- A55 will energize the blower.
- 4- After 16 seconds if S52 remains open, A55 will shut the blower down for another 5 minutes.
- 5- After the third try, A55 will shut the unit down.

Note - The unit will remain in lockout until the failed component is fixed or A55 selection conditions are changed to: M2-SETTINGS-CONTROL-MSAV-VFD BYPASS-ENGAGE M3-RTU OPTION-BLOWER-VFD BYPASS DISENGAGED - NO (configuration ID 1 set to A=automatic bypass).


- 6- The VFD can be set to automatically bypass the VFD after the third start attempt. A55 selection condition must be changed to:
*M2-SETTINGS-INSTALL-NEW M2-MSAV VFD BYPASS-AUTOMATIC
M3-RTU OPTION-BLOWER-VFD BYPASS DISENGAGED - YES (configuration ID 1 set to M=manual bypass)*

Note - Regardless of whether the blower is started in CAV mode using the "engage" selection or the "automatic" selection, S52 will still lock out the the blower after 16 seconds.


- 7- Do not immediately assume the inverter has failed. Troubleshoot the unit keeping the following in mind:
 - Be sure to check multiple components and controls when troubleshooting. A blower component, inverter, or control failure will show the same alarms as an internal VFD fault condition (open A96 terminals B-C).
 - If there are no thermostat wires connected to A55 terminal P297, check the control system to verify a blower demand.
 - S52 is factory-installed in units equipped with the VFD bypass option. S52 is shown on the thermostat diagram.
 - Make sure blower demand is continuous; if blower demand is interrupted A96 and A55 timers will reset.

LGH/LCH092-152U STAGED SUPPLY AIR, DIRECT DRIVE BLOWER

24 VAC POWER



| KEY | COMPONENT |
|---------|----------------------------------|
| A55 | PANEL, MAIN |
| A185 | PRESSURE TRANSDUCER |
| B1 | COMPRESSOR 1 |
| B2 | COMPRESSOR 2 |
| B3 | MOTOR, BLOWER |
| B4 | MOTOR, OUTDOOR FAN 1 |
| B5 | MOTOR, OUTDOOR FAN 2 |
| B10 | MOTOR, EXHAUST FAN |
| B21 | MOTOR, OUTDOOR FAN 3 |
| C6 | CAPACITOR, EXHAUST FAN |
| CB8 | CIRCUIT BRKR., TRANSFORMER T1 |
| CB10 | CIRCUIT BRKR., UNIT MAIN DISCONN |
| CB31 | CIRCUIT BRKR., TRANSFORMER T43 |
| F4 | FUSE, UNIT |
| F10 | FUSE, OUTDOOR FAN MOTOR |
| F27 | FUSE, T4 TRANSFORMER PRIMARY |
| F57 | FUSE, T5 TRANSFORMER PRIMARY |
| F61 | FUSE, UNIT SCOR OPTION |
| HR1 | HEATER, COMPRESSOR 1 |
| HR2 | HEATER, COMPRESSOR 2 |
| J11 | JACK, GFI RECEPITCLE |
| K1-1 | CONTACTOR, COMPRESSOR 1 |
| K2-1 | CONTACTOR, COMPRESSOR 2 |
| K3-1 | CONTACTOR, BLOWER |
| K65-1,2 | RELAY, EXHAUST FAN |
| K191,-1 | CRANKCASE HTR #1 |
| K194,-1 | CRANKCASE HTR #2 |
| L41 | TXV VALVE, SOLENOID |
| L42 | TXV VALVE, SOLENOID |
| RT17 | SENSOR, OUTSIDE AIR TEMP. |
| RT37 | TEMP. SENSOR COMP. #1 |
| RT38 | TEMP. SENSOR COMP. #2 |
| S4 | SWITCH, LMT HI PRESS. COMP 1 & 2 |
| S5 | SWITCH, LIMIT HI TEMP COMP. 1 |
| S8 | SWITCH, LIMIT HI TEMP COMP. 2 |
| S11 | SW., LW PR. LW AMBNT KIT CMP 1 |
| S42 | SWITCH, OVERLDR RLY BLWR MTR |
| S48 | SWITCH, DISCONNECT |
| S49 | SWITCH, FREEZESTAT COMP 1 |
| S87 | SWITCH, LOW PRESS. COMP. 1 |
| T1 | TRANSFORMER, CONTROL |
| T4 | TRANSFORMER |
| T5 | TRANSFORMER |
| T43 | TRANSFORMER, REHEAT |
| TB2 | TERMINAL STRIP, UNIT |
| TB13 | TERMINAL STRIP, POWER DISTR. |



| J/P | JACK/PLUG DESCRIPTION |
|-----|--------------------------------|
| 18 | EXHAUST FAN |
| 86 | OUTDOOR FAN INTERFACE B4 |
| 87 | OUTDOOR FAN INTERFACE B5 |
| 88 | OUTDOOR FAN INTERFACE B21 |
| 132 | EXHAUST FAN MOTOR |
| 259 | ECM BLOWER MOTOR CONTROL |
| 263 | HIGH AND LOW PRESSURE SWITCHES |
| 264 | BLOWER DECK |
| 265 | CONTACTORS AND RELAYS |
| 267 | OUTDOOR FAN AREA |
| 268 | TRANSFORMER T1 POWER |
| 269 | HUMIDITROL CONTROL |
| 293 | F27, LINE SIDE |
| 294 | F27, LOAD SIDE |
| 333 | 0-5V TRANSDUCER INPUT |

- ⚠ USED ON 094U, 122U, 152U UNITS ONLY
- ⚠ T5 ONLY USED ON G AND J VOLTAGE UNITS
- ⚠ S49 IS PART OF 5VDC CIRCUIT
- ⚠ OPTIONAL
- ⚠ T4 ONLY USED J VOLTAGE UNITS
- ⚠ NOTE: FOR USE WITH COPPER CONDUCTORS ONLY. REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE.
- ⚠ F61 AND F10 USED ON LGH UNITS WITH SCOR OPTION
- ⚠ MOVE WIRE FROM 240 TO 208 TAP ON TRANSFORMER FOR 208 VOLT APPLICATIONS
- ⚠ CB10 NOT AVAILABLE ON UNITS WITH SCOR OPTION

— DENOTES OPTIONAL COMPONENTS
 — LINE VOLTAGE FIELD INSTALLED

| | | |
|---|----------------|------------------------|
| 2018/07 | WIRING DIAGRAM | 07/18 |
| | 537618-03 | |
| COOLING | | |
| Energence Ultra EBM LCH/LGH - 092U, 094U, 120U, 122U, 152U - Y, G, J, M | | |
| SECTION B | | REV 0 |
| Supersedes 537618-02 | | New Form No. 537618-03 |

Direct Drive EBM Blower Motor: The blower speed is determined by thermostat demand and settings programmed into the A55. When A55 receives a Y1 demand, a low speed voltage output from A55 terminal 4 will energize B3 in low speed. When A55 receives a Y2 demand, a high speed voltage output from A55 terminal 4 will energize B3 in high speed. A55 output voltage can be checked between A55 terminals 4 and 6.

DIRECT DRIVE BLOWER SEQUENCE OF OPERATION / TROUBLESHOOTING

Blower Operation:

- 1- Line voltage is routed to B3 blower motor through TB2 terminal strip, TB13 terminal strip, T4 transformer (575v units only), and J/P48 terminals 1, 2 and 3.
- 2- B3 blower motor runs internal diagnostics to check for proper temperature, voltage, etc. (KL2-2 and -3). This process takes approximately 10 seconds. Refer to the Failure Handling/Troubleshooting section.
- 3- A55 Unit Controller receives a thermostat demand. After the A55 proves (P259-7 and -6) that B3 blower motor internal relay (KL2-2 and -3) is closed, B3 blower motor is energized (0-10VDC from P259-4 to KL3-4). B3 blower motor controls are grounded through KL2-2 and -3 to A55 P259-6.
- 4- If configured, A55 checks S52 blower proving switch to make sure it closes within 16 seconds of the 0-10VDC signal being sent to B3 blower motor.

Blower Fault Sequence Direct Drive Motor - No S52:

- 1- Line voltage is provided to B3 blower motor.
- 2- After 10 seconds, the B3 blower motor internal relay does not close.
- 3- Alarm 186 is set by the A55 Unit Controller, de-energizing unit. If one of the "Error" failures listed in table 32 occurs ("Warning" failures will not set Alarm 186), service is required. Refer to the Failure Handling/Troubleshooting section.
- 4- If B3 blower motor internal relay closes continue to next step.
- 5- A55 sends 0-10VDC signal to B3 blower motor.
- 6- During B3 blower motor operation, the internal motor relay opens.
- 7- Alarm 186 is set by A55 and de-energizes the unit. Service is required. Refer to the Failure Handling/Troubleshooting section.

Blower Fault Sequence Direct Drive Motor - With S52 (If Configured):

- 1- A55 Unit Controller sends 0-10VDC signal to B3 blower motor.
- 2- After 16 seconds, if S52 blower proving switch remains open, A55 will remove 0-10VDC signal for 5 minutes.
- 3- A55 sends 0-10VDC signal to B3 blower motor.
- 4- After 16 seconds, if S52 blower proving switch remains open, A55 will remove 0-10VDC signal for another 5 minutes.
- 5- After the third try, A55 will de-energize the unit. Service is required.

Failure Handling/Troubleshooting:

- 1- Follow table 32 to troubleshoot possible failures that would cause Alarm 186 to set.
- 2- BEFORE DETERMINING THAT THE BLOWER ASSEMBLY HAS FAILED, use the A55 Unit Controller to clear delays and operate the blower.
- 3- Main Menu > Service > Offline > Clear Delays > Yes > Save
- 4- Main Menu > Service > Test > Blower
- 5- Observe if the blower operates or if Alarm 186 sets again.
- 6- If blower does not operate and Alarm 186 is set again, blower assembly must be replaced.
- 7- If blower assembly does operate, wait a minimum of 30 minutes to ensure Alarm 186 is not set again.

**TABLE 32
DIRECT DRIVE BLOWER MOTOR TROUBLESHOOTING**

| Failure | Error | Warning | Reason | Troubleshoot |
|-------------------------|-------|---------|--|--|
| Locked Rotor | • | | No changes in hall signals within 2000ms | Check for obstruction keeping impeller from rotating |
| Braking Mode | | • | Warning, no error code set, Motor start not possible after 20 sec | Check for secondary airflow source in the system causing the impeller to rotate backwards when off |
| Hall Error | • | | Combination of 3 hall signals gives false signal after one rotation | Measure voltage across each leg, Check electrical connections |
| Power Module Overheated | • | | Temperature > 115°C | Check operating conditions in blower compartment, Check for high motor load (current draw), Check for corrosion-free and secure electrical connections |
| Motor Overheated | • | | Motor over-temperature protector opens | |
| Gate Driver Error | • | | Internal software fault | Measure voltage across each leg, Check electrical connections |
| Phase Failure | • | | Input voltage has phase imbalance | Measure voltage across each leg, Check electrical connections, Repair low/high voltage leg(s) |
| DC Link Voltage Low | • | | Rectified DC link voltage is too low | |
| DC Link Over-voltage | • | | Rectified DC link voltage is too high | |
| Line Over-voltage | • | | Line voltage too high | |
| Line Under-voltage | • | | Line voltage too low | |
| Communication Error | • | | Internal communication failure. Not connected with master/slave wiring | Check low voltage wiring connections |
| DC Link Voltage Low | | • | Warning, not low enough to set error code | Measure voltage across each leg, Check electrical connections, Repair low/high voltage leg(s) |
| Electronics Temp High | | • | Warning, not high enough to set error code, Temperature > 95°C | Check operating conditions in blower compartment, Check for high motor load (current draw), Check for corrosion-free and secure electrical connections |
| Power Module Temp High | | • | Warning, not high enough to set error code, Temperature > 105°C | |
| Motor Temp High | | • | Warning, not high enough to set error code, Temperature > 130°C | |