


IMPORTANT

OBSERVE THE FOLLOWING PRECAUTIONS TO PREVENT DAMAGE TO HIGH- OR LOW-PRESSURE SWITCHES DURING INSTALLATION

PRESSURE SWITCH WILL BE DAMAGED IF SUBJECTED TO TEMPERATURES ABOVE 200°F



APPLY WET RAGS AND / OR THERMAL TRAP PASTE BELOW THE SWITCH BODY

TO PREVENT DAMAGE TO PRESSURE SWITCH PLASTIC COMPONENTS, WET RAGS AND / OR THERMAL TRAP PASTE MUST BE APPLIED BELOW THE SWITCH BODY BEFORE BRAZING. WET RAGS MUST BE LEFT ON PROTECTED AREA UNTIL BRAZED JOINT HAS COOLED DOWN TO AMBIENT TEMPERATURE TO PREVENT MIGRATION OF HEAT INTO THE SWITCH BODY.

0215




507530-01

IMPORTANT

OBSERVE THE FOLLOWING PRECAUTIONS TO PREVENT DAMAGE TO HIGH- OR LOW-PRESSURE SWITCHES DURING INSTALLATION

PRESSURE SWITCH WILL BE DAMAGED IF SUBJECTED TO TEMPERATURES ABOVE 200°F



APPLY WET RAGS AND / OR THERMAL TRAP PASTE BELOW THE SWITCH BODY

TO PREVENT DAMAGE TO PRESSURE SWITCH PLASTIC COMPONENTS, WET RAGS AND / OR THERMAL TRAP PASTE MUST BE APPLIED BELOW THE SWITCH BODY BEFORE BRAZING. WET RAGS MUST BE LEFT ON PROTECTED AREA UNTIL BRAZED JOINT HAS COOLED DOWN TO AMBIENT TEMPERATURE TO PREVENT MIGRATION OF HEAT INTO THE SWITCH BODY.

0215



507530-01